



## KEB\_GearAxisControl instructions

## FAQ No.0015

Part	Version	Revision	Date	Status
en	6.3.0.1	001	2019-01-01	Released

### Content

Introduction .....	2
General description .....	2
Restrictions .....	2
KEB_GearAxisControl .....	3
Variables .....	3
Input.....	3
Output.....	4
InverterEnable.....	5
Modes .....	6
9: Gearing.....	6
Disclaimer .....	8

## Introduction

This document gives a general overview of the KEB\_GearAxisControl function block. General terms and behaviour will be explained.

## General description

The KEB\_GearAxisControl function block allows the user to control a SoftMotion Drive in various modes using a single function block:

- Velocity
- Absolute Positioning
- Relative Positioning
- Set Position
- Homing
- Gearing

This function block is part of the KEB\_SMC\_Utility library.


The KEB\_GearAxisControl function block is an extension of the KEB\_SingleAxisControl block. It contains all the features of the above-mentioned block plus the Phasing mode.

For further information about these modes please see FAQ Document KEB\_SingleAxisControl.



## Restrictions

This function block can be used with Pro/Advanced Drive only. In fact, it needs two AXIS\_REF\_SM3 structure as input variable, **Master** and **Slave** Axis, structure that is automatically created when a SoftMotion Drive is added in the project.





## KEB\_GearAxisControl

### Variables

#### Input

Name	Type	Comment
<b>InverterEnable</b>	BOOL	As long as this variable is TRUE, the drive is switched on.
<b>Reset</b>	BOOL	Reset Drive or FunctionBlock errors
<b>AxisMode</b>	ENUM_AXISMODE	AM_DEFAULT = 0 AM_VELOCITY = 1 AM_POSITIONINGABSOLUTE = 2 AM_POSITIONINGRELATIVE=4 AM_SETPOSITION = 6 AM_HOMING = 7 AM_GEARING = 9
<b>Start</b>	BOOL	Run/Stop Drive in AxisMode Function
<b>Position</b>	LREAL	Target position for the motion (technical unit [units])
<b>Velocity</b>	LREAL	Value of the target velocity (not necessarily to be reached) [units/s]
<b>Direction</b>	MC_Direction	This enumeration provides the desired direction; only relevant for rotating axes (modulo-axis). Supported values depending of AxisMode: -1 = negative 0 = shortest (seen from the current position) 1 = positive 2 = current (current direction) 3 = fastest (direction, which would finish movement as fast as possible)
<b>Acceleration</b>	LREAL	Desired acceleration (increasing energy of the motor) [units/s <sup>2</sup> ]
<b>Deceleration</b>	LREAL	Desired deceleration (decreasing energy of the motor) [units/s <sup>2</sup> ]
<b>Jerk</b>	LREAL	Maximum magnitude of the jerk [units/s <sup>3</sup> ] (ignored for ramptype trapez)
<b>RatioNumerator</b>	INT	Counter of the gear ratio.
<b>RatioDenominator</b>	UINT	Denominator of the gear ratio.
<b>Master</b>	AXIS_REF_SM3	Master axis
<b>Axis</b>	AXIS_REF_SM3	Controlled/Slave axis

## Output

Name	Type	Comment
<b>AxisState</b>	SMC_AXIS_STATE	0: power_off 1: errorstop 2: stopping 3: standstill 4: discrete_motion 5: continuous_motion 6: synchronized_motion 7: homing
<b>RequestedAxisMode</b>	ENUM_AXISMODE	Shows requested axis mode
<b>ActualAxisMode</b>	ENUM_AXISMODE	Shows actual axis mode
<b>HomeDone</b>	BOOL	TRUE indicates that if homing is done
<b>Powered</b>	BOOL	As long as this variable is TRUE, the drive is switched on
<b>Done</b>	BOOL	TRUE indicates that the movement is on
<b>Active</b>	BOOL	TRUE indicates that the drive is moving
<b>Stopped</b>	BOOL	TRUE indicates that the drive is not moving
<b>InverterError</b>	BOOL	TRUE indicates drive error
<b>InverterErrorID</b>	DWORD	Use GetInvStateD function to get a STRING errormessage
<b>FBError</b>	BOOL	TRUE indicates FunctionBlock error
<b>FBErrorID</b>	SMC_error	Use SMC_ErrorString function to get a STRING errormessage
<b>ActPosition</b>	LREAL	Actual position [units]
<b>ActVelocity</b>	LREAL	Actual velocity [units/s]


## InverterEnable

To switch ON the drive, **InverterEnable** must be set to *TRUE*. Once *TRUE*, **AxisState** goes to *standstill* (after a brief moment in *stopping*), then **Powered** is set to *TRUE*. Now the drive is ready.

Once **Powered** is *TRUE* one can select an operational mode, insert the inputs and start the FB.

At the end of every operation, to switch OFF the drive, **InverterEnable** must be set to *FALSE*.

**AxisState** goes to *power off*, then **Powered** is set to *FALSE*.



## Modes


### 9: Gearing

By setting variable **AxisMode** to 9 the drive will be controlled in Gearing mode. In this mode it is mandatory to set **Acceleration** and **Deceleration** values (although **Velocity** will not affect the gearing behaviour).


**Acceleration** and **Deceleration** values will affect the behaviour of Slave Axis when it tries to reduce the gap with the Master.

As seen in the following diagrams, bit **Done** goes *TRUE* when **ActPosition** of Slave Axis reaches **ActPosition** of Master Axis. After that, Slave behaviour depends only by the Master.

#### Case 1: Start Master first, then start Slave




**Case 2: Increase the slave velocity** [RatioNumerator = 2]



- █ Movement.KEB\_GearAxisControl\_0.ActVelocity
- █ Movement.KEB\_SingleAxisControl\_0.ActVelocity
- █ Movement.KEB\_GearAxisControl\_0.Start
- █ Movement.KEB\_GearAxisControl\_0.Done

**Case 2: Increase the slave velocity** [RatioDenominator = 2]



- █ Movement.KEB\_GearAxisControl\_0.ActVelocity
- █ Movement.KEB\_SingleAxisControl\_0.ActVelocity
- █ Movement.KEB\_GearAxisControl\_0.Start
- █ Movement.KEB\_GearAxisControl\_0.Done

## Disclaimer

KEB Automation KG reserves the right to change/adapt specifications and technical data without prior notification. The safety and warning reference specified in this manual is not exhaustive. Although the manual and the information contained in it is made with care, KEB does not accept responsibility for misprint or other errors or resulting damages. The marks and product names are trademarks or registered trademarks of the respective title owners.

The information contained in the technical documentation, as well as any user-specific advice in verbal or in written form are made to the best of our knowledge and information about the application. However, they are considered for information only without responsibility. This also applies to any violation of industrial property rights of a third-party.

Inspection of our units in view of their suitability for the intended use must be done generally by the user. Inspections are particular necessary, if changes are executed, which serve for the further development or adaption of our products to the applications (hardware, software or download lists). Inspections must be repeated completely, even if only parts of hardware, software or download lists are modified.

**Application and use of our units in the target products is outside of our control and therefore lies exclusively in the area of responsibility of the user.**

**KEB Automation KG**  
Südstraße 38 • D-32683 Barntrup  
fon: +49 5263 401-0 • fax: +49 5263 401-116  
net: [www.keb.de](http://www.keb.de) • mail: [info@keb.de](mailto:info@keb.de)