

Benutzerhandbuch

COMBIVIS 6

Version 6.8.0

Translation of the original manual
Document 20428970 EN 01

Imprint

KEB Automation KG
Suedstraße 38, D-32683 Barntrup
Germany

Tel: +49 5263 401-0 • Fax: +49 5263 401-116
E-Mail: info@keb.de • URL: <https://www.keb-automation.com>

ma_mu_sw-cv68-20428970_en
Version 01 • Edition 12/05/2025

Table of contents

1 Safety instructions	21
2 Properties.....	22
2.1 Changes in version 6.8.0	22
3 Versions	23
4 System requirements.....	25
4.1 Minimum equipment for smaller projects	25
5 Version information	26
6 Online Tutorials	27
7 Accessories	28
7.1 DIN 66019 - RS-232 cable operator 0058025-001D.....	28
7.2 KEB USB serial converter 0058060-0040.....	28
7.3 HSP5 adapter 00F50C0-0020.....	31
7.4 Port Expander 00F5025-0080.....	32
8 Device connection.....	36
8.1 Connection of COMBIVERT F5	36
8.2 Connection COMBIVERT B6	37
8.3 Connection COMBIVERT G6.....	37
8.4 Connection COMBIVERT H6	37
8.5 Connection COMBIVERT P6	38
8.6 Connection COMBIVERT F6	39
8.6.1 Housing size D - W	39
8.6.2 Housing size 1 - 9	40
8.7 Connection COMBIVERT S6	42
8.8 Connection COMBIVERT T6	42
8.9 Connection of C6 Stepper/BLDC	42
9 Installation	45
9.1 Silent installation	49
9.2 Silent de-installation	50
10 Registration and licence.....	51
10.1 Registration	51
10.2 Licensing	54
11 Programme description	55
11.1 Menu bar	55
11.1.1 Menu - File	56
11.1.2 Menu - Edit	59
11.1.3 Menu - View	60
11.1.4 Menu - Project	61
11.1.5 Menu - Tools	62
11.1.6 Menu - Window	63
11.1.7 Menu - Help	64
11.2 Toolbar	65

11.3	Navigator.....	65
11.3.1	Display of the communication status:	67
11.3.2	Rename elements.....	69
11.3.3	Add configuration.....	71
11.4	Start page.....	84
12	Startup.....	85
12.1	Start with project assistant	86
12.1.1	Start with the project assistant.....	86
12.1.2	Start with an empty project	89
12.1.3	Manual device search.....	89
12.1.4	Start offline (without connected device).....	90
12.2	Direct device search.....	92
12.3	Direct connection to the device (add device)	93
12.3.1	Offline (virtual device):	95
12.4	Open an existing project	96
12.5	Download of a parameter list	97
12.5.1	When connected via UD/IP (Ethernet):.....	98
12.5.2	For serial or USB connection:.....	100
12.6	Saving a project	101
13	Device editor.....	103
13.1	Opening the device editor	103
13.2	Device reference	104
13.3	Switch active device offline	105
13.4	Screen layout	107
13.5	Communication settings.....	108
13.6	Online wizard / commissioning assistant	109
13.7	Device parameter.....	110
13.7.1	Set addressing	112
13.7.2	Direct addressing	114
13.7.3	Indirect addressing	116
13.7.4	Active set	118
13.7.5	Addressing according to CiA 301.	119
13.8	Operator parameters.....	123
13.9	Documents	124
13.10	Switching between editors	124
13.11	Device memory (recipe management).....	126
14	Property editor (input window)	127
14.1	Initial setting	127
14.2	Function selection	128
14.3	Numerical value input.....	129
14.4	Parameter properties / background information	130
14.4.1	Plain text export according to IEC 61131-3	133
15	General settings	134
15.1	Options - Language Settings.....	135
15.2	Configurator	136
15.3	Options - KEB documents.....	137

15.4	Options - Online update	137
15.5	KEB Parameterization - Parameter view.....	138
15.6	KEB Parameterization - Communication.....	139
15.7	KEB Parameterization - Parameter lists.....	140
15.8	KEB Parameterization - Behaviour	141
15.9	Parameterization - Data paths	141
15.10	Options - KEB Scope	142
15.11	Options - Load and Save	142
15.12	Miscellaneous	143
15.13	KEB Wizards	145
16	Screen layout.....	146
17	Start-up Assistant (Wizards)	149
17.1	Online Start-Up Wizard	149
17.1.1	Online Start-Up Wizard COMBIVERT F6/ H6/ S6/ P6/ T6.....	149
17.1.2	Homing Mode	185
17.1.3	Online Start-up Assistant Basis COMBIVERT F5, B6 and G6.	186
17.1.4	Online Start-Up Wizard COMBIVERT F5	186
17.1.5	Online Start-Up Wizard COMBIVERT G6-L (ASCL) and G6-P (SCL).....	192
17.1.6	Start-Up Wizard COMBIVERT T6.....	192
17.2	Offline Start-Up Wizard	192
17.2.1	Open Start-Up Wizard	192
17.2.2	Offline Start-up Wizard for COMBIVERT F5.....	195
17.2.3	Offline Start-Up Wizard for COMBIVERT G6	198
17.2.4	Offline Start-Up wizard COMBIVERT F6/ H6/ S6/ P6/ T6.	204
17.2.5	Offline Start-Up wizard overview	205
18	Parameter lists.....	206
18.1	Properties.....	206
18.2	Open a blank list	206
18.3	Open list with marked parameters	210
18.4	Open existing list.....	211
18.5	Create complete list	215
18.6	Layout of parameter list.....	216
18.6.1	Display of columns in the parameter list:	216
18.6.2	Display grid lines:.....	217
18.7	Self-created parameter list.....	218
18.8	Insert an empty line.....	220
18.9	Transfer pause during download.....	220
18.9.1	Transfer pause during download to device:	221
18.9.2	User input (confirmation):	221
18.10	Changing of device reference	222
18.11	Upload from device into parameter list.....	222
18.12	Parameter Download	223
18.12.1	Parameter download from a parameter list to several devices:	224
18.13	Renaming parameter list.....	225
18.14	Comparing parameter lists directly.....	226
18.15	Comparing parameter lists	227
18.15.1	Online comparison	227

18.15.2 Offline comparison	228
18.15.3 Comparison method	228
18.16 Convert addressing of parameter lists	230
18.17 Parameter backup	231
18.17.1 Sort mode	233
18.18 CP Parameters	234
18.19 Export parameter list	236
19 Scope.....	238
19.1 Properties	238
19.2 Add scope to the project	238
19.2.1 Add a New Scope	238
19.2.2 Open an external Scope	242
19.2.3 Create scope with same settings	247
19.2.4 Moving scope in the project	248
19.3 Scope Basic Settings	250
19.4 Channel allocation / New Channel	253
19.5 Setting occupied channel	254
19.6 Fast scope mode	256
19.7 Recording	257
19.8 Display window	258
19.9 Adapt Display	259
19.9.1 Distribution / stretching of all curves over the display area:	261
19.10 Display – Zoom	261
19.10.1 Zoom to display 0-100% (or rather -100- +100%):	261
19.10.2 Scaling / fixing of Y-axis:	263
19.11 Display – Cursors	264
19.12 Save recordings	269
19.13 Import / Export	270
19.14 Export to CSV format	270
19.15 Trigger function (online)	271
19.15.1 Trigger function in online mode	271
19.16 Offline mode	273
19.16.1 Switch on and adjustment of time basis	274
19.16.2 Adjusting of trigger source	275
19.16.3 Adjusting of trigger position	276
19.16.4 Application	277
19.16.5 Storage Capacity	278
20 Search function	279
20.1 General text search	279
20.2 Parameter search	279
20.2.1 Search methods:	281
21 Document database	283
21.1 Add/remove documents	283
21.2 Use document database	286
21.3 KEB PDF viewer	290
22 Update	293

22.1	Manual check for new version.....	293
22.2	Automatic check for newer version	293
22.3	Manual update of the parameter description file	294
23	Device storage	295
23.1	Device storage wizard.....	295
23.1.1	Access level / password	296
23.1.2	Connection setup.....	298
23.1.3	Show stored recipes	298
23.1.4	Create a recipe	299
23.1.5	File system / transfer file	302
23.1.6	Edit recipe in the file system	303
23.1.7	Disconnect connection.....	303
23.2	KEB FTP File Transfer Program	304
23.2.1	Operator 00F6P00-4001	306
23.2.2	Operator 00F6P00-2000	310
23.2.3	Operator 00F6P00-3000.....	313
24	IP Scan Tool	316
24.1	Description	316
24.2	Supported devices	316
24.3	Ports.....	316
24.4	Scan	316
24.5	Wink	316
24.6	Assign IP Address.....	316
24.7	Additional information.....	316
24.8	Use IP Scan	316
25	Energy Efficiency Tool.....	318
25.1	Function	318
25.2	Loss-time profile.....	323
25.3	Generate declaration / data sheet.....	324
26	Parameter cockpit	327
27	Additional modules / plug-ins	332
28	Help areas	333
28.1	Help for specific functions	333
28.2	Help for program functions.....	333
28.3	Help for specific device functions (FAQ)	334
28.4	Help for parameter functions	335
28.5	COMBIVIS error messages.....	336
28.5.1	Other error messages:.....	338
28.6	TeamViewer	339
29	Frequently asked questions (FAQ) about COMBIVIS 6	344
29.1	FAQ COMBIVIS 6 parameterisation environment.....	344
29.1.1	Can COMBIVIS 5 and COMBIVIS 6 be used simultaneously?	344
29.1.2	Is it possible to use COMBIVIS 6 twice at the same time?	344
29.1.3	Is it possible to use parameter lists (.dw5), work lists (.wr5) and scope files (.sc5) of COMBIVIS 5 at COMBIVIS 6?	344
29.1.4	Is it possible to parameterize older KEB drive controllers (e.g., F4) with CV6?	344

29.1.5	After inserting a parameter list into the project, there is shown: "channel closed" in the online values.....	344
29.1.6	Is it possible to open several projects with CV6 at the same time?.....	344
29.1.7	Why will be found the same device several times by using the USB-Serial-Converter Part No. 0058060-0020 / -0040?	344
29.1.8	By using USB serial converter at a HSP5 interface of F5/B6, the drive controller will be not or only by searching several times found.	344
29.1.9	When changing a parameter value, the property editor window is not shown. Or: Parameter values cannot be entered/changed.	345
29.1.10	The copy function Fr01 at COMBIVERT F5/B6/G6 seems not to work.....	345
29.1.11	When creating a new project, the location is displayed as C:\user\... However, there is no file with this name in the Windows 7 workstation.....	346
29.1.12	In editor is shown "service not available" at every parameter value“.....	346
29.2	FAQ Scope.....	346
29.2.1	Is it possible to record more than 16 channels?	346
29.2.2	Is it possible to save a COMBIVIS 6-scope recording in COMBIVIS 5 (sc5) format?	346
29.2.3	Is it possible to merge channels from different scope recordings?	347
29.2.4	The externally stored Scope file ending sc6 cannot be opened.	347
29.3	Known problems	347
29.3.1	Scope - horizontal cursors	347
29.3.2	Windows - Decimal point	348
29.3.3	Error message on startup	349
	Glossary	351
	Index	352

List of figures

Fig. 1	Icon 6_8	23
Fig. 2	Icons_Start bar.....	23
Fig. 3	Version info	26
Fig. 4	Cable RS232 PC-inverter.....	28
Fig. 5	Wiring diagram	28
Fig. 6	KEB USB serial converter 0058060-0040	28
Fig. 7	Execution File Transport Program FTP.....	29
Fig. 8	Execution Setup COMBIVIS 6 Select Additional Tasks	29
Fig. 9	Connection F5 and B6 on HSP5	30
Fig. 10	Automatically detect node address	31
Fig. 11	Adapter D-SUB9 / RJ45_00F50C0-0020	32
Fig. 12	Port Expander Bundle 00F5025-0080.....	34
Fig. 13	Circuit example COMBIVERT G6/F5	34
Fig. 14	Connection of COMBIVERT F5 terminal X4A.....	36
Fig. 15	Connection_F5_2.....	36
Fig. 16	Connection_B6.....	37
Fig. 17	Connection_G6	37
Fig. 18	Connection_H6	38
Fig. 19	Connection_P6.....	38
Fig. 20	Connection F6 Housing D to W.....	39
Fig. 21	Connection F6 Housing 1 to 9.....	40
Fig. 22	Operator with LAN interface	40
Fig. 23	Operator with USB interface	41
Fig. 24	Operator with USB and LAN interface	41
Fig. 25	Connection_S6.....	42
Fig. 26	Connection_T6.....	42
Fig. 27	Connection Stepper BLDC	43
Fig. 28	Connection Stepper BLDC documents	44
Fig. 29	Select components.....	45
Fig. 30	Installation Setup.....	46
Fig. 31	Icons Desktop	47
Fig. 32	Last_used_projects	47
Fig. 33	Installed versions	47
Fig. 34	Installation version manager	48
Fig. 35	Version manager test version	49
Fig. 36	Silent Installation Select Components.....	50
Fig. 37	Carry out registration.....	51
Fig. 38	Registration KEB Homepage	51
Fig. 39	Registration Not registered, yet.....	52
Fig. 40	COMBIVIS Registration	52
Fig. 41	Registration Show registration key.....	53

Fig. 42	Registration key	53
Fig. 43	Registration COMBIVIS 6	53
Fig. 44	Registration Show release notes	54
Fig. 45	Start screen.....	55
Fig. 46	Menu bar	55
Fig. 47	Menu bar - File	56
Fig. 48	File - New project	57
Fig. 49	Menu - Edit.....	59
Fig. 50	Menu - View	60
Fig. 51	Menu bar - Project.....	61
Fig. 52	Menu - Help.....	64
Fig. 53	Toolbar.....	65
Fig. 54	Toolbar - Tool text icon	65
Fig. 55	Navigator.....	65
Fig. 56	Navigator - Predefined Folders	66
Fig. 57	Add_object	67
Fig. 58	Device_active_inactive.....	68
Fig. 59	Device_active_no_connection	69
Fig. 60	Navigator_communication_status_online_offline.....	69
Fig. 61	Change element name.....	70
Fig. 62	Properties menu item	70
Fig. 63	Rename elements.....	71
Fig. 64	Add configuration	72
Fig. 65	Work with Configurator.....	72
Fig. 66	Work with Configurator.....	73
Fig. 67	Configurator connections	74
Fig. 68	Configurator Document access.....	75
Fig. 69	Configurator product selection window	76
Fig. 70	Configurator product selection	77
Fig. 71	Configurator properties window	77
Fig. 72	Configurator properties window input.....	78
Fig. 73	Configurator Create COMBIVIS project	78
Fig. 74	Configuration Icon export configuration	78
Fig. 75	Configurator generate project	79
Fig. 76	Configurator Generate Project Preview	79
Fig. 77	Configuration open created objects in COMBIVIS	80
Fig. 78	Configurator Show items in configuration	81
Fig. 79	Configurator Highlighted elements	82
Fig. 80	Export configuration	82
Fig. 81	Configurator Export Icon configuration.....	82
Fig. 82	Configuration Export	83
Fig. 83	Start page.....	84
Fig. 84	Show start page	85

Fig. 85	Start page Mouse pointer	86
Fig. 86	Used projects list.....	86
Fig. 87	New_Project.....	87
Fig. 88	Project name	87
Fig. 89	Device search	88
Fig. 90	Working with an empty project.....	89
Fig. 91	Manual device search	89
Fig. 92	Icon manual device search	90
Fig. 93	Device_search_UDP_IP	90
Fig. 94	Add Icon parameterisable KEB device.....	91
Fig. 95	Add_device	91
Fig. 96	New parameterisable device.....	92
Fig. 97	Icon direct device search	92
Fig. 98	Device search_Ethernet.....	93
Fig. 99	Icon direct connection to the device.....	94
Fig. 100	Add_all_devices	94
Fig. 101	USB_connections.....	95
Fig. 102	Add_device_1	96
Fig. 103	New_Project.....	96
Fig. 104	Start Up last used projects	97
Fig. 105	Download_Parameter list.....	98
Fig. 106	select the file download of a parameter list.....	98
Fig. 107	Add_all_devices	99
Fig. 108	USB_connections.....	100
Fig. 109	Confirm_parameter_list_download	100
Fig. 110	Download_completed.....	101
Fig. 111	Save_project	101
Fig. 112	Compatible_older_version	102
Fig. 113	Open_Device_Editor	103
Fig. 114	Opening_the_device	104
Fig. 115	List device reference KEB devices	105
Fig. 116	Device reference configurable KEB devices	105
Fig. 117	Switch_devices_online_offline	106
Fig. 118	Devices_online_offline_alternative.....	107
Fig. 119	Screen layout	107
Fig. 120	Communication settings	108
Fig. 121	Expert settings	109
Fig. 122	Online_wizard	109
Fig. 123	Devices_Parameter_1.....	110
Fig. 124	Devices_Parameter_2.....	110
Fig. 125	Devices_Parameter_3.....	111
Fig. 126	Devices_Parameter_4.....	111
Fig. 127	Devices_Parameter_5.....	112

Fig. 128 Set-addressing_1	113
Fig. 129 Set-addressing_2	113
Fig. 130 Device_2	114
Fig. 131 Set-addressing_3	114
Fig. 132 Direct_addressing_1	115
Fig. 133 Direct_addressing_2	115
Fig. 134 Direct_addressing_3	116
Fig. 135 Direct_addressing_4	116
Fig. 136 Indirect_addressing_1	117
Fig. 137 Indirect addressing parameter set pointer.....	117
Fig. 138 Indirect addressing Fr09	118
Fig. 139 Active set parameters	119
Fig. 140 Active set setpoint source	119
Fig. 141 Addressing according to CiA 301 variables	120
Fig. 142 Addressing according to CiA 301 ru82.....	120
Fig. 143 Addressing according to CiA 301 ru83.....	121
Fig. 144 Addressing according to CiA 301 fb110.....	121
Fig. 145 Addressing COMBIVERT G6 according to CiA 301 CANopen	122
Fig. 146 Addressing according to CiA 301 parameters.....	123
Fig. 147 Addressing according to CiA 301 subindex	123
Fig. 148 Operator parameters tab.....	124
Fig. 149 Documents tab	124
Fig. 150 Change_between_editors_1	125
Fig. 151 Change_between_editors_2	125
Fig. 152 Device memory (recipe management).....	126
Fig. 153 Property editor (input window)	127
Fig. 154 Basic setting Tools options	127
Fig. 155 Basic setting Behaviour.....	128
Fig. 156 Function selection	129
Fig. 157 Numerical value input.....	130
Fig. 158 Parameter properties_1	131
Fig. 159 Parameter properties_2	132
Fig. 160 Generate plain text export according to IEC 61131-3 code	133
Fig. 161 Plain text export according to IEC 61131-3 code text	133
Fig. 162 Tools options.....	134
Fig. 163 Tools Import and Export Options	134
Fig. 164 Import and Export Options	135
Fig. 165 International Settings	136
Fig. 166 Configurator_1	136
Fig. 167 Configurator_2	137
Fig. 168 KEB dokument	137
Fig. 169 Options_Online_Update_1.....	138
Fig. 170 Options_Online_Update_2.....	138

Fig. 171 Parameter view	139
Fig. 172 Options - KEB Parameterisation - Communication	140
Fig. 173 KEB Parameterization - Parameter lists.....	140
Fig. 174 Behaviour	141
Fig. 175 File paths.....	142
Fig. 176 Scope	142
Fig. 177 Load_Save	143
Fig. 178 Miscellaneous_1	144
Fig. 179 Miscellaneous_2	144
Fig. 180 Options - KEB Wizards	145
Fig. 181 Reset window layout to default	146
Fig. 182 Screen layout new vertical tab group	146
Fig. 183 Orientation cross_1	147
Fig. 184 Orientation cross_2	147
Fig. 185 Orientation cross_3	148
Fig. 186 Start-Up Wizard online	149
Fig. 187 Start-up Assistant (Wizards) Basic settings	150
Fig. 188 Wizard - Motor - Motor data	152
Fig. 189 Wizard - Motor - Generator mode	153
Fig. 190 Wizard - Motor - Brake control	153
Fig. 191 Wizard - Motor - Sine filter - Preview	154
Fig. 192 Wizard - Motor - Sine filter	154
Fig. 193 Wizard - Motor - Expert settings.....	155
Fig. 194 Start-up Assistant (Wizards) Feedback mode.....	156
Fig. 195 Start-up Assistant (Wizards) Controller.....	157
Fig. 196 Wizard - Protection / Warnings - Statusword settings.....	157
Fig. 197 Start-up Assistant (Wizards) Protection / Warnings	158
Fig. 198 Warning Overload OL warning level	158
Fig. 199 Warning - Overload OL stop mode	158
Fig. 200 Warning - Overload counter	159
Fig. 201 Wizard - Protection / Warnings - Application specific warning settings.....	159
Fig. 202 Wizard - Protection / Warnings - Fault reaction ramp mode settings.....	159
Fig. 203 Wizard - Protection / Warnings - Fault reaction ramp value settings	160
Fig. 204 Wizard - Protection / Warnings - Expert settings	160
Fig. 205 Start-up Assistant (Wizards) Identification	161
Fig. 206 Start-up Assistant (Wizards) Operating mode1.....	162
Fig. 207 Start-up Assistant (Wizards) Operating mode2.....	163
Fig. 208 Start-up Assistant (Wizards) Fieldbus	164
Fig. 209 Wizard - Fieldbus - Select fieldbus type	164
Fig. 210 Wizard - Fieldbus - CAN Cross	165
Fig. 211 Wizard - Fieldbus - EtherCAT CAN Cross	165
Fig. 212 Wizard - Fieldbus - CAN Cross expert setting	166
Fig. 213 Start-up Assistant (Wizards) process data size	166

Fig. 214 Start-up Assistant (Wizards)	166
Fig. 215 Start-up Assistant Wizard_load	167
Fig. 216 Start-up Assistant (Wizards) Stored_Mappings	167
Fig. 217 Wizard - Fieldbus - Process data mapping	168
Fig. 218 Start-up Assistant (Wizards) Export device description	168
Fig. 219 Start-up Assistant (Wizards) Install to device-repository	169
Fig. 220 Start-up Assistant (Wizards) Save as EtherCAT-XML-File	169
Fig. 221 Start-up Assistant (Wizards) Safety Module 1	170
Fig. 222 Start-up Assistant (Wizards) Safety Module 2	170
Fig. 223 Start-up Assistant (Wizards) Software	171
Fig. 224 Start-up Assistant (Wizards) CAN EDS	171
Fig. 225 Start-up Assistant (Wizards) ESD	172
Fig. 226 Wizard - Fieldbus - Create Powerlink xdd	172
Fig. 227 Wizard - Fieldbus - CAN Cross	173
Fig. 228 Start-up wizard Test run starts	174
Fig. 229 Add test run in the Navigator	175
Fig. 230 Wizard - Start test run	176
Fig. 231 Wizard - Test run - Open status display	177
Fig. 232 Start-up wizard Velocity mode	178
Fig. 233 Wizard - Test run - Velocity mode	179
Fig. 234 Wizard - Test run - Profile positioning mode	180
Fig. 235 Start-up wizard Cogging	181
Fig. 236 Start-up wizard Measuring condition	183
Fig. 237 Start-up wizard Activate selection	184
Fig. 238 Start-up wizard Graphs and Data	184
Fig. 239 Start-up wizard Expert settings	185
Fig. 240 Start-up wizard Homing m	185
Fig. 241 Online Start-Up Wizard	186
Fig. 242 Start-Up Assistant F5 B6 G6	187
Fig. 243 Start-Up Assistant F5	187
Fig. 244 Start-Up Wizard Online Wizards Motor ident	188
Fig. 245 Start-Up Assistant SCL_1	189
Fig. 246 Start-Up Assistant SCL_2	189
Fig. 247 Start-Up Wizard SCL_3	190
Fig. 248 Start-Up Wizard F5 PROFIBUS 1	191
Fig. 249 Start-Up Wizard F5 PROFIBUS 2	191
Fig. 250 Start-Up Wizard Offline Start-up	192
Fig. 251 Start-up Assistant Offline Start-up object	193
Fig. 252 Start-up Assistant Offline Start-Up Icon	194
Fig. 253 Start-up Assistant Offline Start-Up	194
Fig. 254 Start-Up Wizard Offline Start-Up F5	195
Fig. 255 Start-Up Wizard Offline Start-Up F5 Motor	196
Fig. 256 Define_synchronous motor	197

Fig. 257 Start-Up Assistant process data assignment F5 PROFINET Operator.....	198
Fig. 258 Start-Up Assistant expert mode	198
Fig. 259 Start-Up Assistant process data assignment CAN version	199
Fig. 260 Start-Up Assistant process data assignment CAN version database	200
Fig. 261 Start-Up Assistant process data assignment CAN version PDO 1	201
Fig. 262 Start-Up Assistant process data assignment CAN version PDO 2	202
Fig. 263 Start-Up Assistant process data assignment EtherCAT version.....	203
Fig. 264 Start-Up Wizard EtherCAT Export	203
Fig. 265 Start-Up Wizard EtherCAT Export files	204
Fig. 266 Start-Up Assistant EtherCAT PdIn Details	204
Fig. 267 Start-Up wizard overview	205
Fig. 268 Open a_blank list	206
Fig. 269 Add parameter list	207
Fig. 270 Give list_a name	208
Fig. 271 Add parameter list_object	209
Fig. 272 Give list_a name	210
Fig. 273 Create parameter list from selection	211
Fig. 274 Open Icon existing list	211
Fig. 275 Add parameter list	212
Fig. 276 Import_file	213
Fig. 277 Select_file.....	213
Fig. 278 Parameter list_device.....	214
Fig. 279 Open Icon existing list	214
Fig. 280 Open parameter list.....	215
Fig. 281 Create complete list	215
Fig. 282 Parameter list_Editor.....	216
Fig. 283 Layout_parameter list.....	216
Fig. 284 Parameter lists_columns.....	217
Fig. 285 Display grid lines	218
Fig. 286 Self-created parameter list 1	218
Fig. 287 Self-created parameter list 2	219
Fig. 288 Parameter list alternative	220
Fig. 289 Parameter list Insert empty line.....	220
Fig. 290 Insert parameter list pause.....	221
Fig. 291 Parameter list waiting time	221
Fig. 292 Parameter list waiting time (confirmation).....	222
Fig. 293 Parameter lists changing of device reference	222
Fig. 294 Parameter lists Upload of the list	223
Fig. 295 Parameter lists Download of the lists	224
Fig. 296 Parameter lists Download parameter list	224
Fig. 297 Parameter lists Exclude Download	225
Fig. 298 Renaming parameter list.....	225
Fig. 299 Parameter lists Extended Quick-compare.....	226

Fig. 300 Parameter lists Quick-compare CP Parameters	227
Fig. 301 Comparing parameter lists	227
Fig. 302 Parameter list online comparison	228
Fig. 303 Parameter list comparison	228
Fig. 304 Parameter list comparison method	229
Fig. 305 Parameter list comparison method properties	230
Fig. 306 Parameter list conversion	230
Fig. 307 Parameter list conversion	231
Fig. 308 Parameter lists Tools Parameter backup	232
Fig. 309 Parameter backup - Lists	232
Fig. 310 Parameter lists Upload starts	233
Fig. 311 Parameter lists Create_CP parameter list	235
Fig. 312 Parameter lists CP parameters inverter state	235
Fig. 313 Save Parameter lists Export	236
Fig. 314 Save Parameter lists Export variants	237
Fig. 315 Save parameter lists Export EtherCAT	237
Fig. 316 Add a new scope	238
Fig. 317 Add Scope	239
Fig. 318 Scope Name	240
Fig. 319 Open Scope alternatively	241
Fig. 320 Scope Add Object	242
Fig. 321 Scope COMBIVIS Scope	242
Fig. 322 Add a new scope	242
Fig. 323 Open Scope	243
Fig. 324 Scope Import from file	244
Fig. 325 Scope clipboard	244
Fig. 326 Assign Scope and Add	245
Fig. 327 Scope device selection	246
Fig. 328 Scope output file	247
Fig. 329 Open scope file	247
Fig. 330 Copy scope	248
Fig. 331 Paste scope	248
Fig. 332 Move scope file	249
Fig. 333 Scope_assignment	250
Fig. 334 Scope Tools Options	251
Fig. 335 KEB Scope Display Channels Advanced	251
Fig. 336 Scope Settings	252
Fig. 337 Scope New Channel	253
Fig. 338 Scope device parameters	254
Fig. 339 Scope Setting occupied channel	255
Fig. 340 Scope Channel switched off	255
Fig. 341 Scope display	256
Fig. 342 Scope communication settings	257

Fig. 343 Recording scope	258
Fig. 344 Stop scope	258
Fig. 345 Scope Display window	259
Fig. 346 Scope Display Operation	259
Fig. 347 Scope measurement curve values.....	260
Fig. 348 Scope Measurement curve Alignment	260
Fig. 349 Scope Measurement curve Auto scaling.....	261
Fig. 350 Scope Zoom Level	262
Fig. 351 Scope Zoom.....	262
Fig. 352 Scope measurement curve Keys	263
Fig. 353 Scope Measured curve Fix scaling	264
Fig. 354 Scope Cursors	265
Fig. 355 Scope cursor table	266
Fig. 356 Scope Measurement curve vertical horizontal	267
Fig. 357 Scope Measurement curve Difference values	267
Fig. 358 Scope Measurement curve Integral values.....	267
Fig. 359 Scope Measurement curve RMS values.....	268
Fig. 360 Scope Measurement curve Centre cursors.....	268
Fig. 361 Scope Measurement curve Parameter name	269
Fig. 362 Save scope recording	269
Fig. 363 Scope recording	270
Fig. 364 Export scope files.....	271
Fig. 365 Scope Export to CSV format.....	271
Fig. 366 Scope trigger function	272
Fig. 367 Scope trigger function Exmple	273
Fig. 368 Set scope time base.....	274
Fig. 369 Scope time base switching frequency.....	275
Fig. 370 Scope Setting the trigger source.....	275
Fig. 371 Scope KEB Documents.....	276
Fig. 372 Scope FAQ.....	276
Fig. 373 Scope Setting the trigger source	277
Fig. 374 Scope Trigger function Example1	278
Fig. 375 Search function binoculars.....	279
Fig. 376 Search function Parameter search dialogue	279
Fig. 377 Search function Parameter list	280
Fig. 378 Parameter search - search field	280
Fig. 379 Search function parameter search continue search.....	281
Fig. 380 Search function Search methods	282
Fig. 381 Document database Manage Documents	283
Fig. 382 Documents database Add documents	284
Fig. 383 Document database overview of available installed packages	285
Fig. 384 Documents database Documents installed	286
Fig. 385 Documents database Documents	286

Fig. 386 Documents database Show documents.....	287
Fig. 387 Document database Search mask	287
Fig. 388 Document database Selection	288
Fig. 389 Document database Installation S6 housing 2.....	289
Fig. 390 Document database Filter	289
Fig. 391 Document database Apply Configuration.....	290
Fig. 392 Document database PDF viewer	290
Fig. 393 Document database Adjust toolbar	291
Fig. 394 Document database Options.....	291
Fig. 395 Document database PDF settings	292
Fig. 396 Update Help Check for updates	293
Fig. 397 Update All components are up to date.....	293
Fig. 398 Updating tools	294
Fig. 399 Drive storage.....	295
Fig. 400 Device storage connections	296
Fig. 401 Device storage application	297
Fig. 402 Device storage Password	297
Fig. 403 Device storage current access level	297
Fig. 404 Device storage connection_setup	298
Fig. 405 Disconnect device storage	298
Fig. 406 Device storage Recipe management	299
Fig. 407 Drive storage download as a recipe.....	300
Fig. 408 Enter drive storage password	301
Fig. 409 Drive storage Next free ID.....	301
Fig. 410 Drive storage Parameter list_test.....	302
Fig. 411 Transfer device storage parameter list.....	302
Fig. 412 Execute device storage parameter list	303
Fig. 413 Rename device storage recipe	303
Fig. 414 Disconnect device storage	304
Fig. 415 Device storage Tools KEB FTP	305
Fig. 416 Device storage Data transfer_PC_device	306
Fig. 417 FTP LAN 1	307
Fig. 418 FTP LAN 2	308
Fig. 419 FTP LAN 3	308
Fig. 420 FTP USB 1	309
Fig. 421 FTP USB 2	310
Fig. 422 FTP - Port 8002.....	311
Fig. 423 FTP - Connect.....	312
Fig. 424 FTP Startup.....	313
Fig. 425 FTP - Connect.....	314
Fig. 426 FTP file transfer.....	314
Fig. 427 IPScan Tool.....	317
Fig. 428 Registration Use IPScan	317

Fig. 429 Energy Efficiency Tool Generate Energy Efficiency Declaration	318
Fig. 430 Add energy efficiency tool object	319
Fig. 431 Energy efficiency editor name	320
Fig. 432 Energy efficiency declaration 1	321
Fig. 433 Energy Efficiency Declaration selection	321
Fig. 434 Energy Efficiency Tool Normative Operating Points	322
Fig. 435 Energy Efficiency Tool Custom load points	322
Fig. 436 Energy Efficiency Tool Loss-Time-Profile Options	323
Fig. 437 Energy Efficiency Tool Loss-Time-Profile required	324
Fig. 438 Energy Efficiency Tool Data Sheet 1	325
Fig. 439 Energy Efficiency Tool Data Sheet 2	326
Fig. 440 Parameter cockpit	327
Fig. 441 Add parameter cockpit object	328
Fig. 442 Assign parameter cockpit name	329
Fig. 443 Parameter Cockpit Display fields	330
Fig. 444 Parameter Cockpit Drag and Drop	330
Fig. 445 Parameter Cockpit Testrun	331
Fig. 446 Help area parameterisation	333
Fig. 447 Help areas device editor	333
Fig. 448 Help areas display modes	334
Fig. 449 Help areas online help programming system	334
Fig. 450 Help areas device editor	335
Fig. 451 Help areas FAQ	335
Fig. 452 Help areas parameter function	336
Fig. 453 Help areas parameter function	336
Fig. 454 Help areas error messages	338
Fig. 455 Help areas view hidden files	339
Fig. 456 Help - Call up the service and support page	340
Fig. 457 Help areas Disclaimer	341
Fig. 458 Help areas allow remote control	342
Fig. 459 Help Areas Confirm Access	342
Fig. 460 Help areas TeamViewer	343
Fig. 461 FAQ Property Editor	345
Fig. 462 FAQ Copy function	346
Fig. 463 Scope Settings	348
Fig. 464 Motor identification	349
Fig. 465 Error message on startup	350

List of tables

1 Safety instructions

The purchased software has been programmed according to the state of the art and recognised rules. Nevertheless, damage such as loss of data or malfunction of connected devices may occur during use. Further information can be found in the EULA.

If parameterisations are carried out by means of the software, the user assumes liability for the controlled components. Incorrect parameterisation can impair the function of the drive controller or the machine or put it out of operation completely.

⚠ CAUTION



Inputs have immediate effects on the connected unit!

- a) Test inputs without motor.
- b) Check the result of batch files.
- c) Do not connect the motor until all tests have been successful.

Failure to comply with the safety instructions will result in the loss of all claims against the manufacturer caused thereby.

2 Properties

- Based on the CODESYS platform and the .NET framework
- Program error and message history
- Commissioning Wizards
- Integrated KEB document database
- Integrated device configurator
- Integrated determination of the energy efficiency of KEB COMBIVERT
- Integrated Safety Editor for safe communication with the KEB safety modules
- 16-channel oscilloscope
- Communication via UDP/IP or DIN 66019II (serial or USB) Protocol
- IP addressing of several devices
- Automatic recognition of USB converters
- Parallel search on multiple serial ports and UDP/IP
- HSP5 protocol indirectly via KEB USB serial converter or KEB port expander
- Update function via internet
- It can be installed and operated in parallel with COMBIVIS 5 but no simultaneous access to the same COM port
- Support for COMBIVERT type F5/ B6/ G6/ F6/ H6/ F6/ P6/ S6/ T6, COMBICONTROL C6 and Stepper/BLDC
- Older devices such as COMBIVERT 51 to 58 / F0 to F4 are not supported!
- No display of operator parameter menu with Devicenet and early Interbus and CAN operators type F5 (separate operator menu at CV 5)
- Several versions can be installed in parallel.

Detailed information can be found in the "Release Info" under menu "Help" → "Show Release Notes".

2.1 Changes in version 6.8.0

- (⇒ [Communication settings \[▶ 108\]](#)) - Semi-automatic baud rate setting and reset to default value.
- (⇒ [Renaming elements \[▶ 69\]](#)).
- Download extension packages
- CAN Cross functionality
- Warning message for test run can be set
- Test run wizard is opened in a separate window and placed in the Wizards folder.
- Tooltips extended
- Extension of Motorwizard with Z2 sine filter
- Moving scopes in the Navigator possible
- Timeout values of the communication settings changed
- Silent installation/uninstallation inserted

3 Versions

The free COMBIVIS installation file consists of 2 modules:

Selecting the programme module opens the respective module version.




Fig. 1: Icon 6_8

Parameterisation version "COMBIVIS 6" (dealt with here)

- Parameterisation and analysis of KEB COMBIVERT
- Energy efficiency calculation
- Document database (subject to registration)
- Without term limit

and the

Programming version "COMBIVIS studio 6"

additionally:

- PLC programming according to IEC 61131-3 (C6 controllers)
- Bus configuration (e.g.: EtherCAT, CAN, Profinet)
- Configuration of remote I/Os
- Other additional components
- Licensing with costs required
- In the free demo version time-limited (1h) and no boot projects.

Both modules can be started via the desktop icons or the start menu.




Fig. 2: Icons_Start bar

Optional:

Visualisation platform "COMBIVIS studio HMI"

- Editor with full SCADA functionality
- Extensive graphics library and toolbox with ready-made controls
- Easy data exchange with COMBIVIS studio 6 projects
- Licensing with costs required
- Free demo version, time-limited

Remote maintenance with "COMBIVIS connect"

- Monitoring, project update and maintenance via "end-to-end" VPN
- Enables direct, worldwide support of KEB devices
- Control Center free of charge
- Requires one-time licensing of a company domain

For further information on modules not covered here, please contact KEB.

4 System requirements



COMBIVIS 6 and COMBIVIS studio 6 are intended for use on Windows desktop systems. Other systems such as Windows Embedded, Windows IoT or Windows Server are not supported.

The **COMBIVIS studio 6 Safety Editor** is no longer included in COMBIVIS studio 6.8.0.

4.1 Minimum equipment for smaller projects

- Microsoft Windows 11 or Windows 10, 32-bit or 64-bit version
- 2 GHz processor
- 4 GB RAM (8 GB recommended)
- 10 GB free hard disk space
- Screen resolution min. 1024 x 768
- Display 100% or 125% (150% with restrictions)
- Microsoft .NET Framework Version 4.8

5 Version information

The version info is displayed under menu bar "Help" → "Information"



Fig. 3: Version info

1 Version of COMBIVIS 6

2 Version of the underlying CODESYS
software

6 Online Tutorials

KEB offers information and tutorials on the KEB YOUTUBE channel.

Information, applications, technology:



Here you can find more online tutorials from KEB.
(🌐► <https://www.youtube.com/channel/UCf577xwEciszTqrSAUCVXw>)



Tutorials:





Here you can find more online tutorials from KEB.
(🌐► https://www.youtube.com/playlist?list=PLWebeb-k4oOI_UOXashjFA58aE1bHTOM-)



7 Accessories

7.1 DIN 66019 - RS-232 cable operator 0058025-001D



7.2 KEB USB serial converter 0058060-0040

Converts USB to serial DIN66019 II and HSP5 D-SUB 9-pin



Fig. 6: KEB USB serial converter 0058060-0040

- The KEB-USB serial converter represents a virtual COM interface.
- It is not a commercially available USB-serial converter, as the serial protocol is not fully translated!
- DIN66019 II is always used on the USB side.
- Several USB-serial converters with one KEB device each can be operated simultaneously.
- Internal potential separation.
- Does not require an external power supply.
- The 9-pin serial side supports automatic detection:
- DIN66019 II based on RS 232.
- HSP5 (TTL level).

- 38.4 kBaud should be used as the baud rate.
- Max. baud rate is 115.2 kBaud.
- No automatic baud rate adjustment is supported.
- The baud rate can be set via COMBIVIS 6.

File Transport Programme FTP / Device Memory

As of version V2.4, the copying of recipes per (⇒ [FTP program \[► 304\]](#)) or Wizard to the COMBIVERT F6/S6 is supported.

The KEB-USB converter is then labelled "FTP ready".




Fig. 7: Execution File Transport Program FTP

Driver installation

The driver is installed during the installation of COMBIVIS 6. If not desired, this can be prevented during setup by unchecking the box:




Fig. 8: Execution Setup COMBIVIS 6 Select Additional Tasks

The signed USB driver "kebcdc.inf" is located in the COMBIVIS 6 installation directory "C:\Programmes(x86)\KEB\COMBIVIS_6\Drivers".

With some versions of Windows, a driver from STMicroelectronic is installed automatically. This can also be used. However, the KEB USB converter is then not named as a KEB device in the control panel. The KEB driver would then have to be installed manually via the Windows device manager "Update driver".

The KEB-USB serial converter Art. No. 0058060-0020, which is no longer manufactured, has the same properties, but no electrical isolation. Due to data transport problems, this should not be used on COMBIVERT F6/S6.

Please note for COMBIVERT F5 and B6 on HSP5 interface:

Since node addresses are not specified for HSP5 connection of the USB-serial converter, COMBIVIS 6 finds a device on every device address searched!

e.g. when searching on addr. 0 and 1, the same unit is found and inserted twice, regardless of which actual unit address is set.

Therefore, when connecting via HSP5 interface, search only on one address!




Fig. 9: Connection F5 and B6 on HSP5

Under "Connect to device", uncheck "Automatically detect nodes", otherwise the device will be included in the project up to 240 times! Typically, node address 1 is used.




Fig. 10: Automatically detect node address

7.3 HSP5 adapter 00F50C0-0020

Connection to COMBIVERT B6 and F5 bus operators (HSP5 protocol) only with KEB USB serial converter or port expander.



Fig. 11: Adapter D-SUB9 / RJ45_00F50C0-0020

7.4 Port Expander 00F5025-0080

Ethernet / USB - HSP5 converter

Part no. 00F5025-0080

The Port Expander is a communication gateway with Ethernet and USB interface and 4 HSP5/485 interfaces for connection to drive controllers or operators KEB COMBIVERT.

With the Port Expander, up to 4 units with HSP5 interface can be addressed with COMBIVIS 6, as the Port Expander can convert the HSP5 protocol into DIN66019. Operation with COMBIVIS 5 is also possible.

Connection options in detail:

Input side:

USB on the USB-B interface

Ethernet:

- ARP Address Resolution Protocol Response
- ICMP Echo Response (Ping)
- TCP/IP DIN66019II, Modbus/TCP, Http
- TCP/UDP DIN66019II, Modbus/TCP
- DHCP BootP Response, can be switched off

Output side:

One HSP5 device (F5 control card (X4A) direct / F5 bus operator / B6) at each of the 4 output interfaces.

At port 4 (X4D), an RS485 bus with DIN66019II can alternatively be set, thus theoretically up to 235 participants with a serial DIN 66019II interface (F5 interface operator / G6 / H6 / P6 / F6 / S6).

The **power supply** is provided by an external 24V power supply unit or via the USB cable.

The Port Expander can be mounted on a mounting rail in the control cabinet or operated locally on the table.

Part number:

Part number:	Name	Properties
00F5025-1080	PORT EXPANDER SET	with USB A-B, cable -4025 and HSP5 adapter - 0020
00F5025-0080	PORT EXPANDER	USB, Ethernet-, 4x HSP5 interface, ext. 24V
00F50C4-1010	USB cable	USB A-B, 4 pole, l = 1 m
00F50C0-4010	Cable RS 485/ HSP5	Connection RJ 45 - D-SUB 9, l = 1 m
00F50C0-4020	Cable RS 485/ HSP5	Connection RJ 45 - D-SUB 9, l = 2 m
00F50C0-4025	Cable RS 485/ HSP5	Connection RJ 45 - D-SUB 9, l = 2.5 m
00F50C0-4050	Cable RS 485/ HSP5	Connection RJ 45 - D-SUB 9, l = 5 m
00F50C0-0020	Fieldbus Adapter HSP5	D-SUB 9 / Western 400 mm
00F50C0-0021	Cable RS 485/ DIN 66019II	Connection RJ 45 - D-SUB 9, l = 2.5 m

The inexpensive starter set - part no. 00F5025-1080 - contains:

	Part number:	Name	Properties
1x	00F5025-0080	PORT EXPANDER	USB, Ethernet-, 4x HSP5 interface, ext. 24V
1x	00F50C4-1010	USB cable	USB A-B, 4 pole, l = 1 m
1x	00F50C0-4025	Cable RS 485/ HSP5	Connection RJ 45 - D-SUB 9, l = 2.5 m
1x	00F50C0-0020	Fieldbus Adapter HSP 5	D-SUB 9 / Western 400 mm



Fig. 12: Port Expander Bundle 00F5025-0080

Circuit example with COMBIVERT G6 and F5:



Fig. 13: Circuit example COMBIVERT G6/F5

1 Fieldbus adapter HSP5 Part No.
00F50C0-0020

2 Cable HSP5 Part No. 00F50C0-4025

3 Port Expander Part No.
00F50C0-0080

4 Cable RS 485/DIN 66019II Part No.
00F50C0-0021

- Communication Port Expander to serial DIN 66019II (only Port 4). Type G6, F6, S6, H6 and P6.
- Communication Port Expander to HSP5 (Port 1-4) Type F5 and B6.

Part no. 00F50C0-4025 can also be plugged directly into the Sub-D9-pole HSP5 socket of the F5 instead of the operator.

Further information can be found in the instruction manual. Please search for "00F5025-0080" or "Port Expander" on the KEB homepage ( www.keb.de).

When searching for the devices, node addresses 0 to 4 must be set (Node 0 = Port Expander, Node 1-4 = HSP5-Ports X4A – X4D). For RS485 on Port 4, the node address must be set to (node address of the device + 4).

The **USB driver** "FTDI_USB_Serial_Converter" can be found in the COMBIVIS 6 Installation directory "C:\Programme\KEB\COMBIVIS_6\Drivers" (please unpack first).

8 Device connection

8.1 Connection of COMBIVERT F5



Fig. 14: Connection of COMBIVERT F5 terminal X4A

- 1 HSP5 interface D-Sub 9-pole X4A:
USB serial converter Part No.
0058060-0040, Note 1)



Fig. 15: Connection_F5_2

- | | |
|--|--|
| <ul style="list-style-type: none"> 1 HSP-5 diagnostic interface X6B at fieldbus operators and interfaca operator: KEB USB serial converter, Part No. 0058060-0040, additionally HSP-5 adapter D-Sub 9-pole / RJ45 Part No. 00F50C0-0020 | <ul style="list-style-type: none"> 2 By using an interface operator (Part No. 00F5060-2000), connection at D-Sub 9-pole, X6C: RS 232 cable PC / operator Part No. 0058025-001D or KEB USB serial converter, Part No. 0058060-0040. Access also via IP operator, Part No. 00F5060-8000 |
|--|--|

Note 1:

After disconnecting the operator from the device, the baud rate of the device internal HSP5 interface must be reset to 38400 baud by restarting the F5 (or set manually by parameter Sy11 to 38.4 kBaud). The connection HSP5 operator works with 250kBaud, which is too much for the PC.

Connection possible also by KEB Port Expander (⇒ [Port Expander 00F5025-0080 \[▶ 32\]](#)).

On a free port of a PROFINET operator, COMBIVIS 6 can be operated in parallel to PROFINET. Please see FAQ-documents for instructions.

8.2 Connection COMBIVERT B6



Fig. 16: Connection_B6

- 1 HSP5 diagnostic interface X6B / connection with USB serial converter Part No. 0058060-0040 and HSP5 adapter D-Sub 9-pole / RJ45 Part No. 00F50C0-0020 or port expander

Or (⇒ Port Expander 00F5025-0080 [▶ 32])

8.3 Connection COMBIVERT G6



Fig. 17: Connection_G6

- 1 Instead of the operator: Interface X4A Direct connection to serial DSUB 9 pin protocol DIN 66019II : KEB USB serial converter Part No. 0058060-0040 or RS-232 cable PC / operator Part No. 0058025-001D

8.4 Connection COMBIVERT H6



Fig. 18: Connection_H6

- 1 Connection of the drive units directly to serial D-Sub 9-pole protocol DIN 66019II: KEB USB serial converter Part No. 0058060-0040 or RS-232 cable-PC / operator Part No. 0058025-001D

Access to drive units also via control unit by IP UDP.

8.5 Connection COMBIVERT P6



Fig. 19: Connection_P6

- 1 Interface X6A, connection to serial D-Sub 9-pole, protocol DIN 66019 II: KEB USB serial converter, Part No. 0058060-0040 or RS-232 cable-PC / operator Part No. 0058025-001D

8.6 Connection COMBIVERT F6

8.6.1 Housing size D - W



Fig. 20: Connection F6 Housing D to W

- 1 Connection to serial D-Sub 9-pole,
protocol DIN 66019 II: KEB USB
serial converter Part No.
0058060-0040 or RS-232 cable-PC /
operator Part No. 0058025-001D

8.6.2 Housing size 1 - 9



Fig. 21: Connection F6 Housing 1 to 9

- | | |
|---|--|
| <p>1 F6 Pro: Multi Ethernet interface:
Ether-CAT or LAN switchable</p> | <p>2 Instead of the operator: interface
X4A Connection directly to serial D
Sub 9 pole protocol DIN 66019II :
KEB USB serial converter Part No.
0058060-0040 or RS-232 cable PC /
operator Part No. 0058025-001D</p> |
| <p>3 Via pluggable operator: LAN inter-
face: Part No. 00F6P00-2000 / USB-
B interface: Part No. 00F6P00-3000</p> | |

At the COMBIVIERT F6-Pro, the Ethernet bus interfaces (EtherCAT) can be switched to Ethernet LAN.

8.6.2.1 Operator LAN (00F6P00-2000)



Fig. 22: Operator with LAN interface

- | |
|--|
| <p>1 LAN interface cable. The IP address
must be adjusted in parameter Fb01
by keyboard.</p> |
|--|

A good-shielded D-sub 9-pole extension cable can be used to connect the operator with the diagnostic interface on the COMBIVERT S6/H6.

8.6.2.2 Operator USB (00F6P00-3000)

Plug-in operator with USB interface Art. no. 00F6P00-3000.



Fig. 23: Operator with USB interface

1 USB A-B cable

A good-shielded D-sub 9-pole extension cable can be used to connect the operator with the diagnostic interface on the COMBIVERT S6/H6.

8.6.2.3 Operator LAN/USB (00F6P00-4001)



Fig. 24: Operator with USB and LAN interface

① USB A-B cable

② LAN interface cable. The IP address must be adjusted in parameter Fb01 by keyboard.

A good-shielded D-sub 9-pole extension cable can be used to connect the operator with the diagnostic interface on the COMBIVERT S6/H6.

8.7 Connection COMBIVERT S6




Fig. 25: Connection_S6

- | | |
|--|---|
| 1 Interface X4A: Connection directly to serial D-Sub 9 pole protocol DIN 66019II: KEB-USB serial converter Part No. 0058060-0040 or RS-232 cable PC / operator Part No. 0058025-001D | 2 S6-Pro: Multi Ethernet interface: EtherCAT or LAN switchable. The COMBIVERT F6 operators (see section 2.6.6) can also be used with COMBIVERT S6 with a short D-SUB 9-pin extension cable (art. no. 0058025-004A). |
|--|---|

The COMBIVERT F6 operators can be used at COMBIVERT S6 with short D-Sub 9-pole extension cable.

8.8 Connection COMBIVERT T6




Fig. 26: Connection_T6

- | |
|--|
| 1 Connection via LAN interface by standard LAN cable |
|--|

8.9 Connection of C6 Stepper/BLDC

Connection via COMBICONTROL C6 with COMBIVIS studio 6

Sample project available. See document data bench: FAQ C6 RIO 0001 QuickstartStepperBLDC



Fig. 27: Connection Stepper BLDC




Fig. 28: Connection Stepper BLDC documents

9 Installation

Since version 6.6.0 there is only one installation file. When installing, you can choose whether the standard version COMBIVIS 6 or the extended COMBIVIS studio 6 version shall be installed.

For new installations or when updating COMBIVIS 6, the selection is preset to COMBIVIS 6. When updating COMBIVIS studio 6, COMBIVIS studio 6 is also preset.




Fig. 29: Select components

Sand box installation / parallel installation

Since version 6.7.0 several COMBIVIS versions can be installed in parallel.

Applications:

- Allow parallel installation of the safety version and the non-safety version
- Retaining the old version
- Enable rapid pre-testing of beta versions, avoid impact on a productive environment

With parallel installation, some files are shared:

- Document Database
- Feature management
- KEB version manager

Some files are used individually:

COMBIVIS

- Parameter descriptions / Wizard descriptions

- Database of the configurator
 - Updates
- COMBIVIS-Studio
- Complete development environment including compiler
 - Libraries (optionally shared)
 - Device descriptions (optionally shared)
- Miscellaneous
- Visu-Profiles
 - Options
 - Packages, Plugins

When starting the installation, you can choose whether the previous version should be deleted or retained.

Setup

Uninstall existing version?

The following version shall be installed:

COMBIVIS studio 6 V6.7.0 Build 285

The following version of the application is already installed:

COMBIVIS 6 V6.6.0 Build 261

How would you like to proceed with the existing version?

→ Uninstall

The existing version will be uninstalled.

→ Keep

The new version will be installed in addition to the existing version.

Fig. 30: Installation Setup

- Uninstall: The older version is uninstalled and the new version is installed and replaces the old version.

- Retain: The new version is installed and added.

Then there are 2 (or more) start icons on the Windows surface:




Fig. 31: Icons Desktop

Version Manager

On the start page you will find the Version Manager:




Fig. 32: Last_used_projects




Fig. 33: Installed versions

This allows the individual versions to be managed. The card "Installed" shows the installed versions:




Fig. 34: Installation version manager

A specific version can be:

- started
- uninstalled
- excluded from the update
- directly updated

Versions provided by KEB but not installed are offered for installation on the card "Available" (Internet connection required):




Fig. 35: Version manager test version

9.1 Silent installation

The COMBIVIS 6 setup was created with the 'INNO Setup' installer. The setup file can therefore also be executed in 'silent mode'. You can find further information on this at:
(🌐► <http://www.jrsoftware.org>)

COMBIVIS (studio) 6.6.0 Setup can be configured in such a way that "Compact installation" is preset from the beginning:

For this purpose, parameter /TYPE="compact" must be added, e.g.:
"Setup_COMBIVIS_studio_6_V6.6.0_B227_R17.exe" /TYPE="compact"

Result:




Fig. 36: Silent Installation Select Components

Prevent standard linking of CODESYS files (e.g.: file extension ".project") with CV:
`"Setup_COMBIVIS_studio_6_V6.6.0_B227_R17.exe"/MERGETASKS="!associateProjectFileExtension"`

This can also be combined with the above command with the "Types" parameter.

9.2 Silent de-installation

Silent un-installation is possible instead of standard un-installation. To do this, open the programme folder of the corresponding version.

The file "unins000.exe" is then started with the corresponding parameters (see example).

Example:

```
unins000.exe /VERYSILENT /SUPPRESSMSGBOXES
```

10 Registration and licence

Registration: valid for COMBIVIS 6, free of charge, enables access to the KEB document database.

Licence: valid only for COMBIVIS studio 6, chargeable, turns off the demo mode, includes registration.

10.1 Registration

The free registration of COMBIVIS 6 allows access to the document database. Configurator, parameterisation, data backup and scope work without restriction in the demo version.

Internet access must be available for registration. An account must also be created on the KEB homepage. The registration key can be generated in the login area.

If you have a COMBIVIS studio 6 licence, this includes the registration.

An internet connection is required.

The registration link is on the home page:




Fig. 37: Carry out registration

You will be redirected to the KEB homepage:




Fig. 38: Registration KEB Homepage

Login into your account.

If you don't have an account yet, you can create one under "Login/Logout":




Fig. 39: Registration Not registered, yet

Go to COMBIVIS Registration:




Fig. 40: COMBIVIS Registration

Create the registration key:




Fig. 41: Registration Show registration key




Fig. 42: Registration key

The company name from the address range is the basis for the registration key.

The registration key is a 40-digit combination of letters and numbers.

Copy these two data into the registration window of COMBIVIS 6.




Fig. 43: Registration COMBIVIS 6

After registration, a restart of COMBIVIS 6 is required.

The registration is not related to the computer and can also be used on several computers.

The key is stored as the file "customer.nfo" on C:\ProgramData\KEB\COMBIVIS_6.

10.2 Licensing

The installed COMBIVIS studio 6 version is a demo version. It runs for a maximum of 1 hour and no boot projects can be created. After expiry, the demo version can always be restarted again. To get the full range of functions, you need a licence. Please contact your KEB sales organisation.

The licensing procedure for COMBIVIS studio 6 is described in the release notes: Menu "Help" → "Show release notes".




Fig. 44: Registration Show release notes

The COMBIVIS studio 6 licence includes the registration.

(⇒ [Registration \[▶ 51\]](#))

11 Programme description

The following section describes the individual elements of the programme interface.




Fig. 45: Start screen

- | | |
|--|---|
| ① Menu bar
③ Navigator
⑤ Messages | ② Toolbar
④ Start page |
|--|---|

11.1 Menu bar

The following image shows the menu bar with factory settings. Depending on the project, further menu items can be displayed.




Fig. 46: Menu bar

Only menu items that can be executed for the corresponding program functions are displayed in the submenus. All others are greyed out.

The menu bar and submenus can be customised using the Tools => Customize... Menu.

11.1.1 Menu - File




Fig. 47: Menu bar - File

New Project...

Opens a window for creating a new project.




Fig. 48: File - New project

- **Name**
Enter a project name.
- **Location**
Select the storage location for the project.
- **KEB device scan**
Select "KEB device scan" and **OK** or double-click on "KEB device scan" to start the wizard and list all devices found. The selected devices are transferred to the project by clicking on the "Add selected devices" button.
- **Empty project**
Select "Empty project" and **OK** or double-click on "Empty project" to create an empty project tree.

Open Project...

Open the window for selecting and opening files. All files supported by COMBIVIS are available for selection. With the combination button, you can choose between **Open** and **Open read-only**.

Close Project

Closes the current project.

Save Project

Saves the current project without closing it.

Save Project as...

Opens the window for selecting the storage location, file name and file type. The command button **Save** saves the project with the selected settings.

Print

Opens a window with the possible print settings.

Page settings

Opens a window for defining individual page settings.

The following tabs are available for customisation:

- Paper
- Margins
- Header and Footer
- Document
- Title Page

Last used projects

Displays a list of recent projects. Click to open a project.

Restart

Closes the current project and restarts the programme. Changes can be saved before closing.

Exit

Closes the current project and exits the programme. Changes can be saved before closing.

11.1.2 Menu - Edit




Fig. 49: Menu - Edit

Undo

Undoes the last programme input step by step. Does not apply to values that are transmitted to connected devices.

Redo

Restores an undone entry.

Cut

Cuts project parts (e.g. parameter lists) from the current project and copies them to the clipboard for further processing.

Copy

Copies project parts (e.g. parameter lists) from the current project to the clipboard for further processing. Device parameters are copied to the clipboard with the parameter name and value for further use.

Insert

Inserts project parts (e.g. parameter lists) from the clipboard into the current project.

Delete

Deletes project parts (e.g. parameter lists) from the current project.

Select all

Selects all lines, e.g. from a parameter list.

Find Replace

Opens a dialogue box with various search functions.

Next message

Used to navigate forwards in the message window.

Previous message

Used to navigate backwards in the message window.

11.1.3 Menu - View

The current screen view is defined in the view menu. The listed elements can be displayed.




Fig. 50: Menu - View

Navigator

Used to show the navigator. The navigator is displayed as a window or tab.

Property Editor

Used to show the Property Editor. The property editor shows all properties for the selected parameter on the "Device parameters" tab.

POUs

Display of programme organisational units (e.g. the project settings). The POU's are displayed as a window or tab.

Messages

Window in which errors, warnings and messages are displayed.

Start page

Displays the start page in the main window.

Full screen

Switches COMBIVIS to full screen display or back to window mode. Alternatively, you can also use **CTRL + Shift + F12** to switch.

Properties

Shows the properties for the currently selected object in the main window.

11.1.4 Menu - Project




Fig. 51: Menu bar - Project

(⇒ [List KEB devices \[▶ 104\]](#))

(⇒ [KEB device scan \[▶ 92\]](#))

(⇒ [Add KEB device \[▶ 93\]](#))

Comparing parameter lists

(⇒ [Online comparison \[▶ 227\]](#))

(⇒ [Offline comparison \[▶ 228\]](#))

(⇒ [Comparison method \[▶ 228\]](#))

(⇒ [Add parameter list \[▶ 206\]](#))

(⇒ [Add object \[▶ 66\]](#))

Add folder

Opens a window for entering a folder name. Click OK to save the folder to the active object.

Edit Object

This entry opens the currently selected object for editing.

Edit Object With

If several editing options are available for an object, a selection is opened. Otherwise the same function as "Edit object".

Project Information**File**

Shows basic information such as name, storage location, attributes and more.

Summary

Allows you to enter additional information about the project such as company, author ...

Properties**Statistics**

Shows an overview of the objects and their number in the project.

Licensing

Enables the library to be licenced with a dongle.

11.1.5 Menu - Tools

Package Manager

A list of already installed packages is displayed here. These can be uninstalled or others can be installed.

The "Details" button provides further information on the selected package, as well as information on licences.

Licence repository

Display of all installed licences. Import option for tickets.

Licence manager

Used to install purchased licences.

Customise

The menu, toolbars, keyboard shortcuts and command icons can be customised/as-signed here.

Options

Here you can make (\Rightarrow [General settings \[▶ 134\]](#)).

Import and Export Options

(See general settings)

Import KEB parameter description file

Manual updating of the (⇒ [parameter description file \[▶ 294\]](#)).

Reload parameter descriptions

After the import, the file must be reloaded or COMBIVIS must be restarted.

KEB FTP

Exchange of data via (⇒ [FTP connection \[▶ 304\]](#)).

IPScan

The (⇒ [IP scan \[▶ 316\]](#)) Tool is used to easily locate accessible devices in your own subnetwork.

KEB Documents

The COMBIVIS internal document database can be used to view all (⇒ [KEB Documents \[▶ 286\]](#)). The programming manuals of COMBIVERT F5, G6 and F6/S6/H6 are integrated in the basic configuration.

Manage KEB Documents

Here you can find more (⇒ [Documents \[▶ 283\]](#)) such as instructions, catalogues and E-plan data can be downloaded as data packages via the Internet.

Parameter backup

The (⇒ [Parameter backup \[▶ 231\]](#)) allows you to save one or more parameter lists.

11.1.6 Menu - Window

The standard Windows functions are available here.

11.1.7 Menu - Help




Fig. 52: Menu - Help

Content

Start the integrated COMBIVIS manual.

Index

Start the integrated index search.

Search

Start the integrated search.

Services and support

Click to open the KEB website "Services and Support". Here you will find addresses, telephone numbers and e-mail addresses for the various product groups. The "TeamViewer Quicksupport" software is also available for download.

COMBIVIS 6 Show operating instructions

Opens the COMBIVIS6 operating instructions with the integrated PDF viewer.

"FAQ" - Show documents

Opens the document database and filters it for FAQ documents.

Show release notes

Opens the pdf document with the release information for COMBIVIS 6 and COMBIVIS studio 6.

Visit KEB website

Opens the KEB homepage.

Check for updates

Manual search for updates to programs, drivers, parameter descriptions and documents. If the "Show only recommended updates" checkbox is unchecked, all available downloads are displayed.

Informations

Shows current information of the program version and registration.

11.2 Toolbar

The toolbar changes the available icons depending on the selected object.



Fig. 53: Toolbar

If you leave the mouse pointer over an icon, a tool text about the function is displayed.



Fig. 54: Toolbar - Tool text icon

11.3 Navigator

The navigator shows all devices, lists, offline wizards and other objects contained in the project.

The navigator normally appears on the left side of the window. If it is not visible there, it can be displayed with the menu bar "View" → "Navigator".





Fig. 55: Navigator



Predefined folders are attached to the project and to the device (parameter cockpits (⇒ [Parameter cockpit \[► 327\]](#)), Parameter lists (⇒ [Parameter lists \[► 206\]](#)), Scopes (⇒ [Scope \[► 238\]](#)), Wizards (⇒ [Start-up Assistant \(Wizards\) \[► 149\]](#))). If these are not required, they can be deleted.

Click on project name or device name → right mouse button → "Add object" to add folders, parameter lists, scopes, etc.




Fig. 57: Add_object

Objects attached to the project are valid for several devices, objects attached to the device are only valid for this device.

see also

- █ Parameter cockpit [▶ 327]
- █ Parameter lists [▶ 206]
- █ Scope [▶ 238]
- █ Start-up Assistant (Wizards) [▶ 149]

11.3.1 Display of the communication status:




Fig. 58: Device_active_inactive




Fig. 59: Device_active_no_connection

Alternatively, the communication status can also be changed via the context menu: right mouse button → "Online" / "Offline"




Fig. 60: Navigator_communication_status_online_offline

11.3.2 Rename elements

The names of the elements in the Navigator can be changed in two ways.

Please note! Device designations must not begin with a number.

Click twice slowly on a single element with the left mouse button. Then the new name can be entered.




Fig. 61: Change element name

Right-click on an element to access the function via the menu item **Properties**:




Fig. 62: Properties menu item

A dialogue window then opens. The default designation can be overwritten here.




Fig. 63: Rename elements

11.3.3 Add configuration

The KEB Configurator is a tool for easy modelling of a KEB drive system. While assembling these models you are supported by an intuitive Graphical User Interface (GUI) and different component selection wizards.

The systems assembled with the configurator can be used for various purposes. On the one hand, a configuration is used to document a planned or created drive system from KEB components. Furthermore, the information from the configuration can be used to generate COMBIVIS (or COMBIVIS studio) projects and part lists, e.g., for requesting a quotation.

The configurator also provides easy access to the technical data of KEB devices and their documentation.

Note:

In the configurator, the standard portfolio of KEB is included. For special options, please contact directly to the KEB sales.

Right-click on the project name, then left-click on "Add object" > "Configuration" to start a new configuration.




Fig. 64: Add configuration

11.3.3.1 Work with Configurator

The Configurator consists of 3 main parts:




Fig. 65: Work with Configurator

1. Workspace

Here all selected devices are shown, placed, and connected.

2. Product selection window

The elements are shown that can be used in the Configurator.

3. Properties window

The properties of the elements selected in the workspace are shown.

11.3.3.1.1 Workspace





Fig. 66: Work with Configurator

1 Placed and connected elements / system components

2 Miniature view with zooming option

11.3.3.1.2 Connections

Connections / cables can be inserted from the product selection or by drawing a new connection from an interface with the mouse:



1 ——

Fig. 67: Configurator connections

- 1 Possible interfaces for a connection
are highlighted.

A fitting connection is automatically inserted. If multiple connections are possible, one must be selected from the dialog that will appear automatically in this case.

11.3.3.1.3 Document access

Using the context menu "Show Documents", it is possible to access all documents associated with that element:




Fig. 68: Configurator Document access

11.3.3.1.4 Product selection window




Fig. 69: Configurator product selection window

1 Part number filter

2 Start selection wizard

3 Select elements via double click or
drag & drop

Example of a product selection wizard:




Fig. 70: Configurator product selection

If no wizard is available, the elements will be shown in a table. This view is also available from a wizard using the “Expert view” tab.

11.3.3.1.5 Properties window




Fig. 71: Configurator properties window

1 Expert view

2 For each column, a filter can be set.
Green = Filter active




Fig. 72: Configurator properties window input

1 Name of the selected device: Device name / position of the name field

2 Technical data of the selected device

11.3.3.2 Generate COMBIVIS project

From a configuration the contents of a COMBIVIS project can be generated. This is done via the menu:




Fig. 73: Configurator Create COMBIVIS project

Or via tool bar:



Fig. 74: Configuration Icon export configuration

This menu command opens a preview dialog where additional adjustments can be made:




Fig. 75: Configurator generate project

In COMBIVIS studio 6 in addition to the parameter based devices also PLC devices with complete EtherCAT or CAN-Bus topologies can be generated:




Fig. 76: Configurator Generate Project Preview

Depending on the size of the project to generate this might take a moment.

After the generation, the relation between the elements in the configuration and the created objects persists, which enables additional functionalities:

Open created objects:




Fig. 77: Configuration open created objects in COMBIVIS

Using the context menu all generated objects can be opened. Open in Configuration:




Fig. 78: Configurator Show items in configuration

From the navigator the corresponding elements can be highlighted in the Configurator.




Fig. 79: Configurator Highlighted elements

- 1 Highlighted elements blink for some seconds.

11.3.3.3 Part list

The part list is available using the menu:




Fig. 80: Export configuration

Or via tool bar:



Fig. 81: Configurator Export Icon configuration

The part list contains all elements from the configuration. There are options to customize the view. Different export formats are available as well as a print option.




Fig. 82: Configuration Export

11.3.3.4 Assign documents

In the “Documents” tab of the editor for KEB devices all relevant documents for that device can be listed and viewed with one click. This list contains for instance all documents for the device and the connected motor.

(⇒ [Use document database \[▶ 286\]](#))

11.4 Start page




Fig. 83: Start page

① Last used projects

② Quick start menu

③ Online

④ Options

12 Startup

Working with a device in COMBIVIS 6 always requires the creation of a new project or the opening of an existing project.

Communication with the device can be established via:

- Creating a new project and project wizard (⇒ [Start with the project assistant \[▶ 86\]](#))
- (⇒ [Direct device search \[▶ 92\]](#))
- Manual setting of communication values with known hardware (⇒ [Direct connection to the device \(add device\) \[▶ 93\]](#))

For the last two points, a temporary project is always created in the background first. This can then be saved via "File" → "Save project as...".

If only an existing parameter list is to be loaded into a KEB COMBIVERT, the function "(⇒ [Download of a parameter list \[▶ 97\]](#))" can be used on the start page.

COMBIVIS 6 always starts with the home page in the default setting.




Fig. 84: Show start page



The home page can be reactivated at any time with this icon

When the mouse pointer is positioned on a button, a description of the function is displayed.




Fig. 85: Start page Mouse pointer




Fig. 86: Used projects list

❶ The vertical pin permanently attaches project names to the list.

❷ The "cross" deletes the selected project name from the list.

see also

▀ Startup [► 85]

12.1 Start with project assistant

12.1.1 Start with the project assistant

The automated "Project Wizard" opens a new project, performs a predefined search for connected devices and integrates the found devices into the project.

After clicking on "New project", the "Project wizard" window is opened. Alternatively, one of the last projects can also be opened.




Fig. 87: New_Project

1 Open any project

2 Open one of the last saved projects

- "Empty project" opens an empty project. The device search / integration must then be started manually.
- "KEB Device Search" opens the device search window




Fig. 88: Project name

1 Enter project name and location

The device search depends on the pre-configuration and runs automatically. Device search window:




Fig. 89: Device search

- 1 The search can be started, stopped, the settings can be changed and re-started.

The explanation of the window function can be found at ([⇒ Manual device search \[▶ 89\]](#)).

If devices were found, continue with ([⇒ Device editor \[▶ 103\]](#)).

If one or more device(s) were not found, adjust the search settings, continue with ([⇒ Manual device search \[▶ 89\]](#)).

12.1.2 Start with an empty project




Fig. 90: Working with an empty project

With an empty project, a specific device search can be carried out with connected devices, and a manual device integration can be carried out without connected devices.

12.1.3 Manual device search

Open an empty project and (or from an existing project:) execute menu bar "Project" → "KEB device search".




Fig. 91: Manual device search

or click on the icon for "manual device search":




Fig. 92: Icon manual device search

The search process can be influenced in the device search window.

In deviation from the initial setting, other COM interfaces, addresses, baud rates or IP addresses can be temporarily searched.




Fig. 93: Device_search_UDP_IP

- | | |
|--|------------------------------|
| 1 Search area UDP/IP | 2 Search area COM interfaces |
| 3 Stop search | 4 Start search |
| 5 Adopt selected setting for future searches | 6 Select devices to be added |
| 7 Add found devices to the current project | |

By searching via USB serial converter on COMBIVERT F5/B6 (HSP5 protocol), please note the information ([⇒ under KEB USB serial converter. \[▶ 28\]](#))

If the communication data is known, a device can also be set directly without search ([⇒ Direct device search \[▶ 92\]\).](#)

12.1.4 Start offline (without connected device)

A fictitious device can be added manually in the project. This can then be used, for example, to create a parameter list offline.

→ Open empty project → Click with left mouse button on toolbar: "Add parameterisable KEB device"




Fig. 94: Add Icon parameterisable KEB device




Fig. 95: Add_device

- | | |
|--|--|
| 1 Select device group / type or configuration number | 2 If necessary, select operator or control type (G6) |
| 3 Enter: "Add device" | |

For help in selecting the correct device group for F5 and G6, there is an overview available in the FAQ documents: Menu "Help" → "Display FAQ documents" → "COMBIVIS 6" → "CV6 FAQ0005 F5 G6 Short names operating modes".

Enter or accept the name of the device to be inserted.



Fig. 96: New parameterisable device

The device name must not begin with a digit, COMBIVIS then places an underscore at the beginning of the word.

Offline device is added and the device editor window opens. (⇒ [Direct device search \[▶ 92\]](#)).

12.2 Direct device search

With the selection field "Search for devices" on the home page, a temporary project is created and the device search window is opened. The search must be started manually after setting the hardware configuration.





Fig. 97: Icon direct device search






Fig. 99: Icon direct connection to the device




Fig. 100: Add_all_devices

- | | |
|--------------------------------------|--|
| 1 Set IP address | 2 Devices found in the network |
| 3 Devices found under the IP address | 4 Enter: Single "Add device" - window remains open "Add and close all devices" - window closes |



With the KEB port expander item no. 00F5025-0080, the devices are found on each searched port (8000 and 8001) and listed twice during the automatic search. Please set a fixed port here.

For serial or USB connection:




Fig. 101: USB_connections

- | | |
|---|---|
| 1 Set communication data. Detected USB connections are suggested. Set baud rate manually. Typically 38400 baud for x6 devices.
3 Enter: "Add device" - Add this device to the project and window remains open. | 2 "Communication Test" runs once for each setting change. Found devices are listed immediately.
4 "Add all devices and close" - window closes. |
|---|---|

12.3.1 Offline (virtual device):

When "Offline", the device can be selected manually on the basis of the type/firmware version or if the configuration identifier is known.




Fig. 102: Add_device_1

- | | |
|--|---|
| 1 Set type | 2 Enter the configuration identifier manually |
| 3 Set available operator (or the control version for G6) | 4 Add device |

The device(s) are displayed in the navigator window.

12.4 Open an existing project




Fig. 103: New_Project

- | | |
|--------------------|---------------------------------------|
| 1 Open any project | 2 Open one of the last saved projects |
|--------------------|---------------------------------------|

or:




Fig. 104: Start Up last used projects

1 Open any project

2 Open one of the last saved projects

If a project is opened without connected devices, the last connection status is retained when saving again.

12.5 Download of a parameter list

The function specifies a path with which a parameter list saved somewhere can be downloaded into a KEB device.

A temporary project is created with the selection field "Download of a parameter list", the parameter list is opened, the window for connecting the device is displayed and after the connection the parameter list is loaded into the device.




Fig. 105: Download_Parameter list

Mark and "open" the parameter list:




Fig. 106: select the file download of a parameter list

12.5.1 When connected via UD/IP (Ethernet):

The window shows an input field for the IP address. At the same time, a network scan is carried out and the found devices are listed. Standard port and node address are automatically detected.

The devices found via the IP address are listed below and can be transferred to the project.




Fig. 107: Add_all_devices

1 Set IP address

3 Devices found under the IP address

2 Devices found in the network

4 Enter: "Add device" - window remains open. "Add all devices and close" - window closes.



With the KEB Port Expander, item no. 00F5025-0080, the devices on each searched port (8000 and 8001) are found and listed twice during the automatic search. Please set a fixed port here.

12.5.2 For serial or USB connection:




Fig. 108: USB_connections

- | | |
|--|---|
| 1 Set communication data. Detected USB connections are suggested. Set baud rate manually.
3 Enter: "Add device" - Add this device to the project and window remains open. | 2 "Communication Test" runs once for each setting change. Found devices are listed immediately.
4 "Add and close all devices" - window closes. |
|--|---|

Confirm download with "Yes".




Fig. 109: Confirm_parameter_list_download

After the download is complete, the success is displayed in the message window in the lower window area:




Fig. 110: Download_completed

The download has been completed and COMBIVIS can be closed.

12.6 Saving a project

The project can be saved under "File" → "Save project" with the same name or "Save project as..." with a new name.




Fig. 111: Save_project

Save compatible to older version:

If the project shall be opened on another PC with an older version of COMBIVIS, it is recommended to save the project compatible to this version. Otherwise you get an error message when you open it and you have to adapt the project:

"File" → "Save project as..." → File type




Fig. 112: Compatible_older_version

The file types (*.library) are generated by CODESYS and can be ignored here. If a profile of an older version is required, please contact KEB.

13 Device editor

Data communication is online, all parameter values are changed directly in the device.

A parameter backup of the device must be made via its own parameter list (⇒ [Parameter backup \[► 231\]](#)).

Each device has its own device editor.

13.1 Opening the device editor

There are two ways to open the device editor:




Fig. 113: Open_Device_Editor

1 Double-click on the device name with navigator or:

3 "Open in Editor"

2 mark the device (or devices) to be edited (1.) - Click arrow down.




Fig. 114: Opening_the_device

13.2 Device reference

The device reference is the instrument to clearly distinguish the individual devices in the project. This is assigned in the order in which it is found during the device search and describes the position of the device in the data bus. It is independent of the (device) node address.

I.e. if the wiring is changed and a new search is made, the device reference may be changed!

The device reference is only assigned once and cannot be changed manually!

An overview list with all devices can be displayed:

Context menu "right mouse button" in the Navigator window → "List KEB devices"

In the menu bar: "Project" → "List KEB devices"




Fig. 115: List device reference KEB devices

The screenshot shows the 'Parameterizable KEB-Devices' dialog box. It has a title bar 'Parameterizable KEB-Devices' and a table with the following data:

Device name	Device ref.	Device ConfigID	Device type	Operator Config ID	Operator type	Comm. Status	Protocol	Comm. Address	Node address
axis_1_F5	0	3420	P6M/V4.30 4...	0_32	FS232/485/Dig...	✓	SERIAL	COM7 (384...	2
axis_2_G6	1	7080	GSP 5/V1.0.3...	50304	G6/C/NoOpn V...	✓	SERIAL	COM7 (384...	

Fig. 116: Device reference configurable KEB devices

13.3 Switch active device offline

To protect an active device against accidental operation or if the communication data is to be changed, individual devices can be excluded from communication:




Fig. 117: Switch_devices_online_offline

- 1 Right-click on the device. Click on "Online" and remove or set check mark.

Alternative:




Fig. 118: Devices_online_offline_alternative

1 Select device

2 Connect or disconnect the device

13.4 Screen layout




Fig. 119: Screen layout

1 Navigator: Representation and activation of the individual devices and objects in the project

2 Editor: Editing of devices and objects, division into tabs according to a) devices and b) editors for each device

3 Program messages: Status, warning and error messages are displayed and logged

13.5 Communication settings




Fig. 120: Communication settings

- | | |
|---|---|
| <p>① Selection of the function tables of a device or object.</p> <p>③ Communication data node/device address status of the device, online / offline</p> <p>⑤ Changing the communication settings (offline only).</p> <p>⑦ Searches for the maximum possible baud rate for serial communication and sets the value. The device must be online for this.</p> <p>⑨ Current firmware (configuration) ID of the operator stored in the project.</p> | <p>② Device name</p> <p>④ Switches the current device offline/online.</p> <p>⑥ Resets the baud rate to the factory setting.</p> <p>⑧ Current firmware (configuration) ID of the device stored in the project.</p> <p>⑩ Expert settings: Addressing type for this device deviating from the global project setting.</p> |
|---|---|




Fig. 121: Expert settings

① Addressing type for this device deviating from the global project setting.
[▶ 112]

② Device reference number in the project (not the device address!) [▶ 104]

Further information:

Description of the addressing types (⇒ Set addressing [▶ 112]).

What means the (⇒ Device reference [▶ 104])?

13.6 Online wizard / commissioning assistant

Depending on the device type, commissioning wizards are offered (⇒ Start-up Assistant (Wizards) [▶ 149]).




Fig. 122: Online_wizard

13.7 Device parameter

In the device parameter tab, the function parameters of the device (drive controller) are displayed in the current state. Changeable parameters can be changed here directly in the device. Parameters of the pluggable operators at COMBIVERT F5 or the control cards of COMBIVERT B6 and G6 are displayed in the tab operator parameter.




Fig. 123: Devices_Parameter_1

- ① Parameter groups: Open by clicking on "+" or "Enter" / "Space"
- ② Open set-parameterisable parameters or ARRAYS
- ③ Change values of parameters: Mark parameter and "Enter" or "Double-click" with left mouse button, change value in property editor.

(⇒ [Help for parameter functions \[► 335\]](#))

A distinction is made between parameter groups:

+ oP: operational parameter	
+ Pn: protection parameter	
+ cS: control speed parameter	
- uF: u/f parameter	
+ uF00: rated frequency <0>	50,0000 Hz
+ uF01: boost <0>	5,1 %
+ uF02: add. frequency <0>	0: linear u/f function
+ uF03: add. voltage <0>	0,0 %

Fig. 124: Devices_Parameter_2

Set-parameterisable parameters or ARRAY and STRUCT. By opening with "+", you can access the individual parameters in the sets or the subindices:

+	control speed parameter	
+	uF: uF parameter	
+	uF00: rated frequency <0>	50,0000 Hz
	uF00: rated frequency <0>	50,0000 Hz
	uF00: rated frequency <1>	50,0000 Hz
	uF00: rated frequency <2>	50,0000 Hz
	uF00: rated frequency <3>	50,0000 Hz
	uF00: rated frequency <4>	50,0000 Hz
	uF00: rated frequency <5>	50,0000 Hz
	uF00: rated frequency <6>	50,0000 Hz
	uF00: rated frequency <7>	50,0000 Hz
+	uF01: boost <0>	5,1 %
	uF02: add_frequency <0>	0,0 linear uF fun

Fig. 125: Devices_Parameter_3

and variables: The variables are global and have the same value for type F5/ G6/ B6 in all parameter sets. (Blue cube: writeable and readable, grey cube: read only)

+	uF11: switching frequen	
	uF12: base block time	
	uF13: base block voltage	
	uF14: transistor on delay	
	uF15: hardw. curr. lim. r	
+	uF16: autoboot configu	
	uF17: autoboot gain <0>	

Fig. 126: Devices_Parameter_4

Further properties in the context menu:




Fig. 127: Devices_Parameter_5

- | | |
|--|---|
| 1 All parameters displayed on the screen are updated. | 2 Only the selected parameters are displayed and updated. |
| 3 Opening the parameter groups with keys r, o, p, c... possible (F8), closing with "Space" | 4 Creates new parameter list with marked parameters. |
| 5 Displays an explanation of the parameter in KEB documents. | |

13.7.1 Set addressing

Set addressing is used for COMBIVERT F5/G6/B6.

The parameter sets are selected in the basic setting of COMBIVIS 6:

- for devices with KEB set addressing (COMBIVERT F5, B6 and G6 (V1) in a direct way (switchable to "active set" or indirect).
- for devices with CANopen addressing (COMBIVERT G6 (V2),) according to CiA 301 (cannot be switched).

Setting in toolbar - "Tools" → "Options" → "KEB Parameterisation" → Tab: "Parameter"




Fig. 128: Set-addressing_1




Fig. 129: Set-addressing_2

Or only for the current device in the "Device Editor" → "Communication Settings" → "Expert Settings" → "Explicit":




Fig. 130: Device_2

① Addressing type for this device deviating from the global project setting.
[▶ 112]

② Device reference number in the project (not the device address!) [▶ 104]
[▶ 104]

Which addressing is currently being used is permanently displayed in the editor at the bottom edge.

Group-/Parameter-Name	Parameter value
ru: run parameter	
oP: operational parameter	<ul style="list-style-type: none"> oP00: reference source <0> 0: analog REF oP01: rotation source <0> 2: FOR/REV, 0-lim. oP02: rotation setting <0> 0: low speed oP03: reference setting <0> 0.0000 Hz oP05: reference setting % <0> 0.0 % oP06: min. reference forward <0> 0.0000 Hz oP07: min. reference reverse <0> -1: = forward parameter oP10: max. reference forward <0> 70.0000 Hz oP11: max. reference reverse <0> -1: = forward parameter oP14: abs. max. reference for <0> 400.0000 Hz oP15: abs. max. reference rev <0> -1: = forward parameter oP16: rotation delay time 0: off oP18: step value rot. source <0> 2: FOR/REV, 0-lim. oP19: step value input sel. 1 16: I1 oP20: step value input sel. 2 32: I2

Fig. 131: Set-addressing_3

13.7.2 Direct addressing

For each parameter, it is shown to which set it belongs.

The first sub-view shows the parameter which is addressed directly (here: set 0 and 2).

Group-/Parameter-Name	Parameter value
+ ru: run parameter	
+ oP: operational parameter	
oP00: reference source <0;2>	0: analog REF
oP01: rotation source <0;2>	2: FOR/REV, 0-lim.
oP02: rotation setting <0;2>	0: low speed
oP03: reference setting <0;2>	0,0000 Hz
...	---

Fig. 132: Direct_addressing_1

In the second sub-view (second "+"), all 8 parameters are always displayed with direct addressing.

Group-/Parameter-Name	Parameter value
+ ru: run parameter	
+ oP: operational parameter	
oP00: reference source <0;2>	0: analog REF
oP00: reference source <0>	0: analog REF
oP00: reference source <1>	0: analog REF
oP00: reference source <2>	0: analog REF
oP00: reference source <3>	0: analog REF
oP00: reference source <4>	0: analog REF
oP00: reference source <5>	0: analog REF

Fig. 133: Direct_addressing_2

With direct addressing, you can also access parameters of several sets at the same time:




Fig. 134: Direct_addressing_3




Fig. 135: Direct_addressing_4

13.7.3 Indirect addressing

Occurs indirectly via parameter pointer Fr09. The values displayed in the first sub-view belong to the adjusted set in Fr09 (parameters that cannot be set are always the same in all sets).




Fig. 136: Indirect_addressing_1




Fig. 137: Indirect addressing parameter set pointer

Only the parameter set pointer Fr09 shows to which set the currently displayed parameter values belong! The pointer is therefore permanently shown in the editor at the bottom.

The setting of the set pointer Fr09 occurs in the editor at parameter Fr09 or directly with

the icon:






Fig. 138: Indirect addressing Fr09

In the second sub-view (second "+"), all 8 parameters are always displayed with direct addressing.

13.7.4 Active set

In the first sub-view the parameters of the set are shown and parameterised with which the drive controller is currently running. Display in parameter ru26, active set at the bottom of the editor or in the editor

In the second sub-view (second "+"), all 8 parameters are always displayed with direct addressing.




Fig. 139: Active set parameters

axis_1_F5		Device settings	Device-parameters	Operator-parameters	Documents	Online Wizards	Information
Group-/Parameter-Name	Parameter value						
ru: run parameter							
oP: operational parameter							
oP0: reference source	0: analog REF						
oP01: rotation source	2: FOR/REV, 0-lim.						
oP02: rotation setting	0: low speed						
oP03: reference setting	0,0000 Hz						
oP05: reference setting %	0,0 %						
oP06: min. reference forward	0,0000 Hz						
oP07: min. reference reverse	-1: = forward parameter						
oP10: max. reference forward	70,0000 Hz						
oP11: max. reference reverse	-1: = forward parameter						
oP14: abs. max. reference for	400,0000 Hz						
oP15: abs. max. reference rev	-1: = forward parameter						
oP16: rotation delay time	0: off						
oP18: step value rot. source	2: FOR/REV, 0-lim.						
oP19: step value input sel. 1	16: I1						
oP20: step value input sel. 2	32: I2						
oP21: step value 1	5,0000 Hz						
oP22: step value 2	50,0000 Hz						
Addressing mode : active set password : application password		🔑	indirect set pointer : 0	⬇️	active parameter set : 0	⬆️	

Fig. 140: Active set setpoint source

13.7.5 Addressing according to CiA 301.

Addressing of the COMBIVERT F6, H6, P6, S6, T6. The addressing occurs according to CiA 301.

VARiables are marked with blue or grey cube. (blue: readable and writable / grey: read only). The parameter value is in the line.

+ ..	st: status info	
+ ..	dr: drive parameter	
-	vl: velocity mode	
	vl04: vl velocity min amount for	0 1/min
	vl05: vl velocity max amount for	2000 1/min
	vl06: vl velocity min amount rev	0 1/min
	vl07: vl velocity max amount rev	2000 1/min
	vl20: vl target velocity	0 1/min
	vl21: target velocity high res	0.0000 1/min
	vl41: vl velocity actual limit for	2000 1/min
	vl42: vl velocity actual limit rev	2000 1/min
	ds: drive specif. control para.	

Fig. 141: Addressing according to CiA 301 variables



STRUCTure parameters are marked with a "tree symbol". The associated sub-indices are again marked with blue/grey cubes (blue: readable and writable / grey: read only).

=	ru80: relative load	0.0 %
-	ru81: actual torque	0.000 Nm
-	ru82: actual power/energy (Count)	7
	ru82: mechanical power [1]	0.000 kw
	ru82: electrical output power [2]	0.000 kw
	ru82: electrical power loss [3]	0.000 kw
	ru82: out. energy mot. [4]	0.4 KWh
	ru82: out. energy mot. volatile [5]	0.000 KWh
	ru82: out. energy gen. [6]	0.0 KWh
	ru82: out. energy gen. volatile [7]	0.000 KWh
+ -	ru83: diff. speed (Count)	3
-	ru84: ref value display	0.0000 1/min

Fig. 142: Addressing according to CiA 301 ru82



ARRAY parameters are marked with a "tree symbol". The associated sub-indices are again marked with blue/grey cubes. (blue: readable and writable / grey: read only)

ru82: out. energy gen. [6]	0.0 kWh
ru82: out. energy gen. volatile [7]	0.000 kWh
ru83: diff. speed (Count)	3
ru83: diff. speed [1]	0.0000 1/min
ru83: diff. speed [2]	0.0000 1/min
ru83: diff. speed [3]	0.0000 1/min
ru84: ref value display	0.0000 1/min

Fig. 143: Addressing according to CiA 301 ru83

STRING parameters contain text. Available only in COMBIVERT F6-Pro and S6-Pro (e.g. fb110)

fb105: MAC Address (EoE Channel)
fb106: MAC Address (EthChannel)
fb108: Ethernet over fieldbus IP configuration (Count)
fb109: basic IP configuration (Count)
fb110: Scan names (Count)
fb110: Scan names [1]
fb110: Scan names [2]
ec: encoder parameter

Fig. 144: Addressing according to CiA 301 fb110

Addressing of the COMBIVERT G6

Addressing according to CiA 301 is similar to direct set addressing with COMBIVERT F5. There are ARRAYS and VARiables. The ARRAYS have x subindices. The subindices are numbered from 1 to x. Set 0 corresponds here to subindex 1. Set 1 to subindex 2, etc.

In the first sub-view (parameter sets closed), the number of available subindices is displayed for set-parameterisable parameters and the parameter value is displayed for non-set-parameterisable parameters.

Indirect addressing, "active set" and addressing of several parameters simultaneously are not supported!




Fig. 145: Addressing COMBIVERT G6 according to CiA 301 CANopen

The display of the closed ARRAYS or parameters in the group view can be changed.

Under "Tools" → "Options" → "KEB Parameterisation" → Tab: "Parameters" → "ARRAYs" you can set whether the value of the first subindex should be displayed.




Fig. 146: Addressing according to CiA 301 parameters

Or in the context menu: Right mouse button → "Display subindex [1] for ARRAYs".




Fig. 147: Addressing according to CiA 301 subindex

13.8 Operator parameters

The tab only appears when an operator is detected. For COMBIVERT B6 and G6, the internal communication control card is designated as "operator".

Same mode of operation as for the "Device parameters" tab




Fig. 148: Operator parameters tab

13.9 Documents

All available manuals are displayed in the documents tab. By entering the device part number, only the associated documents are displayed. Part numbers entered here are permanently assigned to the device, but can be changed by overwriting them.




Fig. 149: Documents tab

(⇒ [Document database \[▶ 283\]](#))

13.10 Switching between editors

Switching between the editors can be done by:

- Clicking on the editor tab
- Double-click on the object in the navigator




Fig. 150: Change_between_editors_1

Key combination "CTRL+TAB"

With the "CTRL" key held down, the " \leftarrow ", " \uparrow ", " \rightarrow ", " \downarrow " keys can be used to select the editor or view to be opened. Only active editors are displayed.




Fig. 151: Change_between_editors_2

13.11 Device memory (recipe management)

The KEB COMBIVERT F6/ S6 have the function Recipe management. Certain parameter lists are stored in the device memory and can later be loaded into the runtime environment in various ways.

To save the files, the device memory wizard ((\Rightarrow [Device storage wizard \[▶ 295\]](#))) or the KEB (\Rightarrow [FTP \[▶ 304\]](#)) can be used.




Fig. 152: Device memory (recipe management)

14 Property editor (input window)

To change the parameter value, the input window can be opened by double-clicking on the current parameter value or by marking it and pressing the "Enter" key.




Fig. 153: Property editor (input window)

14.1 Initial setting

Under: "Tools" → "Options" → "KEB Parameterisation" → "Behaviour" you can define in the "Property Editor" field whether the input window is only sequentially or always visible.




Fig. 154: Basic setting Tools options




Fig. 155: Basic setting Behaviour

14.2 Function selection




Fig. 156: Function selection

- | | |
|---|--|
| 1 The value is accepted with "OK" or the "Enter" key.
3 The input value is accepted with "OK". It can also be typed directly as a digit.
5 Scroll bar | 2 Scroll bar
4 Open selection table |
|---|--|

14.3 Numerical value input




Fig. 157: Numerical value input

- | | |
|---|---|
| 1 The value is accepted with "OK" or the "Enter" key. | 2 Scroll bar can be moved with the mouse. |
| 3 Direct input of the numerical value.
The value is accepted with "OK".
The unit is automatically inserted. | |



Depending on the international setting of the MS-Windows, "comma" (German) or "dot" is used as a separator for fractional numbers. In German, the dot is interpreted as a 1000 separation.

14.4 Parameter properties / background information

The stored device description file contains a lot of information about the device parameters. These are shown when you click on the small triangle at the bottom of the input window.




Fig. 158: Parameter properties_1




Fig. 159: Parameter properties_2

- 1 A mouse click on the triangle opens a window that shows basic data of the parameter: Hexadecimal address, limits, default value, resolution, data length, etc.

14.4.1 Plain text export according to IEC 61131-3

With the version **COMBIVIS studio 6** you can export the display texts in IEC 61131 format. At parameter: Context menu → "Generate IEC 61131-3 code" → "Generate plain text function".




Fig. 160: Generate plain text export according to IEC 61131-3 code

```

1  /*
2   * This function generates the plaintext for parameter "ru01: exception state" (Device-Type: 9266; "no guarantee for correctness and completeness")
3   *
4   */
5  FUNCTION GetPlainText_ru01 : STRING(35)
6  VAR_INPUT
7      // The value for which the plaintext is desired
8      value : DMWORD;
9  END_VAR
10
11
12
13
14 CASE value OF
15     16#00000000: GetPlainText_ru01 := 'no exception';
16     16#00000001: GetPlainText_ru01 := 'ERROR chain';
17     16#00000002: GetPlainText_ru01 := 'ERROR supply';
18     16#00000003: GetPlainText_ru01 := 'ERROR overcurrent PU';
19     16#00000004: GetPlainText_ru01 := 'ERROR overcurrent analog';
20     16#00000005: GetPlainText_ru01 := 'ERROR overpotential';
21     16#00000006: GetPlainText_ru01 := 'ERROR underpotential';
22     16#00000007: GetPlainText_ru01 := 'ERROR overload';
23     16#00000008: GetPlainText_ru01 := 'reset E. overload';
24     16#00000009: GetPlainText_ru01 := 'ERROR overload 2';
25     16#0000000A: GetPlainText_ru01 := 'ERROR overheat powmod.';
26     16#0000000B: GetPlainText_ru01 := 'reset E. overheat pmod.';
27     16#0000000C: GetPlainText_ru01 := 'ERROR overheat internal';
28 END_CASE

```

Fig. 161: Plain text export according to IEC 61131-3 code text

15 General settings

General and special options can be indicated and adjusted in "Tools" → "Options...".




Fig. 162: Tools options

These settings will be saved automatically non-volatile when COMBIVIS 6 is closed. In the event of a version update, the option settings are retained.

The settings can be exported and imported on another computer: Menu bar "Tools" → "Import and Export Options..."




Fig. 163: Tools Import and Export Options




Fig. 164: Import and Export Options

15.1 Options - Language Settings

There are 3 language areas:

- Program language
- Parameter language
- Help

These can be handled independent. If a language is not available English is shown.

Setting the program language and help under: Toolbar –"Tools“ → "Options“ → "International Settings“.




Fig. 165: International Settings

The parameter language can be adjusted by: "Options" → "KEB Parameterization" → "Parameters".

(⇒ [KEB Parameterization - Parameter view](#) [▶ 138])

15.2 Configurator

KEB Configurator initial settings can be set here. They apply to each new start of the configurator KEB Configurator.




Fig. 166: Configurator_1




Fig. 167: Configurator_2

15.3 Options - KEB documents




Fig. 168: KEB documents

(⇒ ► Document database [► 283])

15.4 Options - Online update

KEB COMBIVIS 6 can search for available updates and install if an internet connection is available. Not only program updates are searched for, but also updates for manuals, parameter description files (required at firmware update in KEB devices) and libraries.




Fig. 169: Options_Online_Update_1

1 Activates the automatic online update.

2 Selection: When to check for updates.

Automatically check for updates weekly/monthly means: next test 7/30 days after the last test if an Internet connection exists or at the next connecting after this date.

If the Internet connection cannot be established via the standard proxy settings, the setting for COMBIVIS 6 can be made separately.




Fig. 170: Options_Online_Update_2

15.5 KEB Parameterization - Parameter view

Setting for the display of the device parameters in the device editor.




Fig. 171: Parameter view

- | | |
|---|--|
| <p>1 Parameter language: If language file is not available, English will be used.</p> <p>3 Display of normally invisible service parameters.</p> <p>5 Settings for drive profiles according to CiA 301. Instead of number of subindices the value of subindex 1 is shown (Only useful with COMBIVERT G6).</p> | <p>2 Set-addressing of parameters when creating a parameter list.</p> <p>4 Display of service parameters with special password protection.</p> |
|---|--|

A change of the parameter language is implemented immediately. No program restart is required.

(⇒ [Set addressing \[▶ 112\]](#))

15.6 KEB Parameterization - Communication

Settings for the communication with the devices.




Fig. 172: Options - KEB Parameterisation - Communication

- | | |
|---|---|
| ① Timeout
③ Close communication channels when application is minimised | ② Connection test each x seconds
④ Assignment of interface / transmission rate. The number of COM interfaces depends on the PC hardware. |
|---|---|

15.7 KEB Parameterization - Parameter lists

Default settings of new opened parameter lists.




Fig. 173: KEB Parameterization - Parameter lists

15.8 KEB Parameterization - Behaviour

Settings for the behaviour of COMBIVIS 6.




Fig. 174: Behaviour

1 Behaviour at error messages

2 Behaviour of the property editor (input window)

3 Available assistants will be directly opened in the project.

(⇒ [Property editor \(input window\) \[▶ 127\]](#))

15.9 Parameterization - Data paths

Data path for the parameter description file (XML-file). Depending on operating mode and firmware for each KEB device one or more parameter description files are necessary. If the file is not available in COMBIVIS no parameters are displayed in the editor. By online update function the database can be actualised automatically.

On the main path the XML-Files of all addressable devices are stored. In addition to the main path, description files can also be stored in other places (e.g. for test firmware etc.). The data path must be achieved here as "Additional directory".




Fig. 175: File paths

- 1 Apply updated files without restarting.

15.10 Options - KEB Scope




Fig. 176: Scope

(⇒ [Scope Basic Settings \[▶ 250\]](#))

15.11 Options - Load and Save

Settings for loading, saving and for the start-window:




Fig. 177: Load_Save

1 Create an automatic backup copy
when saving the project.

2 Create an automatic backup.

3 Display when COMBIVIS is started

The backup is stored as “xxx.backup” and can be made readable again by changing in “xxx.project”.

15.12 Miscellaneous

In default all tabs in the device editor are directed horizontally. Alternatively, the tabs can be directed vertically.




Fig. 178: Miscellaneous_1

- ❶ Arrange tabs horizontally or vertically in the device editor.




Fig. 179: Miscellaneous_2

15.13 KEB Wizards




Fig. 180: Options - KEB Wizards

If the operating mode is changed and the inverter is in the "Operation Enabled" state, the motor can move. This depends on the selected mode and the respective valid parameters.

This behaviour may surprise inexperienced users.

By selecting the radio button, a warning is displayed in the Testrun Wizard before the operating mode is changed via the drop-down selection. If the user cancels here, the operating mode is not changed.

16 Screen layout

Reset screen layout:

All changes of the screen layout can be reset:

Menu bar: "Window" → "Reset Window Layout"




Fig. 181: Reset window layout to default

Change screen layout manually:

The tabs (editor window, scope, parameter list...) can be displayed one below the other or side by side:

Activate the tab group to be dragged → select menu "Window" → "New horizontal or vertical tab group".




Fig. 182: Screen layout new vertical tab group

Alternative:

Select the tab to be dragged with the left mouse button, hold it down and drag it to the centre of the screen. An orientation cross appears. Depending on the selection, the tab is arranged at the top, bottom, right or left (area with blue background).




Fig. 183: Orientation cross_1

The shifted window can be superimposed on the actual COMBIVIS window. In multi-screen mode, you can use it to drag the window to another screen. The window is placed anywhere on the screen with the mouse pointer. To reset it, place it on the middle field in the orientation cross.




Fig. 184: Orientation cross_2

Tabs below or next to each other can be dragged to the place next to another tab. So these tabs are in a row.

The same behaviour when dragging the tab to the center of the orientation cross (see above).




Fig. 185: Orientation cross _3

17 Start-up Assistant (Wizards)

Start-up wizards are tools for an easy creating of parameter lists and parameter adjustments.

Two procedures of start-up wizards can be found:

Online start-up wizards – all adjustments are done directly in the device.

Offline start-up wizards – creates a parameter list, which can be stored or directly downloaded to the device.

Only the compatible wizards will be offered in the project.

For “generation 5” drives (type F5, B6, G6) online and offline wizards can be found.

For “generation 6” drives (type F6, H6, P6, S6, T6) an online wizard is offered. It can be used offline partly. At next connection to the drive the values will be transferred to the drive.

17.1 Online Start-Up Wizard

Online wizards need a connected device because all adjustments are done directly in the device parameters.

17.1.1 Online Start-Up Wizard COMBIVERT F6/ H6/ S6/ P6/ T6.

For the new “generation 6” drive controller a step by step start-up online wizard is implemented. It can be used also offline but then not all features can be handled.

The idea is to start-up the drive in simple cases without having knowledge of the programming structure of the drive.

Depending on the functions available in the device type, parts of the wizard are masked.

For each function card there is a tab “expert settings”. There, the parameters belonging to the respective function are listed directly and allow advanced settings. The normal user is passed over it and normally does not need to set anything.





Fig. 186: Start-Up Wizard online

① Select Wizard

② Step by step guidance forward and backward

③ Expert mode with the relevant parameters

Please also watch the tutorial on YouTube:



17.1.1.1 Basic Settings

- Backup/data backup / read back the stored values. The backup is saved with the project.
- A saved backup file can be exported as parameter list to the navigator and from there exported out of the project.
- Load factory setting
- In the process, CV loses the connection with the device for a short time, but this is automatically re-established.
- Process data disabling, save bus settings, reconnect with former adjustments:
- With active process data, the controller can overwrite certain parameters again and thus make a manual adjustment impossible. This function only works with COMBIVERT F6-K, S6-K and H6.
- Device clock

The clock has no runtime reserve, also no connection to the clock of the safety module (option).




Fig. 187: Start-up Assistant (Wizards) Basic settings

1 Create backup.

2 Load backup to the device

3	Delete backup, download to the device or export to the navigator as parameter list.	4	Set device to default.
5	Disable process data (only F6-K, S6-K, and H6).	6	Set clock, manually or by PC clock.

17.1.1.2 Wizard Motor

Characteristics:

- Can be used for synchronous and asynchronous 3-phase motors.
- KEB synchronous motor data can be chosen directly by part no.
- Motor data can be adjusted manually, and the data can be stored in a motor data base (after identification in window "Identification").
- Motor data is displayed similarly to a name plate and the parameter values are prepared accordingly.
- In addition to the parameter values, calculated values are also displayed, e.g. the rated power or the maximum torque.
- Motor data can be loaded from the user database.
- User data base can be loaded or exported.
- Motor brake and sine-wave filter data can be entered optionally.
- The braking transistor can be activated.
- The temperature sensor type and error response can be set.

Leaving of the window "motor" activates the motor data in the drive controller.

17.1.1.2.1 Motor data

The basic motor data is specified on this tab. Motor data can be taken from the following sources:

- KEB motor database
- User database
- Manual input




Fig. 188: Wizard - Motor - Motor data

17.1.1.2.2 Feedback mode

If the regenerative energy is not fed back into the grid, a braking transistor can be activated on this register page. The energy is then thermally converted with a connected braking resistor.




Fig. 189: Wizard - Motor - Generator mode

17.1.1.2.3 Brake control

The control of a brake can be activated and set on this tab.




Fig. 190: Wizard - Motor - Brake control

17.1.1.2.4 Sine filter

This wizard can be used to select sine filter combinations from a drop-down menu. The "Preview" button can be used to display the parameter values of the selected data.


Parameter	Value
dr49: sinus filter ind. UV	0.368 mH
dr50: sinus filter cap. UV high res. [μF]	12.000
dr52: sinus filter cap. UV [μF]	12.0
dr51: sinus filter resistance UV	0.0120 Ω
dr53: sinus filt. min. switch. freq.	8.00 kHz
is10: switching frequency	8 kHz
is22: Basic Tp	0: 62.5us / 16kHz, 8kHz, 4kHz, 2kHz + 8 x TpBase
is15: temp dep derating	0: off
is16: min. derating frequency	no derating
dr99: motordata control	0: store motordata,init reg

Ok

Fig. 191: Wizard - Motor - Sine filter - Preview

Click on  to transfer the parameter values to the "Parameters" selection. Alternatively, the data can also be entered manually in the parameters.

NOTICE! Changing the Basic TP has a background effect on the cycle times, the switching frequency and the offline scope (see device instructions).



The sine filter settings are only needed if you use a sine filter. Otherwise leave the setting at their default values. Some of the settings depend on the way the filter is connected (Y or Δ). Please refer to the manual for detailed information.

Filter options

Choke size:

Capacitor Block 1:

Capacitor Block 2: (optional)

Preview

Parameter

Inductance UV:	0.001 mH
Resistance UV:	0 Ω
Capacitance UV:	0 μF
Min switching frequency:	0 kHz
Basic Tp:	0
Software Reset:	---

Fig. 192: Wizard - Motor - Sine filter

17.1.1.2.5 Expert settings

The page shows a selection of the parameters influenced by the motor wizard.




Fig. 193: Wizard - Motor - Expert settings

17.1.1.3 Feedback mode

- Adjustment of the operating mode and feedback mode (v/f mode, closed loop, encoder less closed loop)
- Adjustment of the encoder interface, encoder type and values
- At encoders with electronic nameplate, this can be read out (KEB motors)
- At synchronous motors, the v/f mode is not available).




Fig. 194: Start-up Assistant (Wizards) Feedback mode

17.1.1.4 Controller

- Adjustments for speed controller and position controller.
- Pre adjustments depending on the inertia of motor and machine.




Fig. 195: Start-up Assistant (Wizards) Controller

17.1.1.5 Wizard Protection / Warnings

17.1.1.5.1 Status word setting

Statusword settings				Warning level settings		Application specific warning settings		Fault reaction ramp mode settings		Fault reaction ramp value settings		Expert settings									
<i>Please select which warnings should be reflected in the Statusword (Bit 7):</i>																					
Warning ID	Warning name	Show in status word	Status	Information																	
OL	Overload	<input checked="" type="checkbox"/>	No warning	Protects the drive controller against a permanent overload.																	
OL2	Overload 2	<input checked="" type="checkbox"/>	No warning	Protects the drive controller against overloads in a lower frequency range.																	
OH	Drive controller overheat	<input checked="" type="checkbox"/>	No warning	Monitors the heat sink temperature of the drive controller.																	
OHT	Internal overheat	<input checked="" type="checkbox"/>	No warning	Monitors the internal temperature of the drive controller.																	
dOH	Motor overheat	<input checked="" type="checkbox"/>	Warning active	Monitors the temperature of the motor.																	
OH2	Overheat 2	<input checked="" type="checkbox"/>	No warning	Protects the motor against thermal destructions caused by high currents.																	
watchdog	Watchdog	<input checked="" type="checkbox"/>	No warning	Monitors the time between process data telegrams to detect communication interruptions.																	
ProgErr	Programmable external error	<input type="checkbox"/>	No warning	Triggers a reaction if one of the configured digital inputs is set.																	
OS	Overspeed	<input type="checkbox"/>	No warning	Monitors the speed of the drive.																	
MaxAccDec	Maximum acceleration	<input type="checkbox"/>	No warning	Triggers a reaction if the current speed exceeds the configured level.																	
SwSwitch	Software limit switch	<input type="checkbox"/>	No warning	Monitors the acceleration and deceleration in all modes of operation.																	
SpeedDiff	Speed difference	<input type="checkbox"/>	No warning	Triggers a reaction if the configured level is exceeded.																	
ENC-A	Encoder A	<input type="checkbox"/>	Warning active	Triggers a reaction if the encoder detects an error.																	
ENC-B	Encoder B	<input type="checkbox"/>	No warning	If the drive is set to a mode that requires an encoder errors will always lead a fault-reaction, regardless of this setting.																	
Uph	Internal phase failure	<input type="checkbox"/>	No warning	Triggers a reaction if the encoder detects an error.																	
limit switch	Hardware limit switch	<input type="checkbox"/>	No warning	If the drive is set to a mode that requires an encoder errors will always lead a fault-reaction, regardless of this setting.																	

Fig. 196: Wizard - Protection / Warnings - Statusword settings

17.1.1.5.2 Setting the warning levels

Setting the warning level and corresponding behaviour when triggered.




Fig. 197: Start-up Assistant (Wizards) Protection / Warnings

If you leave the mouse pointer on the corresponding element, the associated parameter with name and value is displayed in the tooltip.




Fig. 198: Warning Overload OL warning level




Fig. 199: Warning - Overload OL stop mode




Fig. 200: Warning - Overload counter

17.1.1.5.3 Application specific warning settings




Fig. 201: Wizard - Protection / Warnings - Application specific warning settings

17.1.1.5.4 Fault reaction ramp mode settings




Fig. 202: Wizard - Protection / Warnings - Fault reaction ramp mode settings

17.1.1.5.5 Fault reaction ramp value settings




Fig. 203: Wizard - Protection / Warnings - Fault reaction ramp value settings

17.1.1.5.6 Expert settings




Fig. 204: Wizard - Protection / Warnings - Expert settings

17.1.1.6 Identification

- Guided motor data identification/measurement.
- Must not be done at KEB motors selected by KEB motor database.
- Identified motor data can be stored in user motor database.




Fig. 205: Start-up Assistant (Wizards) Identification

17.1.1.7 Operating modes

Operating modes

Settings for the available operating modes according to CiA 402 e.g.: ramp mode, s-curves, sped limits, position profiles, homing methods etc.




Fig. 206: Start-up Assistant (Wizards) Operating mode1




Fig. 207: Start-up Assistant (Wizards) Operating mode2

17.1.1.8 Wizard Fieldbus

- Selection of bus system
- Process data size
- Process data adjustments
- Bus diagnosis
- Create and export of device description files
- Save and handle of self-created mappings




Fig. 208: Start-up Assistant (Wizards) Fieldbus

17.1.1.8.1 Selection of the bus system

Depending on the hardware of the device the bus type can be selected.




Fig. 209: Wizard - Fieldbus - Select fieldbus type

17.1.1.8.1.1 CAN Cross

If the wizard recognises that a device is CAN Cross-capable, then

- the selection in the drop-down field is extended accordingly.
- the parameter value of fb73 is displayed in the window.
- the expert settings are expanded to include the visualised parameters for CAN Cross functionality.

This looks as follows for "CANopen":




Fig. 210: Wizard - Fieldbus - CAN Cross

The parameters required to set the Can Cross functionality are now visualised there and can be set directly. This includes the 'Cob-Id' belonging to the respective send and receive PDO with the sub-parameters 'RTR' and 'TPDO'/'RPDO', as well as the 'Transmission type' and the 'CAN-ID'.

For 'EtherCAT + CAN Cross' and simultaneously for 'Profinet + CAN Cross' it then looks as follows:




Fig. 211: Wizard - Fieldbus - EtherCAT CAN Cross

The send and receive PDOs for the CAN cross functionality are displayed below the (EtherCAT/Profinet) send and receive PDOs.

The relevant parameters are summarised in the expert settings:




Fig. 212: Wizard - Fieldbus - CAN Cross expert setting

17.1.1.8.2 Process data size

At EtherCAT and Profinet the process data size can be chosen (depending on firmware version).




Fig. 213: Start-up Assistant (Wizards) process data size



If the selected bus system or the process data size is changed, an error is triggered in the drive (ru01 = Error! fieldbus type changed). The change must be confirmed by pressing the "run software reset" button or a power-on reset of the device. Only then will the change be accepted!




Fig. 214: Start-up Assistant (Wizards)

17.1.1.8.3 Assignment of process data

The wizard offers a standard process data assignment:

"Stored Mappings" → "KEB database" → "Load" → select device type. The process data will be loaded and activated.




Fig. 215: Start-up Assistant Wizard _load

A customer specific assignment can be stored in the user data base and can be re-loaded.

"Stored Mappings" → "User database" → "Load/Save"




Fig. 216: Start-up Assistant (Wizards) Stored_Mappings

The user database is saved in the file <Installationsordner>\KEB\PdTemplate-
sUser.xml and can be transferred to other PCs by copying the file.

17.1.1.8.4 Manual assignment

The process data must be disabled!

The right-hand window lists the parameters available for process data.

These can be copied with the mouse to the Transmit PDO field or the Receive PDO field using drag & drop. The data length is taken over correctly.

Parameters can be deleted by moving them to the waste bin at the bottom left using the mouse or by selecting them and pressing the "Remove" button.

"Read-only parameters" cannot be dragged into the Receive PDO field.

The number of transferred objects can be restricted. This allows certain objects to be excluded from data exchange from right to left.




Fig. 217: Wizard - Fieldbus - Process data mapping

- | | |
|--|---|
| ① Transmit PDOs (Drive controller
-> PLC)

③ Parameter available for process
data

⑤ Enable process data | ② Receive PDOs (PLC -> Drive con-
troller)

④ Number of active PDOs

⑥ Waste bin for deleting PDOs |
|--|---|

17.1.1.8.5 Device description file

With the wizard, the device description file can be generated depending on the selected bus type. At CAN and EtherCAT, this contains the current process data assignment.

EtherCAT EDS:

"EtherCAT" → "Export device description file".




Fig. 218: Start-up Assistant (Wizards) Export device description

If KEB COMBICONTROL is available, descriptions can be loaded directly to it:




Fig. 219: Start-up Assistant (Wizards) Install to device-repository

For an EtherCAT PLC this can be generated and saved:




Fig. 220: Start-up Assistant (Wizards) Save as EtherCAT-XML-File

The FSOE process data description can additionally be selected for the KEB Safety Modules: (=> manual of the respective device).




Fig. 221: Start-up Assistant (Wizards) Safety Module 1




Fig. 222: Start-up Assistant (Wizards) Safety Module 2

PROFINET

The device description file GSDML can be found in the KEB document database in the "Software" area under the part number of the COMBIVERT® or keyword "PROFINET":




Fig. 223: Start-up Assistant (Wizards) Software

CAN EDS:

In the CAN process data wizard, an EDS device description file can be created and saved:




Fig. 224: Start-up Assistant (Wizards) CAN EDS

Ethernet IP EDS:

The EDS device description file can be found in the KEB document database in the "Software" area under the part number of the COMBIVERT or the term "Ethernet":




Fig. 225: Start-up Assistant (Wizards) ESD

Powerlink xdd:

In the Powerlink process data wizard, the xdd device description file can be created and saved:




Fig. 226: Wizard - Fieldbus - Create Powerlink xdd

EtherCAT + CAN Cross and PROFINET + CAN Cross:

With PROFINET, an EDS device description file can be generated and saved for CAN. With EtherCAT, additional files can also be created and saved as described above.




Fig. 227: Wizard - Fieldbus - CAN Cross

17.1.1.9 Wizard Test run

The Test run wizard opens in a separate window.

It enables a motor run or positioning step from the PC without having a separate controller. The status of the status machine is also displayed graphically.

The Test run wizard opens in a separate window.

CAUTION

Test run wizard has no watchdog function

If communication is lost due to cable interruption or program crash, the drive continues to run with its last setpoints!

- Always create a second possibility to stop the drive. This can be done by a separate switch for controller enable, STO or mains voltage.

NOTICE



Motor runs in the "Operation Enabled" state when the operating mode is changed!

- ✓ This behaviour is desired, but can surprise users.
- a) A warning message can be activated under Tools > Options > KEB Assistant.
- b) The user then has the option of cancelling.

The test run wizard can be called up by clicking on the "Start test run wizard" button. It is then stored in the Navigator for the corresponding device under the wizards.




Fig. 228: Start-up wizard Test run starts

The test run can also be added via the context menu using the right mouse button.




Fig. 229: Add test run in the Navigator




Fig. 230: Wizard - Start test run

17.1.1.9.1 State Machine

The view for the state machine can be opened with the field "Status display" in the upper right corner.

Wizard Expert settings

Preconditions for successful running

- Communication
- Digital inputs STO set
- Voltage supply run
- Error state no exception
- Brake open **Brake control bit** If a brake is used, it must be opened.
This is the current brake status in the drive.
- PDO Communication PDOs inactive **Disable PDOs** PDOs override changes made in the wizard and must be disabled.

State display 

Current operation mode: 2: velocity mode

Mode selection: **velocity mode**

Start **Stop**

Current Position: -196496
= -2 rotations and
-65424 increments.
Each rotation equals 65536 increments.

Current target velocity:

Default Velocity: 150 rpm

Target velocity: -20000	0	20000	0 rpm Set target velocity
Target velocity: -20000	0	20000	0 rpm Set target velocity
Target velocity: -20000	0	20000	0 rpm Set target velocity
Target velocity: -20000	0	20000	0 rpm Set target velocity

+ Start velocity test scope




Fig. 231: Wizard - Test run - Open status display

① Click here to open the status display

The state machine graphically displays the state of control word co00 and status word st00. In the control word, each bit can be set individually by clicking on the green dots. The direct buttons below can also be used.




Fig. 232: Start-up wizard Velocity mode

17.1.1.9.2 Velocity Mode

Velocity mode:

- Presetting of 4 or more speeds (see ⑨)
- Operating the control word
- Brake control bit
- Starting a predefined scope recording




Fig. 233: Wizard - Test run - Velocity mode

- | | |
|--|---|
| ❶ Display of the current status, such as STO, error, power supply. | ❷ Switch brake - bit 15 in the control word (parameter co00). |
| ❸ Setting the operating mode (parameter co01). | ❹ Start / Stop - Enable Operation in the Statemachine. |
| ❺ Actual speed | ❻ Current setpoint |
| ❻ Preset target speeds | ❼ Take over target speed in vl20 |
| ❾ + Add / - Remove target speed | ❽ Start preset scope. |

17.1.1.9.3 Profil position mode

The drive can be moved in relative or absolute position profile.

The positioning profile (Profile position mode) is used here:

- Presetting of 3 or more positions
- Operating the control word and status word
- Brake control
- Starting a predefined scope recording
- Set current position to 0 by executing homing method 37




Fig. 234: Wizard - Test run - Profile positioning mode

① Display of the current status, such as STO, error, power supply.
Switching the brake: Bit 15 in the control word (parameter co00).

② Setting the operating mode (parameter co01)

③ Start / Stop - Enable Operation in the Stateemachine

④ Actual speed

⑤ Current position of the drive

⑥ Positioning speed for the next profile (parameter ps30)

- | | |
|---|--|
| <p>⑦ If the drive has to stand still when no position is active = enter "0" (parameter v120).</p> <p>⑨ Write predefined target into parameter co19 "Target position" and start positioning.</p> <p>⑪ Predefined target position</p> <p>⑬ Hook: The positioning profile is cancelled and the new target is approached. / No hook: The current positioning profile is ended and the new target is approached.</p> <p>⑮ "-" deletes a target position.</p> | <p>⑧ Move to position 0.</p> <p>⑩ Set the current position to 0. Like homing method 37.</p> <p>⑫ Hook: Relative positioning / No hook: Absolute positioning</p> <p>⑭ "+" adds another target position</p> <p>⑯ Start preset scope.</p> |
|---|--|



With "relative position" and "change target position immediately = off", a positioning profile is generated with each mouse click on the field "Start positioning" and then processed one after the other.

17.1.1.9.4 F5-compatible behaviour

Downward-compatible behaviour is supported in the test wizard. To utilise this, bits 0 and 4 must be set in parameter ud50 [1] option code.

- F5 compatible control word
This is activated via bit 0 = 1.
- F5 compatible setpoint speed
The alternative speed specification is activated via bit 4 = 16).
If this mode is active, the specification via the "Target Velocity" parameter is ignored in all relevant operating modes (in particular Velocity Mode and Posi Mode). Instead, the speed is specified with the parameter ud50 [6].
The setting is made as a percentage of the reference speed ud50 [13] in the range of ±100 %.
The speed is therefore determined using this formula: ud50 [6] / 100% * ud50 [13]

17.1.1.10 Cogging

The cogging compensation function is used to minimise the cogging torque generated by the permanent magnets at low speed. For this purpose, the wizard measures a characteristic curve and saves it in the drive.




Fig. 235: Start-up wizard Cogging

- Only applicable for permanent magnet linear motors or permanent magnet synchronous motors!
- The anticogging measurement should only be carried out when the drive controllers for speed and position are well adjusted!
- The motor must be able to run load-free.
- Depending on the motor size and type, adjustments to the wizard setting may be necessary.

- No values may be changed manually or by the bus system in the drive during the measurement.
- The wizard uses the Profile position mode for the measurement.
- The calibration takes approx. 20 - 30 minutes.
- After the measurement has been completed, the result must be transferred to the drive and the function activated.
- The measurement can be cancelled at any time. As long as the measured values are not transmitted and activated, the drive is not affected.

The **mode "Target reached"** controls the measurement via the positioning profile and ensures that really every measuring position is approached. This mode gives an accurate result, but requires well adjusted speed and positioning controllers.

The **mode "Time based"** controls the measurement via a temporal sequence of measurements, regardless of whether the measurement position has actually been reached or not. The result is somewhat less precise, but it works less problematically because the movement does not have to be so accurate.




Fig. 236: Start-up wizard Measuring condition

After the measurement has been completed, the data must be transferred to the drive controller and activated:




Fig. 237: Start-up wizard Activate selection

The measurement results are displayed in the "Graphs and data" editor.

The results can be saved in a separate file and can also be called up again.




Fig. 238: Start-up wizard Graphs and Data

17.1.2 Homing Mode

Set the current position to 0.

In many cases, the current mechanical position of the drive must / should represent the zero point. This can be achieved by the following setting:

- Set mode to "homing mode"
- The homing method must be set to "35: on current position" (default). The parameter hm01 is included in the expert settings:




Fig. 239: Start-up wizard Expert settings

- Enable the bit "Start homing" in the Control Word and disable the bit.




Fig. 240: Start-up wizard Homing mode

The other modes cannot be used or only with restrictions by the test run wizard.

17.1.3 Online Start-up Assistant Basis COMBIVERT F5, B6 and G6.

For all COMBIVERT F5, B6 or G6 a small startup wizard is available.




Fig. 241: Online Start-Up Wizard

- | | |
|--|---|
| 1 Adjust control and speed mode | 2 Set factory default (Fr01 = -4) |
| 3 Copy set 0 / subindex 0 to all sets / subindices | 4 Copy all values of one set / subindex to another set / subindex |

17.1.4 Online Start-Up Wizard COMBIVERT F5

17.1.4.1 Calibration of asynchronous motors F5-A/-K and F5-H/-L (ASCL)

A wizard for the calibration process is available for the modes for closed-loop operation of three-phase asynchronous motors with and without encoders. Prerequisite is a device software F5-A/-M/-K from V4.3 or F5-H/-L from V2.3. There is a standard mode and an expert mode. Certain device settings that must be changed for calibration, such as setpoint settings, are saved before starting calibration. The functional description of the calibration procedure can be found in the F5-A application manual (([Document database \[▶ 283\]](#))).

It must be possible to open and close the control release terminal as specified during the calibration process. Switching via software is not possible.

[Open in Device Editor](#)




Fig. 242: Start-Up Assistant F5 B6 G6

- | | |
|---|---|
| 1 Adjust speed mode | 2 Enter motor data |
| 3 Start calibration with automatic procedure. | 4 Display of the current values during calibration. |
| 5 Switch on expert mode | |

With expert mode:




Fig. 243: Start-Up Assistant F5

- | | |
|--|---|
| 1 Open list with manually adjustable parameters. | 2 Full selection of identification options. |
| 3 Adopt best settings. | 4 Manually adaption of filter settings. |
| 5 Expert mode enabled. | |

In the tab "Expert settings" all relevant parameters are available as an online list and can be adjusted manually if required such as the parameter editor:




Fig. 244: Start-Up Wizard Online Wizards Motor ident.

17.1.4.2 Motor Data Identification F5-A/ S/ K and F5-E/ P (SCL)

For driving with PM synchronous motors with and without encoder a wizard for motor data calculation and measurement is available. It works only with F5-A/ S/ K from V4.3 or F5-E /P from V2.3. A standard mode and an expert mode are available. Specific values which are to be changed for measurement (set value...) are saved before and set back after finishing of the measurement. The description of the motor identifying function can be found in the application manual F5-A (([Document database \[► 283\]](#))).

The control release (terminal 16) must be switched open and close while identifying runs. Switching by software is not possible.

[Open in device editor](#)




Fig. 245: Start-Up Assistant SCL_1

- | | |
|--|--|
| 1 Adjust speed mode | 2 Adjust motor data manually. |
| 3 Routing to motor data assistant. | 4 Start identification with automatic procedure. |
| 5 Display of actual measured data or status. | 6 Enable expert mode. |

(⇒ [Motor configurator F5-S \[▶ 195\]](#))

In expert mode, additional useful functions are offered:




Fig. 246: Start-Up Assistant SCL_2

- | | |
|--|---|
| 1 Open list with manually adjustable parameters. | 2 Full selection of identification options. |
| 3 Adopt best adjustments. | 4 Manually adaption of filter settings. |
| 5 Stabilises the start. | 6 Extra menu for rotor position detection. |
| 7 Expert mode enabled. | |

In the tab "Expert settings" all relevant parameters are available as an online list and can be adjusted manually if required such as:

Name	Value
dr26: DSM EMK [Vpk/1000RPM]	64
dr30: DSM stator resistance	25,394 Ω
dr31: DSM inductance	24,82 mH
dr50: mot.prot. min. ls/ld	150 %
dr63: DSM EMK HR[Vpk/1000RPM]	64,24
Model	
cS01: act. source	2: calculated + off
dS18: function mode	2048: off + on
uF15: hardw. curr. lim. mode	0: off
Identification	
dr48: motor identification	0: off + 1000 Hz
dr49: ident. acc/dec time	5,00 s
dr67: current for Ls/Ioff iden	100 %
Fr10: load mot. dependent para.	0: done
uF09: voltage stabilisation	1120: off
uF18: deadtime comp. mode	3: auto. ident
Settings	
cS00: speed control config.	4: speed ctrl (F5-M/S only)
dS02: current decoupling	1: on
dS03: curr./torq. mode	2: off + on + off + off + Mn + together + off
Pn65: special functions	80: OL2 temp.dep + derat lim = OL2
Encoder	
Ec00: encoder 1 interface	19: Resolver Interface
Ec10: encoder 2 interface	2: Incremental Out

Fig. 247: Start-Up Wizard SCL_3

17.1.4.3 Start-Up Assistant F5 with PROFINET

Using the wizard for the process data assignment can be done in a simple manner the PDO assignment. In standard mode, certain parameters of the wizard can be dragged by "drag and drop" from the Device Editor in the appropriate fields. There is an operator firmware version 2.9ff required.




Fig. 248: Start-Up Wizard F5 PROFIBUS 1

- 1 Drag and hold the parameter onto the "Online Wizard" tab with the left mouse button pressed.




Fig. 249: Start-Up Wizard F5 PROFIBUS 2

A change can be done only in condition "Inactive PDO".

In the **Expert mode** the PDO assignment can be done manually by hexadecimal addresses.

(⇒ Offline Start-Up Wizard [▶ 192])

see also

Offline Start-Up Wizard [▶ 192]

17.1.5 Online Start-Up Wizard COMBIVERT G6-L (ASCL) and G6-P (SCL)

Motor Data Identification G6-L (ASCL)

The online start up wizard basically works the same as (⇒ [F5-ASCL \[▶ 186\]](#)). The functional description of the calibration procedure can be found in the G6 application manual (⇒ [Document database \[▶ 283\]](#)).

Motor Data Identification G6-P (SCL)

The online start up wizard basically works the same as (⇒ [F5-SCL \[▶ 186\]](#)).

The functional description of the calibration procedure can be found in the G6 application manual (⇒ [Document database \[▶ 283\]](#)).

17.1.6 Start-Up Wizard COMBIVERT T6.

A separate commissioning assistant will be published for the COMBIVERT T6 during the term of CV 6.6.0. This is only integrated in COMBIVIS studio 6, since the start-up works with the integrated embedded PLC.

The “inverter-specific” parameters can be addressed with the online start-up wizard.

(⇒ [Online Start-Up Wizard COMBIVERT F6/ H6/ S6/ P6/ T6. \[▶ 149\]](#))

17.2 Offline Start-Up Wizard

For an offline Start-up wizard, it is not needed to connect a device.

The result can be loaded directly into a connected device, or a list of data (parameter list or another file) can be created, that can be saved and load into the device later.

17.2.1 Open Start-Up Wizard

If there is a wizard for the device software offered, it will be shown direct in the navigator window.




Fig. 250: Start-Up Wizard Offline Start-up

If it isn't shown because e.g., the software mode has switched, the start-up wizard can be opened manually: Mark device → right mouse key → "Add object" → "Start-up Wizard"




Fig. 251: Start-up Assistant Offline Start-up object

or: Mark device → Toolbar: Icon → "Start-up Assistant"




Fig. 252: Start-up Assistant Offline Start-Up Icon




Fig. 253: Start-up Assistant Offline Start-Up
Give name and "Add"

17.2.2 Offline Start-up Wizard for COMBIVERT F5

17.2.2.1 Motor configurator F5-S

The motor configurator is available in the operating modes for PM servo motors of types F5-S, F5-P, F5-E and G6-P. It creates a parameter list with related motor data based on the KEB synchronous motors or self-defined data. This list can be stored or direct loaded to the device. Currently only synchronous motors are available.

The self-defined motors are stored in a separate file. This can be copied to other PCs:

C:\Program Files\KEB\COMBIVIS_6\KEB\UserMotors.xml

Motor from KEB-database:




Fig. 254: Start-Up Wizard Offline Start-Up F5

1 Reduction of list for design,
voltage, speed, pole pair number

Choose motor, e.g. B1SM000-6200:




Fig. 255: Start-Up Wizard Offline Start-Up F5 Motor

- | | |
|--|------------------------|
| 1 Adjust design of cooling type. | 2 Adjust encoder type. |
| 3 Pre-adjustment of speed controller: 2 = strong, 15 = weak (based on motor inertia) | 4 Forward |
| 5 Back | |

Define your own synchronous motor:




Fig. 256: Define_synchronous motor

1 Put motor data into motor lis.

2 Use motor data directly for parameterisation.

In Overview it can be chosen if the parameter would be load directly into the device or if a parameter list shall be created.

17.2.2.2 Process data adjustment

Process data adjustment F5-CAN Bus Operator

The process data assignment for the F5-CAN operator can be created and thus an XML file. However, a download setting in the device is not possible.

The function of the assistant is like the assistant of G6.

Process data adjustment F5 EtherCAT operator

The process data assignment for the F5-CAN operator can be created and thus an EDS file. However, a download setting in the device is not possible.

The function of the assistant is like the assistant of G6.

Process data adjustment of F5 PROFINET Operator

Using the wizard for the process data assignment can be done in a simple manner the PDO assignment. In standard mode, certain parameters of the wizard can be dragged by "drag and drop" from the Device Editor in the appropriate fields. There is an operator firmware version 2.9ff required.

By "**Upload**" the adjustments of the device will be transmitted to the assistant and displayed.

By "**Download**" the adjustments of the assistant can be transmitted to the connected device.




Fig. 257: Start-Up Assistant process data assignment F5 PROFINET Operator

- | | |
|-------------------------------------|--|
| 1 Assistant for PROFINET Mapping | 2 Pd-Mapping with "Drag&Drop" |
| 3 Enable expert mode. | 4 Own data sets can be created, read or deleted. |
| 5 Load mapping from or into device. | |

In the **Expert mode** the PDO assignment can be done manually by hexadecimal addresses.




Fig. 258: Start-Up Assistant expert mode

A parameter list with the relevant parameters can be generated under the "Overview" wizard.

see also

- ▀ Offline Start-Up wizard overview [▶ 205]
- ▀ Offline Start-Up Wizard for COMBIVERT G6 [▶ 198]

17.2.3 Offline Start-Up Wizard for COMBIVERT G6

see also

- ▀ Motor configurator F5-S [▶ 195]

17.2.3.1 Motor data configurator G6-P

The motor data configurator G6 works in the same way as the COMBIVERT F5-S.
 (⇒ [Motor configurator F5-S \[▶ 195\]](#))

17.2.3.2 Process data adjustment CAN version

Using the wizard for the process data assignment can be done in a simple manner the PDO assignment. In standard mode, certain parameters of the wizard can be dragged by "drag and drop" from the Device Editor in the appropriate fields.

By "**Upload**" the adjustments of the device will be transmitted to the assistant and displayed.

By "**Download**" the adjustments of the assistant can be transmitted to the connected device. An EDS file suitable for the device and the PDO assignment is generated with "**CAN EDS**".




Fig. 259: Start-Up Assistant process data assignment CAN version

A previously saved setting or the KEB default setting can be loaded into the wizard with "Configuration database". The KEB default setting loads the assignment for the CiA 402 profile into the wizard. With "Save" you can save your own assignment.




Fig. 260: Start-Up Assistant process data assignment CAN version database

In **expert mode**, the PDO assignment can also be done manually with the hexa-decimal addresses.




Fig. 261: Start-Up Assistant process data assignment CAN version PDO 1




Fig. 262: Start-Up Assistant process data assignment CAN version PDO 2

A parameter list with the relevant parameters can be generated under the Assistant Overview.

Process data assignment EtherCAT version

The PD assignment can be made in a simple way with the process data assignment wizard. Certain parameters can be dragged and dropped from the device editor into the corresponding fields of the wizard.




Fig. 263: Start-Up Assistant process data assignment EtherCAT version

1 View Assistant for EtherCAT Mapping

2 Pd-Mapping with "Drag&Drop"

3 Load mapping from or into device.

4 Own data sets can be created, read or deleted.

- The current settings of the connected device are transferred to the assistant with "Upload".
- The wizard setting is transferred to the connected device with "Download".
- XML or ESI files can be created which are corresponding to the device and the PD assignment with "Device Descriptions".




Fig. 264: Start-Up Wizard EtherCAT Export




Fig. 265: Start-Up Wizard EtherCAT Export files

- | | |
|-------------------------|--|
| 1 Create XML-File | 2 Create ESI-File |
| 3 Created MDP-File | 4 Install in device memory (only with COMBIVIS studio 6) |
| 5 Save as external file | |

Detailed setting of the Pd mapping is possible under "PdIn Details" and "PdOut Details".




Fig. 266: Start-Up Assistant EtherCAT PdIn Details

17.2.4 Offline Start-Up wizard COMBIVERT F6/ H6/ S6/ P6/ T6.

There are no Offline wizard for COMBIVERT F6 /H6/ S6/ P6/ T6. The Online wizard can also be used offline to a limited extent.

17.2.5 Offline Start-Up wizard overview




Fig. 267: Start-up wizard overview

- | | |
|---|---|
| <ol style="list-style-type: none"> 1 Select which parameters of which wizard shall be included into the list. 3 Creates and exports parameter list with all selected wizards. | <ol style="list-style-type: none"> 2 Load the parameters of the selected wizards into the device. 4 Generates parameter list with all selected wizards. |
|---|---|

18 Parameter lists

18.1 Properties

- Parameter lists can be attached to projects or to devices
- Parameters of different devices can be stored in one list and can be uploaded or downloaded in parallel
- Online and offline data will be indicated in the list at the same time
- Direct or indirect set addressing or addressing according to CiA 301 of the parameters
- “Drag and drop function” for parameters from the device editor
- Direct shifting/copying of parameters between editor and parameter list
- Attached parameter lists will be saved with the project
- Export / import of “.dw5” and “.wr5” lists (=COMBIVIS 5)
- Printer functions
- Parameters can get user-defined names
- Parameter lists can be exported individually in COMBIVIS 6 or COMBIVIS 5 format
- Parameter lists can be compared with actual device adjustments or with other parameter lists
- Online and offline values can be compared directly
- Upload or download history
- Export as recipe directly to the COMBIVERT
- Export as EtherCAT CoE startup command file

If only an existing parameter list may be loaded to the KEB COMBIVERT, the function “Download parameter list“ on the start page can be used.

(⇒ [Download of a parameter list \[▶ 97\]](#))

18.2 Open a blank list

Attach a parameter list to a device or project: Mark device or project → in tool bar click on icon "Add parameter list" → give new list a name → "Add"




Fig. 268: Open a _blank list

or:

Mark device in the navigator with right mouse key → “Add parameter list“.




Fig. 269: Add parameter list

Choose a name for the list and “Add”




Fig. 270: Give list_a name

Alternative:

Right-mouse-key → choose "Add Object" → "KEB Parameter list..." → give list a name → "Add"

or:

In tool bar click on icon → "KEB parameter list..." → give list a name → "Add".




Fig. 271: Add parameter list_object




Fig. 272: Give list_a name

18.3 Open list with marked parameters

When some parameters are marked, a new parameter list can be opened by context menu: "right mouse key" → "Create parameter list from selection".

With key "shift" and "Ctrl" several parameters in different groups can be marked at the same time. But all used groups must be opened before marking the parameters.




Fig. 273: Create parameter list from selection

18.4 Open existing list

Parameter lists in "cvxpl" = COMBIVIS 6 format / "dw5" = COMBIVIS 5 format and work lists in "wr5" = COMBIVIS 5 format can be opened.

Parameter lists can be opened at an empty project. The matching device will be added automatically in offline mode.

Attach a parameter list to a device or project: Mark device or project in the navigator → in tool bar click on icon "Add parameter list" → Set check mark at "Import parameter list" → select file → "open" → "Add"




Fig. 274: Open Icon existing list

or:

Click with right mouse key on device → "Add new parameter list".




Fig. 275: Add parameter list

Click on "Import parameter list from file" → navigate to the location → select file:




Fig. 276: Import_file




Fig. 277: Select_file

Next step:

The parameter list is appended to the device at which the dialog was opened. But it can also be chosen whether it is hung on another device in the project or on a virtual device, which has the same type as the one with which the list was created earlier.




Fig. 278: Parameter list_device

1 Type and Firmware version of origin device / parameter list.

2 New device: a new device with matching type and will be add to the project (offline). Assign to existing device: parameter list will be added to a device of the project. No check of compatibility.

3 Selection of the device to which the list is to be assigned. The Firmware ID (Config-ID) is compared between list and device: orange=different.

If there are parameters of several devices in the list (only at .cvxp lists), it can be chosen which device of the list will match which device in the project.

The open parameter list is displayed in the editor.

Fig. 279: Open Icon existing list

Open parameter list without open project:

A stored parameter list can be opened directly from Windows Explorer by double click or with button “Open parameter list” on COMBIVIS start page. A temporary project will be created in background.




Fig. 280: Open parameter list

18.5 Create complete list

Open choice box by click with right mouse key on the respective device → Choose “Create complete list” → A parameter list with all device parameters will be created.




Fig. 281: Create complete list



This complete list is filled in column “offline” with COMBIVIS-default values and does not include yet the actual values of the device. For data storage it is essential to take an upload from the device before saving.

18.6 Layout of parameter list

1	2	3	4	5
Fading out description	Area for notes	Origin Config-ID of the parameters	Time stamp of modification, Upload or Download	Basis Config-ID of devices in this parameter list

Fig. 282: Parameter list_Editor

1 Fading out description	2 Area for notes
3 Origin Config-ID of the parameters	4 Time stamp of modification, Upload or Download
5 Basis Config-ID of devices in this parameter list	

1	2	3	4	5	6	7	8	9	10	11	12	13	14
Parameter	Dref	Device	Address/Index	Subindex	Set	R/W	Id/Tat	Name	Userdefined Name	Offline value	Online value	Notes area	Comment

Fig. 283: Layout_parameter list

1 Line number	2 Device reference
3 Reference of device: not shown in default adjustment.	4 Parameter address (hex)
5 Subindex address	6 Set address
7 Write / read permission	8 Parameter ID
9 Parameter name	10 User-defined name of parameter, changeable, not shown in default adjustment.
11 Parameter value (offline)	12 Actual parameter value in device (online)
13 Notes area	14 Online-indicator

In the subindex and set column is only one value shown, depending on the valid addressing mode for this parameter.

see also

KEB Parameterization - Parameter lists [▶ 140]

18.6.1 Display of columns in the parameter list:

The columns which may be shown can be chosen by pulling up and close with mouse or: “right mouse key” → “columns” → “set hook”.




Fig. 284: Parameter lists_columns

The columns "Device name" and "User-defined name" are switched off in the factory setting.

18.6.2 Display grid lines:

The grid lines can be activated by: "right mouse key" → "Advanced" → "Display grid lines".




Fig. 285: Display grid lines

18.7 Self-created parameter list

Open blank list ((\Rightarrow Open a blank list [▶ 206])) → mark and copy the parameter in the device editor → insert into the parameter list. Or: copy with Ctrl+C and paste with Ctrl+V.




Fig. 286: Self-created parameter list 1




Fig. 287: Self-created parameter list 2

“Copy” command: the selected parameters are copied in the clipboard.

“Copy (extended)” command: the selected parameters plus the underlying subindices or set programmable parameters are copied in the clipboard.

Alternatively:




Fig. 288: Parameter list alternative

Place device editor and parameter list window beside each other (([Screen layout \[▶ 146\]](#)) → mark the parameter in the device editor with left mouse key → hold the key → pull the parameter into the parameter list (Drag&Drop).

18.8 Insert an empty line

To insert an empty line “right mouse key” → “Insert empty line“.




Fig. 289: Parameter list Insert empty line

Empty lines have no influence. They are used only for structuring.

Comments can also be inserted in empty lines.

18.9 Transfer pause during download

A transfer pause stops the download of the parameter list to the device in this line.

A pause can be inserted for an adjustable time or a pause can be inserted until an "OK" command is entered. The process is defined by a number in the offline value field.




Fig. 290: Insert parameter list pause

18.9.1 Transfer pause during download to device:

Offline value "minus xx milliseconds"

The time is counted down. The remark text will be shown. After expiration the download is continued automatically, e.g. -2000 ms = 2 sec. wait.




Fig. 291: Parameter list waiting time

18.9.2 User input (confirmation):

Offline value: (+) xx ms: Unrestricted pause and display of the remark text, continue after "OK".




Fig. 292: Parameter list waiting time (confirmation)

18.10 Changing of device reference

The device reference shows from or to which device the parameter value is read or written during upload or download.

A change can be made by "double-clicking with left mouse button" on the DRef-number (device reference). Changing multiple GRef. at the same time can be affected by:

Marking of the corresponding lines in the column "GRef" → "right mouse key" → "Edit Device-Reference" → choose new device reference → "OK".




Fig. 293: Parameter lists changing of device reference

18.11 Upload from device into parameter list

Definition: with "Upload" is meant the reading of data from the KEB device into COMBIVIS.

WARNING



Unexpected drive movement

Open the control release or the STO inputs before upload, because at upload some pointer can be changed. Especially when values are written by bus system at the same time an unexpected moving of the drive can occur.

Carrying out the upload into an opened parameter list:

- Click on icon in the tool bar, or:
- Click right mouse key in the parameter window, choose "Upload list", or:
- Tap key "F5"

and answer the following questions with "Yes".

The column "Offline value" will become overwritten with the values (online values) which are adjusted in the device.




Fig. 294: Parameter lists Upload of the list



Be sure that the device reference in the list matches the target device's reference. Otherwise adapt the reference of the list (⇒ [Changing of device reference \[▶ 222\]](#)).

18.12 Parameter Download

Definition: with "Download" is meant the transfer of data from COMBIVIS to the KEB device.

WARNING



Uncontrolled drive movement

Open the terminal control release or the STO inputs before download of parameter list into the device. Because some parameters can be written only at open control release terminal. And an unexpected moving of the drive can occur.

If only one existing parameter list is to be loaded into a KEB COMBIVERT, the function "Download of a parameter list" can be used on the start page ((⇒ [Download of a parameter list \[▶ 97\]](#))).

Carrying out the download of an opened parameter list:

- Click on icon in the tool bar, or:
- Click right mouse key in the parameter window, choose "Download List" or:
- Tap key "F4" and answer the following questions with "Yes".

The values, which are adjusted in the device, will become overwritten with the values of the column "Offline Values". Only the writeable parameters which are in the list will get overwritten. All the rest will remain unaffected.




Fig. 295: Parameter lists Download of the lists



Be sure that the device reference in the list matches the target device's reference. Otherwise adapt the reference of the list (([⇒ Changing of device reference \[▶ 222\]](#))).

18.12.1 Parameter download from a parameter list to several devices:

Parallel up/download from/to several devices (here: DRef 0 and 1) from a list is possible. Each parameter is dedicated to one device. Therefor the suitable target-Config-IDs must be registered. Missing Config-IDs will be added at up/download optionally.




Fig. 296: Parameter lists Download parameter list

Parameters can be excluded from downloading if they are set in the R/W column to "Read only".




Fig. 297: Parameter lists Exclude Download

18.13 Renaming parameter list

Double-click slowly in the navigator on parameter list's name and rename. Confirm with "Enter".




Fig. 298: Renaming parameter list

18.14 Comparing parameter lists directly

Online and offline values can be compared in a parameter list directly by context menu: Right mouse key → “Advanced” → “Enable quick-compare”

In column “Online value”:

- Green: Online / offline values equal
- Red: Online / offline values unequal
- Yellow: Parameter not existing

#		Offline value	Online value
0	source	0: analog REF	0: analog REF
1	on source	2: FOR/REV, 0-lim.	7: reference, no LS
2	on setting	0: low speed	0: low speed

Fig. 299: Parameter lists Extended Quick-compare



If the parameter list is designed with indirect set pointer, all parameters in all sets will be compared only with 1 set (the set to which the set pointer Fr09 is adjusted). For an expedient comparing use direct set or CiA 301 addressing for the parameter list ((⇒ [Parameter backup \[▶ 231\]](#))).

For parameters whose values are displayed online (in the device) by pointer setting (e.g. Ud16, Ud22, In24 ...), the value listed in the offline list by different pointer settings is always compared online with the same value designated by the pointer; e.g. at COMBIVERT F5, B6, G6: Ud16...).

Example:

Ud15 (CP-selector) is the pointer for Ud16 (CP-Address). In Ud15 one of 36 possible parameters and in Ud16 the related (application) parameter address can be chosen. Ud16 contains the parameter and Ud15 the place in the CP menu where it displays its value. In a data saving list all 36 Ud15 and Ud16 must be listed, but online, in the device. Ud15 shows every time the same value. That gives at comparing once an equal and 35 times an unequal value.


#	DRef	Addre...	Set	R/W	IdTxt	Name	Offline value	Online value	Comm
549									
550	0	0x0802	I	RW	Ud02	control type	4: F5-M / 4000 rpm	4: F5-M / 4000 rpm	
551	0	0x0809	I	RW	Ud09	drive mode control	0: dr. mode ref.val.(sy.4...	0: dr. mode ... LS => RUN	
552	0	0x080F	I	WA	Ud15	cp selector	1	1	
553	0	0x0810	I	RW	Ud16	cp address	0209h	0209h	
554	0	0x0811	I	RW	Ud17	cp set norm	1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard	
555	0	0x080F	I	WA	Ud15	cp selector	2	1	
556	0	0x0810	I	RW	Ud16	cp address	0201h	0209h	
557	0	0x0811	I	RW	Ud17	cp set norm	1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard	
558	0	0x080F	I	WA	Ud15	cp selector	3	1	
559	0	0x0810	I	RW	Ud16	cp address	0200h	0209h	
560	0	0x0811	I	RW	Ud17	cp set norm	1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard	
561	0	0x080F	I	WA	Ud15	cp selector	4	1	
562	0	0x0810	I	RW	Ud16	cp address	020Fh	0209h	
563	0	0x0811	I	RW	Ud17	cp set norm	1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard	
564	0	0x080F	I	WA	Ud15	cp selector	5	1	
565	0	0x0810	I	RW	Ud16	cp address	0211h	0204h	

Fig. 300: Parameter lists Quick-compare CP Parameters

18.15 Comparing parameter lists

A parameter list can be compared with an actual device adjustment or with the offline values of another parameter list:

Find by context menu - right mouse key → “Compare parameter list”



The screenshot shows a software window titled "Parameter_list_test [axis_1_F5]" with a toolbar at the top. Below the toolbar is a "Description" section. The main area is titled "Parameters" and contains a table with rows numbered 549 to 565. A context menu is open over row 554, specifically over the "Name" column. The menu items are: "File", "Download list" (F4), "Upload list" (F5), "Compare list" (highlighted with a red box), "Insert empty line" (F7), "Insert pause" (F8), "Edit Device-Reference", and "Watch displayed parameters" (F9). The "Compare list" item is the fourth item in the list.

#	DRef	Addre...	Set	R/W	IdTxt	Name	Offline value	Online val
549								
550	0	0x0802					4: F5-M / 4000 rpm	4: F5-M / 4000 rpm
551	0	0x0809					0: dr. mode ref.val.(sy.4...	0: dr. mode ... LS => RUN
552	0	0x080F					1	1
553	0	0x0810					0209h	0209h
554	0	0x0811					1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard
555	0	0x080F					2	1
556	0	0x0810					0201h	0209h
557	0	0x0811					1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard
558	0	0x080F					3	1
559	0	0x0810					0200h	0209h
560	0	0x0811					1: S0 + direct (bit 0-7)...	1: S0 + dire... + standard

Fig. 301: Comparing parameter lists

18.15.1 Online comparison

Comparing of a parameter list's offline values with actual online values in a device generates a new parameter list with the different values of the device. The values of the parameter list are shown also in the offline column in the new difference list.




Fig. 302: Parameter list online comparison

- | | |
|--|---|
| 1 If the device reference of the device and the list are different, this can be ignored. | 2 Unused set pointers and index parameters are not displayed. |
|--|---|

18.15.2 Offline comparison

Comparing of a parameter list's offline values with another offline parameter list creates a new list with the unequal values of the 2nd list.




Fig. 303: Parameter list comparison

- | | |
|--|---|
| 1 If the device reference of the device and the list are different, this can be ignored. | 2 Unused set pointers and index parameters are not displayed. |
|--|---|

18.15.3 Comparison method

There are two different comparison methods:

Line-by-line comparison mode:

The comparison is made line by line without considering the meaning. Blank and pause lines can be faded out. This procedure works when comparing two identical parameter lists at different values. For example a data backup before and after a change.



Only the values in the same lines will be compared, independent which parameter is in this line! Displacements in the list, e.g., by additional parameters will cause in a wrong result!

"Advanced Diff algorithm":

Compares the contents of two parameter lists with a diff. algorithm and presents the differences. This algorithm is able to find both inserted and removed entries.

This mode identifies groups of parameters which are in the same line on both lists. A comparison of differently structured lists (e.g. indirect vs. direct addressing) is not possible! It is adjustable which columns shall be compared.

The result is shown in a separate window. A new parameter list can be generated from this.




Fig. 304: Parameter list comparison method

1 Columns to be compared




Fig. 305: Parameter list comparison method properties

- | | |
|--|--|
| 1 Generates a parameter list with the selected properties. | 2 White: parameters with same adjustments. |
| 3 Yellow: parameters with different adjustments. | 4 Grey: Parameters missing. |
| 5 Green: Parameters only available in this list. | |

18.16 Convert addressing of parameter lists

With this command the addressing mode of a parameter list can be changed. E.g., a set addressed list into a list with subindex addressing/CiA 301 and vice versa. Also, an indirect addressed list can be changed to direct addressing.

Context menu / Right-click in the parameter list: "Convert list"




Fig. 306: Parameter list conversion




Fig. 307: Parameter list conversion

- | | |
|--|------------------------------------|
| 1 Current addressing mode of list | 2 Addressing mode after conversion |
| 3 Mark if ARRAY parameters are in the list | 4 New additional list with result |
| 5 Overwrite the current list | |

18.17 Parameter backup

A parameter backup is useful after the completion of the machine function or before a planned change of the setting. If necessary, the functionality of the axis has then been saved for a later device replacement.

The parameter backup generates a parameter list in the project. This can be exported.

In the wizard for the F6 / H6 / S6 / T6 / P6 there is also the backup function. This generates a backup file, which can be converted to a parameter list in the project ((⇒ [Basic Settings \[► 150\]](#))).

For all KEB COMBIVERT:

Open → "Tools" → "Parameter Saving".




Fig. 308: Parameter lists Tools Parameter backup




Fig. 309: Parameter backup - Lists

- ① Select the devices whose parameters are to be saved.
- ② Selection of whether device and/ or operator parameters are to be saved
- ③ Selection of how parameters are to be addressed. Sorting takes place accordingly (see sorting mode).
- ④ When selected, only devices that are online appear in the list.
- ⑤ All parameters of the selected devices are saved in one list. This is positioned in the Navigator at the project. The distinction is made by the device reference.
- ⑥ A separate list is created for each selected device. This is positioned in the navigator at the respective device.

- | | |
|--|---|
| <p>⑦ The separate lists are saved outside COMBIVIS as parameter lists in ".dw5" format.</p> <p>⑨ Upload starts. Observe any warning message. Cancellation is possible at any time.</p> | <p>⑧ The pattern for the names of the generated objects or files can be configured using the selection fields for separate lists.</p> |
|--|---|

After the start a message can be shown:




Fig. 310: Parameter lists Upload starts

Explanation:

If "WA" parameters are included in the list, the upload should not be started if data is being written to the COMBIVERT at the same time by a bus system or other parallel communication. During the upload, pointers to memory cells must be adjusted. If information is written via this pointer at the same time, it may end up in a wrong cell. This could be, for example, a wrong target position. After the backup is finished, all pointers are back in their original position.

The lists can be exported from the navigator (\Rightarrow Export parameter list [▶ 236]).

18.17.1 Sort mode

Depending on the type of the COMBIVERT not all addressing modes are available.

Parameter list design with indirect set addressing:

Design of the list:

Set pointer Fr09 = 0

All set programmable parameters of set 0 and all not set programmable parameters

- Set pointer Fr09 = 1

All set programmable parameters of set 1

.....

- Set pointer Fr09 = 7

All set programmable parameters of set 7

- Operator parameters

If the drive controller works in contouring mode (synchronous bus mode) the indirect set addressing must be used!

Parameter list design with direct set addressing, joined parameters:

Without set pointer, each parameter belongs direct to one set or several sets.

Design of the list:

- Parameter X of set 0
- Parameter X of set 1

- Parameter X of set 2
- Parameter X of set 3

.....

- Parameter X of set 7
- Parameter Y of set 0
- Parameter Y of set 1
- Parameter Y of set 2
- Parameter Y of set 3

.....

- Parameter Y of set 7

-
- Operator parameters

All not set programmable parameters are written in set 0.

At subindex / CiA 301 addressing “joined parameters” is used always.

Parameter list design with direct set addressing, joined sets:

Without set pointer, each parameter belongs direct to one set or several sets.

Design of the list:

- All set programmable parameters of set 0 and all not set programmable parameters.
- All set programmable parameters of set 1

-
- All set programmable parameters of set 7
- Operator parameters

18.18 CP Parameters

CP parameters are parameters displayed in the device display at COMBIVERT F5, B6, and G6 in a separate menu. The CP parameters show selectable application parameters.

In COMBIVIS 6 there is no actual CP parameter menu. Parameterisation is only possible via the application parameters.

A list can be created which shows the assignment of CP parameter and application parameter.

→ Click with right mouse key on the device in the navigator → “Create CP parameter list”.




Fig. 311: Parameter lists Create_Cp parameter list

The screenshot shows the 'CP parameters [Node_1_F5H_M]' tab. The table displays the following data:

#	IdTxt	Name	Online value	Comment
0	Ud01	password	CP read / write	
1	ru07	actual value display	0.000 1/min	
2	ru01	set value display	1751.075 1/min	
3	ru00	inverter state	0: no operation	
4	ru15	apparent current	0.0 A	
5	ru16	peak apparent current	0.0 A	
6	ru12	actual torque display	0.00 Nm	
7	ru18	actual DC voltage	315 V	

Fig. 312: Parameter lists CP parameters inverter state

In the column “#” the number of the CP parameter is shown. The parameter is the assigned application parameter. For example, in the picture above: CP03 shows “ru00 inverter state”.



The assignment of the CP parameter is read out while creating the list. A subsequent change in the device is not reflected in the list. A scaling or set assignment is not considered.

18.19 Export parameter list

Basically, lists attached to the project are saved with the project.

A parameter list can be exported from the project into following formats:

“dw5”= COMBIVIS format - only 1 device in the list

“cvxpl”= COMBIVIS format – several devices in the list

“wr5”= COMBIVIS format – work list

EtherCAT CoE startup command file



A “wr5” list does not store any values, just a list of (online) parameters!



Parameter lists to be used on COMBICONTROL C6, F5 LCD operator or F6 operator must be stored in "dw5" format.

Export:

Select parameter list in Navigator → right-mouse-click: „Export“ → select storage format → select storage location.




Fig. 313: Save Parameter lists Export

Alternatively, from open parameter list: right-mouse-click→ Export → select format:

Source Config-IDs: 9278											Last downloaded on: 8/5/2021 8:55:35
Parameters											
#	DRef	Device	Addre...	Su...	Set	R/W	IDText	Name	Offline value	Online value	
0											
1											
2	0	Node_1...	0x3001	0	-	WA	ud01	password	0	application	
3											
4	0	Node_1...	0x					Export			
5	0	Node_1...	0x					Download list	F4		
6	0	Node_1...	0x					Upload list	F5		
7	0	Node_1...	0x					Compare list			
8	0	Node_1...	0x								
9	0	Node_1...	0x								

Fig. 314: Save Parameter lists Export variants

A parameter list can also be exported to an EtherCAT compatible XML format. This list can be transferred, for example, as a start-up list to an EtherCAT compliant PLC (COMBICONTROL C6, TwinCAT 3.x).

Select parameter list in Navigator → right mouse click → Export → EtherCAT CoE startup command file.




Fig. 315: Save parameter lists Export EtherCAT

19 Scope

19.1 Properties

- Running of one Scope per project possible. Several scopes files can be added and displayed.
- Scope files can be attached to the project or to devices.
- Scoped files are saved with the project when it is saved.
- Up to 16 channels per scope from different devices.
- COMBIVERT F5 / B6 / G6: Up to 4 channels per device operate in fast scope mode. Possible combinations (2x32-bit + 2x16-bit) or (1x32-bit + 3x16-bit) or 4x16-bit parameter length.
- COMBIVERT F6 / H6 / S6 no fast Scope mode up to firmware version 2.0. From version 2.1 up to four 32-Bit parameters can be used in fast Scope mode (Service 21).
- Display as dot, line, step curve or interpolated curve.
- It is possible to record channels in all devices of the project at the same time.
- Export in XML format with file extension ".sc6" for import into another COMBIVIS 6 project.
- Export to Excel-compatible ".CSV" format.
- Offline mode (4 channels buffer in one device).
- Online trigger mode ("freeze" on certain condition).
- 2 horizontal and 2 vertical cursors simultaneously.
- Extensive zoom functions.
- Autoscaling function (distribution of curve values over the X and Y axes).
- Unit axis with the unit of the parameter value.
- Import of ".sc5" scope files from COMBIVIS 5 not possible

19.2 Add scope to the project

Following possibilities are offered for to add a scope:

- a new, empty scope
- an external scope with file extension “.sc6” or “XML”
- a scope with the same settings as an existing one.

19.2.1 Add a New Scope




Fig. 316: Add a new scope

Select whether the new scope is to be attached to the project or a device:




Fig. 317: Add Scope

Enter the name of the new scoped file → Add




Fig. 318: Scope Name




Fig. 319: Open Scope alternatively

Open the first and further scopes: In the Navigator, highlight the project name, device name or scope folder under the project or device → "right mouse button" on the project → "Add object" → "COMBIVIS Scope"




Fig. 320: Scope Add Object

or in the toolbar: Icon „Add Object“ → „COMBIVIS Scope“



Fig. 321: Scope COMBIVIS Scope

Only one scope can be active at the same time. With each scope, a recording can be saved in the project. The channels, formats and settings can be different in all scopes.

19.2.2 Open an external Scope

External stored scopes can be opened in a current project or directly with a temporary project.

Insert into an open project: Click on the Icon  in the toolbar.




Fig. 322: Add a new scope

Select whether the new scope is to be attached to the project or a device:




Fig. 323: Open Scope

Set hook at import from file → choose the file → „Add“




Fig. 324: Scope Import from file




Fig. 325: Scope clipboard

→ Choose to which device the scope channels shall belong → "Add"

Selection "New device" adds a new virtual device to the project. This is necessary if there are no devices or only non-compatible devices in the project.




Fig. 326: Assign Scope and Add

Different channels in the opened scope can belong to different devices of the project.




Fig. 327: Scope device selection

The version of the COMBIVERT is stored in the scope, so at opening it is pre-selected if a matching device is found in the project.

Directly with temporary project in background:

Choose scope file in Windows Explorer, then double-click or in context menu "Open with....".




Fig. 328: Scope output file

On Start Page with button "Open Scope"




Fig. 329: Open scope file

19.2.3 Create scope with same settings

After changing settings in the device, it is useful to make a before-and-after comparison. For this, you can create a copy of the scope. This can then be used to record a second scope. This saves a new channel assignment and new adjustment settings.

Copy scope:

By "copy" and "paste" in the navigator, it is easily possible to create a similar scope.




Fig. 330: Copy scope




Fig. 331: Paste scope

19.2.4 Moving scope in the project

A scope can be moved in the project with the mouse pointer. E.g., from the drive to the project or from one drive to another. The channel assignment is adjusted automatically.

Note! A warning is displayed if the device reference (Gref) of the scope channels does not match the device where it was inserted.




Fig. 332: Move scope file

The assignment of the channels can be adjusted in the settings of each channel.




Fig. 333: Scope_assignment

19.3 Scope Basic Settings

It is possible to configure basic setting in window **KEB Scope-Settings**. These adjustments will be preset always when a new scope will be opened.

Menu bar → “Tools” → “Options” → in window “KEB Scope-Settings”




Fig. 334: Scope Tools Options




Fig. 335: KEB Scope Display Channels Advanced

In window „**Settings**“ in scope itself settings can be adjusted which are valid only for this scope.




Fig. 336: Scope Settings

- | | |
|---|---|
| 1 Description for scope | 2 Online (direct display of recorded values in CV6) / Offline mode (see there) |
| 3 Display / design of cursor, grid and legend | 4 Trigger option (Identification of special occurrences in recording – see there) |
| 5 Time gap between two measured points: 0 = shortest time | 6 Limitation of communication |
| 7 Cursors snap into measured value | |

Limitation of communication / scan time:

Lock channels:

The specified parameter on a channel can be accessed and queried only by Scope. Other parameters are accessible.

Exclusive communication:

All communication with the devices is limited to the scope. Simultaneous change of a parameter is not possible (Also the test run wizard of the x6-devices no longer works).

At disabled function parameters can be adjusted while scope is running and displays changes coequally (e.g., for speed controller adjustment).

In the default setting (both functions off), the communication is split between the read-out scope channels and all device parameters visible in other windows. The scope scan rate is therefore faster if all editor windows are hidden.

19.4 Channel allocation / New Channel

In window “New Channel” a parameter can be chosen directly for this channel.




Fig. 337: Scope New Channel

- | | |
|--|------------------------------|
| 1 Device reference (selection) from which device the channel shall be recorded | 2 Control data of the device |
| 3 Parameter group selection | 4 Parameter selection |
| 5 Set selection mode (indirect e.g. for contouring control) | 6 Set or subindex selection |
| 7 Transfer and activation of the channel | |

Alternative:

Arrange windows next to or on top of each other. Select parameter in device-editor and pull it to the window “scope”. (Doesn’t matter if scope is in tab “display”, “settings” or “new channel”).

Please do not forget acceptance and activation!




Fig. 338: Scope device parameters



At COMBIVERT H6/ F6/ S6/ P6/ T6 up to firmware 2.7, the index values of ARRAY and STRUCT parameters cannot be recorded. This function is only possible at COMBIVERT F6/S6 from firmware version 2.8.

19.5 Setting occupied channel

The settings of the display can be changed at any time, even subsequently.



Fig. 339: Scope Setting occupied channel

- | | |
|--|-----------------------------|
| 1 Channel number | 2 Channel switched on/off |
| 3 Optional description | 4 Delete channel |
| 5 Display channel allocation: Device / Parameter | 6 Change channel allocation |

A disabled (not "enabled") channel is not shown in the display and not recorded at the next recording.

Scaling of this channel:




Fig. 340: Scope Channel switched off

- | | |
|---|--|
| 1 Parameter value at 0% Y-axis | 2 Parameter value at 100% Y-axis |
| 3 Benchmark at 10% of Y-axis (corresponding to 0 % / 100) | 4 Reset to original values |
| 5 Auto scaling of this channel | 6 Synchronise with another channel (e.g. setpoint and encoder speed) |




Fig. 341: Scope display

1 Display of curve	2 Display in points
3 Display as line, linear connection between points	4 Display as stairs between points
5 Display as line, interpolated connection between points	6 Interpolation value
7 Measurement value point highlighted	8 Color of curve
9 Width of curve	

19.6 Fast scope mode

The fast Scope mode depending on the device type is a possibility of fast and simultaneous transmission of measured values. It works like a process data communication.

COMBIVERT F5/ B6/ G6: Up to 4 channels per device operate in fast scope mode. (2x32-Bit + 2x16-Bit) or (1x32-Bit + 3x16-Bit) or 4x16-Bit parameter length. The order does not matter.

COMBIVERT F6 / H6 / S6: no fast Scope mode up to firmware version 2.0. From version 2.1 up to four 32-Bit parameters can be used in fast Scope mode (Service 21).

Typically, the first chosen channels are placed automatically in fast Scope mode if it is available.

An assignment of parameters outside the fast Scope mode leads to a considerable slowdown in the recording raster because a time gap must be offered for the additional asynchronous values.

The fast Scope mode works only in direct addressing mode.

The assignment can be changed in menu “channel” → “extended” → “Edit fast scope mode settings”:




Fig. 342: Scope communication settings

19.7 Recording

Start recording in window “Display” as follows:

Menu: “Scope” → “Start scope”

- or Context menu / right mouse key → “Start scope”
- or Tap key “F9”
- or click on symbol in the toolbar




Fig. 343: Recording scope

Stop with same functions but a stop-icon will be shown:




Fig. 344: Stop scope

Starting and stopping the scope also works when the scope is not in the foreground.

Recording time is not limited. Per hour with 4 channels at 15ms cycle time the size will be approx. 90 MB.

19.8 Display window

Behaviour of the display while recording:

Context menu / "Right mouse key" → "Auto-Zoom/Scroll":




Fig. 345: Scope Display window

- | | |
|---|---|
| 1 Saves the current Y-axis proportioning for a new recording. | 2 At recording the displayed window jumps with the recorded value to the next window width. |
| 3 The window runs synchronous with the actual recorded value. | |

19.9 Adapt Display

Time axis (X-axis):




Fig. 346: Scope Display Operation

- | | |
|--|---|
| 1 Stretch / compress time axis | 2 Showing / hiding the cursor value table |
| 3 Complete recording time is displayed | |
| 4 Shift window left / right | |

X-axis:

Recording time in ms or μ s

Y-axis:

Parameter value in basic setting refers to: 100% = maximum value range 0% = 0
-100% = min. value range

By passing the curve with the mouse, the actual value will be displayed.




Fig. 347: Scope measurement curve values

By right mouse key click on the curve a window opens with adjustment possibilities.




Fig. 348: Scope Measurement curve Alignment

19.9.1 Distribution / stretching of all curves over the display area:

Click with "right mouse key" in the display window: "Auto-scale all channels"

All actual values will be stretched on the Y-axis all over the window from -100% to +100%.




Fig. 349: Scope Measurement curve Auto scaling

19.10 Display – Zoom

At zooming the relation between the curves is kept.

19.10.1 Zoom to display 0-100% (or rather -100- +100%):

Context menu "Right mouse key" → "Fit Zoom level" → "All axes" (or only "X- or Y-axis")

Tab key F5 (F3 / F4)




Fig. 350: Scope Zoom Level

Zoom by mouse:




Fig. 351: Scope Zoom

1 Mark whole image with mouse wheel or "+" and "-" keys - Mark partial area with left mouse button, open window

2 Time axis: click and hold with mouse and scroll to right or left side

- Whole display with mouse wheel or keys "+" and "-"

- The view in the window can be displaced by using the buttons “ $\leftarrow \uparrow \rightarrow \downarrow$ ”

Or

- Tap key “Ctrl” and left mouse key in parallel“

Or

- With pressed mouse wheel

Or

- the buttons in the field:




Fig. 352: Scope measurement curve Keys

19.10.2 Scaling / fixing of Y-axis:

Zooming will be done only at the time- (X-) axis by mouse.

Point to the Y-(%) axis → context menu / “right mouse key” → “Scale fixed”




Fig. 353: Scope Measured curve Fix scaling

Also, a manually scaling of the Y-axis can be done.

19.11 Display – Cursors

There are 2 vertical and 2 horizontal cursors:

To integrate: “Right mouse key” → “Cursors” → “Vertical 1 or 2 and horizontal 1 or 2”.

Alternative with keys:

- Alt+A: Vertical 1
- Alt+B: Vertical 2
- Alt+C: Horizontal 1
- Alt+D: Horizontal 2




Fig. 354: Scope Cursors

The cursors will always be first placed in the centre.

The cursor can be moved by pressed left mouse key or by using key combination "Alt+→" and "Alt+ arrow key right".




Fig. 355: Scope cursor table

1 Cursor vertical 1/2

2 Cursor horizontal 1/2

3 Cursor table visible / invisible

4 Cursor table: Values of the current horizontal cursor position (Y-axis) or of the intersection point of the vertical cursor position with the measurement curve

Calculation mode:

Based on vertical cursor values, it is possible to realize several calculation types: difference, integral or average.

On basis of horizontal cursor values only difference is possible.

By context menu / "right mouse key" in the cursor list area the calculation mode can be chosen.




Fig. 356: Scope Measurement curve vertical horizontal

Or for changing click onto the name with left mouse key.

	Vertical 1	Vertical 2	Difference	Horizontal 1	Horizontal 2	Difference
Position	8984 ms (21.03...	10781 ms (21.0...	1796ms	43,4 %	0 %	-43,4 %
[0] ru00: invert...	68: reverse dec...	64: forward acc...	[-4] 4294967292	66: forward con...	64: forward acc...	[-2] 4294967294
[1] ru03: actual...	-16,1625 Hz	19,9375 Hz	[2888] 36,1000 Hz	21,7000 Hz	0,0000 Hz	[-1736] -21,700...
[2] ru15: appar...	1,7 A	1,7 A	[0] 0,0 A	1,1 A	0,6 A	[-5] 429496729...

Fig. 357: Scope Measurement curve Difference values

	Vertical 1	Vertical 2	Integral	Horizontal 1	Horizontal 2	Difference
Position	8984 ms (21.03...	10781 ms (21.0...	Diff.: 1796ms	43,4 %	0 %	-43,4 %
[0] ru00: invert...	68: reverse dec...	64: forward acc...	118,20468*s	66: forward con...	64: forward acc...	[-2] 4294967294
[1] ru03: actual...	-16,1625 Hz	19,9375 Hz	3,84689781640...	21,7000 Hz	0,0000 Hz	[-1736] -21,700...
[2] ru15: appar...	1,7 A	1,7 A	2,649399 A*s	1,1 A	0,6 A	[-5] 429496729...

Fig. 358: Scope Measurement curve Integral values

	Vertical 1	Vertical 2	RMS	Horizontal 1	Horizontal 2	Difference
Position	8984 ms (21.03...	10781 ms (21.0...	Diff.: 1796ms	43,4 %	0 %	-43,4 %
[0] ru00: invert...	68: reverse dec...	64: forward acc...	65,771	66: forward con...	64: forward acc...	[-2] 4294967294
[1] ru03: actual...	-16,1625 Hz	19,9375 Hz	10,941 Hz	21,7000 Hz	0,0000 Hz	[-1736] -21,700...
[2] ru15: appar...	1,7 A	1,7 A	1,518 A	1,1 A	0,6 A	[-5] 429496729...

Fig. 359: Scope Measurement curve RMS values

With this it is possible to get very easy the RMS current of a drive over a running circuit. If the cursors are no longer in the picture due to zooming, they can be brought back into the picture with the context menu "right mouse button" → "Centre cursors".




Fig. 360: Scope Measurement curve Centre cursors

The displayed length of the parameter name in the cursor list can be chosen in the context menu.




Fig. 361: Scope Measurement curve Parameter name

19.12 Save recordings

Several scope recordings can be added to the project and saved with it.

Each scope can save one recording.




Fig. 362: Save scope recording

([Add a New Scope](#) [▶ 238])

see also

[Add scope to the project](#) [▶ 238]

Add a New Scope [▶ 238]

19.13 Import / Export

With the export and import function Scope records can be stored outside of the project or external files can be imported. The file extension is "sc6".




Fig. 363: Scope recording

1 Clears the display.

2 Copies the displayed picture to the clipboard. Can be used e.g., in MS-Office programs.

3 Imports a COMBIVIS 6 scope file, the actual displayed curves will be erased.

4 Exports the actual scope curves in a SC6 or a CSV-format e.g., for saving.

19.14 Export to CSV format

Exports the current scope curves in a CSV-format. This allows importing the recorded curves in e.g., Excel program.




Fig. 364: Export scope files




Fig. 365: Scope Export to CSV format

Adjustments of "CSV"-format by: "Tools" → "Options" → "KEB-Scope" → "Extended"
Files in csv format cannot be re-imported.

19.15 Trigger function (online)

19.15.1 Trigger function in online mode

This function realizes in case of long-term recordings a limitation of the saved period (e.g. period around a defined error occurrence). Therefor a trigger event will be defined (e.g., a special drive controller status or a reached current level).

Around this event a predefined time domain will be saved. That results in a compact scope-file also for long term recordings.

This function will be adjusted and activated in the window "Scope" → "Settings". The trigger event will be placed in scope display at 0 ms on the time axis.




Fig. 366: Scope trigger function

- | | |
|---|---|
| 1 Trigger channel: On which channel shall be triggered? | 2 Which trigger pulse edge or level? |
| 3 Lead time: saved time before trigger event. | 4 Over travel time: saved time after trigger event. |
| 5 Level, absolute relating to unit or percentile relating to range of values. | 6 Activate trigger function. |

Example:




Fig. 367: Scope trigger function Example

19.16 Offline mode

The Offline mode uses the function of the fast Scope mode's 4 channels to buffer parameter values in the device. Therefor a part of the device's storage is reserved.

Via channel allocation recording and filling of storage will be generated. The storage works like a drum store. each new value overwrites the oldest one.

The store will be frozen by a trigger event and can be read-out by scope. Because of a faster data communication in the devices than to the PC it can be recorded with a shorter time grid.

Useful for:

- Shorter time grid, therewith better hit rate in short peaks
- Recording without PC
- Recording of sporadically events.

Characteristics:

- Available for COMBIVERT F5 but not F5-Basic, B6, F6, G6, H6, S6 and P6 drive controllers
- Contrary to online mode data won't be readout sequential from the drive controller and displayed but internally saved in the drive controller.
- No dependency on communication time, therefore very short frames realisable.

- Up to 4 channels in one device will be recorded with chronological synchronism and in a fixed frame (fast Scope mode).
- For data recording a connection drive controller to PC must not be active.
- Flexible trigger conditions allow a selective recording of sequences.
- Trigger will be released by a digital input.

Also, after drive controller's power-off the trigger requirement will remain unaffected (only F5-A/M, S, H, K, L, P, E \geq D housing). In COMBIVERT G6 the trigger condition will be saved after Power Off, stored date will be lost. It is possible to trigger intermittent effects over a long period. At COMBIVERT F6/ H6/ S6/T6, the values and the triggers are lost when the supply is switched off.

- At COMBIVERT F5, B6 and G6 all Parameters are recorded only from set 0.

19.16.1 Switch on and adjustment of time basis

Activating of Offline mode: "Scope" → "Settings" → "Mode"




Fig. 368: Set scope time base

- 1 Reading out a stored recording. The channel assignment is read out automatically.

Set the time base (sampling rate):

Maximum number of buffered values * scan time = stored time. That means: the smaller time base the shorter recorded time.

Max. quantity of values depends on controller's data space ((\Rightarrow [Storage Capacity \[▶ 278\]](#))).



For COMBIVERT H6/F6/S6/P6/T6 the sampling rate depends on the setting in parameter is22 / time base Tp. Only multiples of the time base set in is22 can be used (rounded if necessary).




Fig. 369: Scope time base switching frequency

19.16.2 Adjusting of trigger source

Digital or software inputs act as trigger source.

The activation of inputs initiates a saving of the scope recording. e.g.: setting "F" for recording of acceleration. If no trigger source is set, the drum store is filled and read out when recording starts.




Fig. 370: Scope Setting the trigger source

With the software inputs IA ... ID, complex trigger conditions can be realised indirectly via the software outputs OA ... OD e.g.: Switching condition "apparent current>level" via output OA to input IA.

Example for COMBIVERT F5 (similar for G6):

A description and 2 samples can be found by menu "Help" → "Show FAQ" Documents" → "FAQ CV6 0003 OfflinescopeTriggerConditions (en)". Also 2 sample parameter lists are included.




Fig. 371: Scope KEB Documents




Fig. 372: Scope FAQ

19.16.3 Adjusting of trigger position

Trigger position defines how many percent of the complete recording period before trigger event shall be displayed.

Example: 30% = 30% of recording indicate the period before the trigger event.




Fig. 373: Scope Setting the trigger source

Remark:

When the recording is started, the offline memory (ring memory / drum storage) is filled with values. Until the memory has finished the first loop values from previous records can be in. If, after the start of the recording, the trigger still comes within the first "round" and has only a little delay, it may be that the previous values have not yet been overwritten and are displayed.

19.16.4 Application

Start offline recording via click on start/stop button or tap key "F9".

In the bottom of the scope-window the flashing code "wait for trigger" appears. The drive controller waits for the trigger event.

The code will change into "data recording" as soon as the trigger event occurs. The recording will be realised and saved.

If the saving process is finished, the code will change into "offline data readout". The saved data will be read out by scope and displayed.

After reading out the diagram can be handled like in online-mode.

Recording without connected PC and read out afterwards

Start offline recording by start/stop button or tap key "F9" → at the bottom of the display is shown blinking "Wait for trigger" → the device is waiting for the trigger condition.

Close COMBIVIS 6 without stopping the scope, if applicable save project. Disconnect the PC from the device.

When the first trigger condition occurs, the curves will be saved in the device's storage. Further will be ignored.

Connect cables as shown before → start COMBIVIS 6 with the respective or with a new project → if needed get connection to the device → at "Scope" → "Settings":

 → the saved data will be read out of the device and displayed in Scope.

The saved data will be erased at F5-A-S/-E/-H; ≥D-housing only by a new starting of off-line recording. The drive controller can also be switched off in the meantime. At G6/ H6/ F5-A-Servo (A housing) trigger requirements and saved data will be erased also by switching off the device or by overwriting.

For example:

Time base: 500μs - trigger source: F - trigger position: 5%




Fig. 374: Scope Trigger function Example1

19.16.5 Storage Capacity

e.g.: in KEB COMBIVERT F5-A Version 4.2: ≥ D housing		
For 1x or 2x 16 bit parameters:	approx.	1900 values/channel
For 3x or 4x 16 bit parameters:	approx.	950 values/channel
For 1x or 2x 16 and 1x or 2x 32 bit parameters:	approx.	470 values/channel

(32-bit-parameters are e.g., position, torque, and control / status word long)

Therewith 4 channels with 16 bit in 0.5ms time basis give approx. 0.47s recording time.
For the other drive controllers this might differ strongly.

For example: a KEB COMBIVERT G6-G has approximately 20% more space.
COMBIVERT F5-C has approx. 70% less and COMBIVERT B6 approx. 86% less.

20 Search function

There are two different search functions in COMBIVIS 6:

20.1 General text search

The general text search under the "binoculars" in the toolbar (only with COMBIVIS studio 6):




Fig. 375: Search function binoculars

Here is just looking for texts in specific fields.

20.2 Parameter search

The parameter search is opened with Ctrl + Shift + F or the icon in the toolbar. Parameters can be searched in the Device Editor and parameter lists in the project.




Fig. 376: Search function Parameter search dialogue




Fig. 377: Search function Parameter list

- | | |
|--|-------------------------|
| 1 Search text | 2 Jump to next result |
| 3 Shows all results in Search Results window | 4 Setting text type |
| 5 Search area | 6 Search specifications |

Normally, the parameter search is done from the current cursor position to the end. If the parameter you are looking for is in front of it, it will not be found. With the "end from the beginning" option the parameter will be found, but it may be in a loop and the user must decide at which point the loop is executed.

Searches can be made for:

- Parameter ID (abbreviation). Search field must be set to "IdTxt". (Parameter Id without dot).
- By parameter name: e.g., "current" all-the parameters will be found with the term "current" in the name.
- By hexadecimal address: Default as 1234h or 0x1234 possible.
- By entries in the "Comment" column (only in parameter lists)




Fig. 378: Parameter search - search field

20.2.1 Search methods:

If you click on "Continue search", the display window jumps to the next location.




Fig. 379: Search function parameter search continue search

With "Search all" a new result window opens in the message window with all the locations. Clicking the locality in the results executes a jump to the appropriate place in the editor or in the parameter list.




Fig. 380: Search function Search methods

21 Document database

All KEB documents can be viewed via the COMBIVIS internal document database. The programming manuals of COMBIVERT F5, G6 and F6/S6/H6 are integrated in the basic configuration. Other documents, such as manuals, catalogues and E-Plan data can be downloaded as data packages via the Internet.

Using the document database requires registration of COMBIVIS 6 or licensing of COMBIVIS studio 6. A registration request is available at the bottom of the home page or under menu bar: "Help" → "Registration". The registration is free of charge.

21.1 Add/remove documents

The documents are grouped in packages. Documents are updated via the auto-update function. An Internet connection to the KEB homepage (www.keb.de) is required for the installation or update.

The database administration is opened via the start page item "Manage KEB Documents".




Fig. 381: Document database Manage Documents

or via the toolbar:




Fig. 382: Documents database Add documents

The administration window opens:




Fig. 383: Document database overview of available installed packages

- | | |
|---|---|
| 1 Overview of available / already installed packages.
3 Info about the content of the package. | 2 Marked packages will be installed.
4 Data volume of the selection. |
|---|---|

The document packages available on the computer are displayed in the "Installed" tab. A green background means that the package is up to date.




Fig. 384: Documents database Documents installed

21.2 Use document database

There are two ways of accessing the documents:

Global access to all available documents:

The database is opened via the start page "KEB Documents".




Fig. 385: Documents database Documents

or via the toolbar:




Fig. 386: Documents database Show documents

The editor "KEB documents" opens:

It is possible to search by part number, file type, area and/or language.




Fig. 387: Document database Search mask

1 Editor

2 Search mask

3 Result of the filtering

When entering the part number, devices are suggested which are contained in the configuration database. Part numbers of other KEB devices are also accepted.




Fig. 388: Document database Selection

The document is opened by double-clicking on the document name. Various options are available via the context menu - right mouse button - on the document name.




Fig. 389: Document database Installation S6 housing 2

Device-dependent access to the documents:

In the device editor there is a tab "Documents". Here, the documents can be filtered by device part number. One or more entered part numbers are permanently assigned to the device in the project.




Fig. 390: Document database Filter

- | | |
|-----------------------------|-----------------------------------|
| 1 Freely selectable name | 2 Add / remove device to the list |
| 3 Part number of the device | 4 Update |

5 Documents available for selection.
Open by double-clicking with the mouse.

Apply from configuration

For a project created with the configurator, the associated documents can be transferred automatically (KEB Configurator).




Fig. 391: Document database Apply Configuration

1 Load data from configuration.

21.3 KEB PDF viewer

The KEB PDF viewer is a simple program adapted to the KEB document database. It is installed with the installation of CV6.

Other viewers can also be used, but some of them have limited functions, such as Adobe Reader. The search for parameter information of the parameter cannot be carried out there if the document is already open.




Fig. 392: Document database PDF viewer

1 Tool list

2 Search window

3 Search result

4 View of the document

5 Content

The toolbar can be adjusted by grabbing and moving the fields on the dashed line with the mouse.




Fig. 393: Document database Adjust toolbar

The used PDF viewer can be set under toolbar "Tools" → "Options" → "KEB Documents".




Fig. 394: Document database Options




Fig. 395: Document database PDF settings

22 Update

22.1 Manual check for new version

A connection to the KEB homepage is established with the "Check for updates" function on the start page or in the "Help" menu, provided there is a connection to the Internet. The file versions and documents are checked for a new date and downloaded and integrated on request.




Fig. 396: Update Help Check for updates




Fig. 397: Update All components are up to date

22.2 Automatic check for newer version

An automatic check for newer versions is set as background function when connected to the Internet.

(⇒ Options - Online update [▶ 137])

22.3 Manual update of the parameter description file

If an Internet connection to the KEB homepage is not possible, the parameter description file can also be updated with an external memory (e.g. USB stick).

Search for the file "paras.xml" at (🌐▶ www.keb-automation.com) → save on PC or stick
→ integrate via menu → "Tools" → "Import KEB parameter description file".




Fig. 398: Updating tools

After the import, the file must be reloaded or COMBIVIS must be restarted.

23 Device storage

23.1 Device storage wizard

The device storage wizard enables the transfer of recipe lists into the device memory of COMBIVERT F6 and S6 as of firmware V2.3.

The connection can be made via:

- Cable part. no. 0058025-001D
- KEB-USB serial converter part. no. 0058060-0040 from version V2.4 and the designation "FTP ready" on the name plate
- UDP Port 8002 on COMBIVERT F6/S6 Pro on the internal Ethernet interface

Note:

- The F6 Ethernet or USB operator opens only access to the operator-internal store, not to drive controller!
- Files in compressed form (zip files) cannot be loaded into the device storage.
- Accessing the device storage and loading recipes into the device only works when the modulation is switched off (status voltage enabled, switched on, ready to switch on).

The function of the recipe management is described in the manual of the COMBIVERT (keyword: recipe management). It can be found in the ([⇒ Document Database \[▶ 283\]](#))

With the device storage wizard also other file types can be transferred (description files, firmware, etc.).

The drive storage wizard is in the device editor:




Fig. 399: Drive storage




Fig. 400: Device storage connections

1 Connection blue = communication with device storage, green = with device, red = offline

3 Display file system

5 Transfer file

7 Storage area for file transfer

2 Establish connection with device storage.

4 Files on the PC

6 Files in the device storage

Recipes have the file extension "dw5".

23.1.1 Access level / password

Depending on the file function, a specific **access level** must be entered for transfer:

- User access: Level 3 = Application, password: 440
- Service access: Level 5 or 6 = Supervisor, password ***

User-specific passwords are not possible.




Fig. 401: Device storage application

The password must be set via the key symbol.




Fig. 402: Device storage Password

The key symbols in the toolbar or below in the parameter editor do not work here! The current access level is displayed here:




Fig. 403: Device storage current access level

After Power-On-Reset the access level is 0: read-only.

23.1.2 Connection setup

Klick on the button "Connect". If needed enter the device password.

The connection to the parameter interface (green contactor in the navigator) is interrupted and 'redirected' to the internal storage (blue contactor). The parameters are not accessible while using the device storage wizard.




Fig. 404: Device storage connection_setup




Fig. 405: Disconnect device storage

23.1.3 Show stored recipes

Tab Recipe management.

The recipes can be transferred to the Navigator as a parameter list.




Fig. 406: Device storage Recipe management

23.1.4 Create a recipe

A parameter list can be loaded directly from the Navigator as a recipe into the COMBIVERT. Select the parameter list → right mouse key → "Download as recipe".




Fig. 407: Drive storage download as a recipe

A password is required. The user password is typically "440" (Level 3).




Fig. 408: Enter drive storage password

The file names of the recipes must meet certain criteria (=> Programming Manual). The function and the name can be selected.




Fig. 409: Drive storage Next free ID

With "OK" the list is transferred as a recipe to the drive storage. Doppelte Dateinamen werden dabei vermieden.




Fig. 410: Drive storage Parameter list_test

23.1.5 File system / transfer file

In the "File system" tab, the file system of the PC is shown in the left half of the window and the COMBIVERT file system is shown in the right half of the window.

The drives C: and D: are available in COMBIVERT. Normally, C: stores the user-specific files (recipes) and D: the system-relevant files (firmware, etc.).

The file names of the recipes must meet certain criteria (=> Programming Manual).

Transfer a recipe from the PC file system to the COMBIVERT: Select (mark) files → by > transfer from one to other file system

or drag and drop the file with the mouse from the PC file system onto the dashed area.




Fig. 411: Transfer device storage parameter list

Transfer a recipe from the PC file system to the COMBIVERT: Select (mark) files → by > transfer from one to other file system.




Fig. 412: Execute device storage parameter list

23.1.6 Edit recipe in the file system

The recipe can be deleted from the file system (trashcan icon). The recipe name can be changed.




Fig. 413: Rename device storage recipe

The content of a recipe can only be changed by transferring it as a parameter list to the Navigator and saving it again as a recipe after the change.

(⇒ [Show stored recipes \[► 298\]](#))

23.1.7 Disconnect connection

After the connection has been disconnected, the connection to the parameterisation interface of the COMBIVERT opens again = green connector symbol in the Navigator. Due to blocking times, the switching time is approx. 10 seconds.




Fig. 414: Disconnect device storage

23.2 KEB FTP File Transfer Program

The KEB File Transfer Programme (KEB FTP) can be used to exchange data between KEB components. The following transfer is possible:

- PC and KEB Portable Operator (Part number 0058060-1010 /-1110) with USB cable
- PC and COMBICONTROL C5 / C6 COMPACT I+II, H6CU, P6, T6MCU with LAN cable (not with KEB USB converter).
- PC and the operating operator of the COMBIVERT F6 with USB or LAN cable (UDP port 8002).
- PC and COMBIVERT S6/ F6 with cable ((⇒ [DIN 66019 - RS-232 cable operator 0058025-001D \[▶ 28\]](#)) or KEB-USB-serial converter from version V2.4 and the designation "FTP ready" on the type plate ((⇒ [KEB USB serial converter 0058060-0040 \[▶ 28\]](#))).
- PC and UDP Port 8002 on COMBIVERT F6/S6 Pro on the internal Ethernet interface.

Restrictions

- The 00F6P00-2000 and -3000 operators only open the internal memory of the operator (not that of the drive controller)! The 00F6P00-4001 operator has two modes for accessing the operator's internal memory or the device memory.
- Files in compressed form (zip files) cannot be loaded into the device storage.
- Accessing the device storage and loading recipes into the device only works when the modulation is switched off (status voltage enabled, switched on, ready to switch on).
- Not useable for C6 IPC types!

Opening KEB FTP

Menu bar "Tools" → "KEB FTP"




Fig. 415: Device storage Tools KEB FTP

Note:

KEB FTP is a separate program that is displayed in the COMBIVIS 6 window. It can also be obtained separately from the KEB homepage, independently of COMBIVIS. It is not possible for KEB FTP and COMBIVIS 6 to serve the same COM-Port at the same time. So, the used COM Port in KEB FTP must be inactive in COMBIVIS 6 or other programs.

Settings:

IP address or COM Port and password if required (=> device manual) must be set, then click on button → "Connect".

The password resets, depending on the device, sometime after the last operation. For the connection to COMBIVERT S6/F6, the baud rate must be set to 115200.

File name length max. (e.g.):

- COMBICONTROL C5 = 8 digits + file extension
 - COMBICONTROL C6 = 32 digits + file extension
 - Portable Operator = 32 digits + file extension
- => please consider the respective device manual




Fig. 416: Device storage Data transfer_PC_device

- | | |
|-----------------------------------|--------------------------|
| 1 Transfer data from PC to device | 2 Communication settings |
| 3 Transfer data from device to PC | 4 Data in the KEB device |
| 5 Data in the PC | |

see also

- ▀ Connection of COMBIVERT F5 [▶ 36]
- ▀ Connection COMBIVERT B6 [▶ 37]
- ▀ Device connection [▶ 36]
- ▀ Device memory (recipe management) [▶ 126]

23.2.1 Operator 00F6P00-4001

Example: Loading a worklist type .wr5 onto the operator 00F6P00-4001

The operator has 2 interfaces: USB-B and LAN/UDP.

Version 1 with LAN connection via COMBIVIS device editor:

The "Drive memory" in COMBIVIS always accesses the first memory in the data connection chain. So to the operator memory.

- Connect operator directly to COMBIVERT F6 or via cable 0058025-004A to COMBIVERT S6
- Connect PC and operator with LAN cable
- Operator not in "FTP local mode" or "FTP bridge mode"
- Establish connection to the device in COMBIVIS (depending on the network, devices, etc.)
- Open "Drive memory" in the editor
- Establish connection, the plug symbol changes from green to blue
- Insert password "660" (key symbol)
- Transfer file (▀▶ [Device memory \(recipe management\) \[▶ 126\]](#))
- Disconnect connection




Fig. 417: FTP LAN 1

Version 2 with LAN connection via KEB FTP:

- Connect operator directly to COMBIVERT F6 or via cable 0058025-004A to COMBIVERT S6
- Connect PC and operator with LAN cable (if necessary, adjust IP address in parameter fb01 via USB or keyboard)
- Select "FTP local mode" from the operator menu
- In the COMBIVIS Navigator, switch the device "offline" in the context menu (right mouse button). Alternatively in the "Communication settings" card in the device editor.
- Start Menu / Tools / KEB FTP
- Enter IP address and port Format "xxx.xxx.xxx.xxx:8002" (enter two-digit number in two digits only)
- COMs" field empty
- Enter password "660" (user access)
- "Connect"




Fig. 418: FTP LAN 2

- Access to the PC is visible in the left half and access to the operator memory is visible in the right half.
- Klick to open the drive C:\ in the operator memory and open
- Select the ready-made work list in the PC
- Transfer with button ">>"




Fig. 419: FTP LAN 3

- "Disconnect", close FTP, switch device "online"
- Exit "FTP local mode" operator menu

Version 3 with USB cable via KEB FTP:

- Connect operator directly to COMBIVERT F6 or via cable 0058025-004A to COMBIVERT S6
- Connect PC and operator with USB-B cable
- Select "FTP local mode" from the operator menu
- In the COMBIVIS Navigator, switch the device "offline" in the context menu (right mouse button). Alternatively in the "Communication settings" card in the device editor.
- Start Menu / Tools / KEB FTP
- Select COM interface
- Enter the baud rate. Format "COMxx:38400" or "COMxx:115200"
- Enter password "660" (user access)
- "Connect"




Fig. 420: FTP USB 1

- Access to the PC is visible in the left half and access to the operator memory is visible in the right half.
- Click to open the drive C:\ in the operator memory and open
- Select the ready-made work list in the PC
- Transfer with button ">>"




Fig. 421: FTP USB 2

- "Disconnect", close FTP, switch device "online"
- Exit "FTP local mode" operator menu

23.2.2 Operator 00F6P00-2000

Connect with operator 00F6P00-2000 (LAN version) via KEB FTP:

- Connect operator directly to COMBIVERT F6 or via cable 0058025-004A to COMBIVERT S6.
- Connect operator with network cable (if necessary, adjust IP address in parameter fb01 via USB or keyboard).
- In the operator basic menu (F1 key), move the cursor to "FTP menu", but do not enter it yet.
- Disconnect the device in the communication settings and set the port to 8002.




Fig. 422: FTP - Port 8002

- Start Menu / Tools / KEB FTP.
- Enter IP address and port Format "xxx.xxx.xxx.xxx:8002" (enter two-digit number in two digits only).
- COMs" field empty.
- Enter password "660" (user access).
- "Connect".




Fig. 423: FTP - Connect

- Access to the PC is visible in the left half and access to the operator memory is visible in the right half.
- Click to open the drive C:\ in the operator memory and open.
- Select the ready-made work list in the PC.
- Transfer with button ">>".




Fig. 424: FTP Startup

- "Disconnect", close FTP, reset the port in the communication settings, switch the device "online".
- Exit the "FTP mode" operator menu.

23.2.3 Operator 00F6P00-3000

Connect with operator 00F6P00-3000 (USB version) via KEB FTP

- Connect operator directly to COMBIVERT F6 or via cable 0058025-004A to COMBIVERT S6.
- Connect PC and operator with USB-B cable.
- In the basic menu of the operator (F1 key), move the cursor to "FTP menu", but do not enter it yet.
- In the COMBIVIS Navigator, switch the device "offline" in the context menu (right mouse button). Alternatively in the "Communication settings" card in the device editor.
- In the COMBIVIS menu / Tools / Start KEB FTP.
- Select COM interface.
- Enter the baud rate. Format "COMxx:38400" or "COMxx:115200".
- Enter password "660" (user access).




Fig. 425: FTP - Connect

- "Connect".
- Press the enter button on the operator within 10 seconds to start FTP mode.
- Access to the PC is visible in the left half and access to the operator memory is visible in the right half.
- Click to open the drive C:\ In the operator memory and open
- Select the file in the PC
- Transfer with button ">>"




Fig. 426: FTP file transfer

- "Disconnect", close FTP, switch device "online"
- Exit "FTP mode" operator menu with F1

24 IP Scan Tool

The IPScan tool makes it easy to find accessible devices in your own subnetwork.

24.1 Description

KEB IPScan uses the UDP protocol to transfer a block of data to allow detecting KEB devices with Ethernet. The scan request is sent from a device called "IP Scanner" via broadcast to reach all devices in the local network subnet range. All devices with IPScan functionality (KEB Kontiki based firmware) respond to the IP Scanner with their name, location, and IP parameters. Also, any active instance of IPScan.exe-Software is found (e.g.: IPScan running in C6-IPC).

24.2 Supported devices

- Full support: embedded devices (C6-C, H6-CU, P6, T6) + Ethernet Operator, Port Expander
- Limited support: C6 X86 based (ECON, PERFORM, E22, P3X)
- Not supported: arm based WEC7 devices (C6 SMART, C6 HMI LC)

24.3 Ports

The request port is 67 on the UDP protocol, the response port is 68. Sometimes the response port on the IP Scanner is in use, so an alternative port can be used (devices with firmware after year 2014).

24.4 Scan

By pressing the "Scan devices" button a call to the network is issued and the responding devices appear in the list below.

24.5 Wink

By pressing the "Wink this device" button the selected device from the list is asked to show a local response. This can be a blinking light or flashing header, depending on the specific hardware.

24.6 Assign IP Address

With the "Assign IP address" button, the selected device parameters and location may be changed. This highly depends on the selected device type and needs a specific password for that. It is primarily used by service personnel.

24.7 Additional information

The 'Info' button shows additional information about the selected device (if available).

24.8 Use IP Scan

The program works independent from COMBIVIS, but is opened in COMBIVIS. Menu bar "Tools" → "IPScan".




Fig. 427: IPScan Tool




Fig. 428: Registration Use IPScan

- 1 Start network scan
 - 2 Device blinks (see device manual)
 - 3 Assign address - reserved for KEB Service

25 Energy Efficiency Tool

Every manufacturer of drive technology is obliged to submit an energy efficiency declaration for their devices. With this plug-in the energy efficiency of different types of COMBIVERT can be classified and documented. The plug-in calculates absolute and relative power losses at eight different load levels in accordance with EN 61800-9-2. Users can also define up to 8 additional user-defined load points to determine the exact efficiency of the COMBIVERT.

For all KEB devices, even those which are not listed in the tool, the declaration can be obtained from the document database or from the KEB homepage (www.keb.de) as PDF (search for part number -> data sheets).

25.1 Function

This plug-in creates a PDF document for a specified KEB COMBIVERT. The KEB Configurator is the data base. Therefor only devices are offered which are parts of configurator.

The operating points refer to the torque-generating current and the rated frequency of the motor. The losses are related to the rated apparent power of the COMBIVERT.

The energy efficiency tool can be opened directly from the configurator or as an editor in the Navigator. Configurator:

From the configuration project, select a specific COMBIVERT and right-click on it to go to the context menu. Then click on "Generate Energy Efficiency Declaration".




Fig. 429: Energy Efficiency Tool Generate Energy Efficiency Declaration

Navigator:

In the Navigator, right-click the project node and navigate to the item "Add Object". Click on the "Energy Efficiency Declaration" button to open the editor.




Fig. 430: Add energy efficiency tool object

Choose a name for the editor:




Fig. 431: Energy efficiency editor name




Fig. 432: Energy efficiency declaration 1

- | | |
|--|----------------------|
| 1 Activate the loss-time profile | 2 Select device |
| 3 Points for loss calculation | 4 Custom load points |
| 5 Losses of load points normative and user-defined | 6 Create document |

Coming from the navigator, the COMBIVERT must be selected from the list. After opening the window, the 1st device is displayed in the list. Select the correct COMBIVERT based on the part number.




Fig. 433: Energy Efficiency Declaration selection

In the default setting, the relative and absolute losses are displayed for the operating points defined in EN 61800-9-2.




Fig. 434: Energy Efficiency Tool Normative Operating Points

In addition, the user can define up to 8 own load points. The loss values are interpolated from the normative values. The points can be entered by a mouse double-click in the left-hand graph or manually in the table "Custom load points".




Fig. 435: Energy Efficiency Tool Custom load points

The values are displayed graphically in the left field.

25.2 Loss-time profile

This can be used to create a curve that shows the losses over an operating cycle. The profile is activated by setting the check mark in the field "Loss-time options".




Fig. 436: Energy Efficiency Tool Loss-Time-Profile Options

The cycle time can be entered absolutely in seconds or relative.

The profile is generated exclusively from the "User-defined operating points" table.

To integrate normative load points, they can be dragged down from the "Normative operating points" table above. The time values must be entered manually.




Fig. 437: Energy Efficiency Tool Loss-Time-Profile required

25.3 Generate declaration / data sheet

After defining the work points and optionally the loss-time profile, the user can create a PDF report. The report contains all important device data, the normative and custom defined loss values, and the loss-time profile (if selected).

ENERGIEEFFIZIENZ NACH EN 61800-9-2




Energieeffizienzdaten¹ 15F6A12-3511

Effizienzklasse	KEB IE 2			
Arbeitspunkt	rel. Frequenz ²	rel. Strom ²	rel. Verluste ³	abs. Verluste ⁴
1	90 %	100 %	1,49 %	247 W
2	50 %	100 %	1,39 %	230 W
3	0 %	100 %	1,27 %	210 W
4	90 %	50 %	0,88 %	146 W
5	50 %	50 %	0,86 %	142 W
6	0 %	50 %	0,81 %	134 W
7	50 %	25 %	0,68 %	112 W
8	0 %	25 %	0,65 %	108 W
Verlustleistung Standby	-	-	-	29,41



Relative Verluste in den Arbeitspunkten



Gerätedaten

Materialnummer	15F6A12-3511
Produktserie	F6
Gehäusegröße	2
Gerätegröße	15
Eingangsbemessungsspannung	400 V
Motorbemessungsleistung	11 kW
Ausgangsbemessungsleistung	16,6 kVA
Ausgangsbemessungsstrom	24 A
Bemessungsschaltfrequenz	4 kHz

1) Alle Verlustdaten gelten für eine Umgebungstemperatur von 45 °C und beziehen sich auf den Betrieb bei Bemessungsschaltfrequenz und maximaler Kühlleistung. Die Daten sind für das Basisgerät mit Luftkühlkörper gültig. Alternative Kühlkörperkonzepte können die Verlustleistung beeinflussen.
 2) Die Arbeitspunkte werden normativ vorgegeben und definieren sich durch den „drehmomentbildenden Strom“ und die „relative Motorstatorfrequenz“. Ziel der Verwendung dieser Parameter ist es, die Verluste von Frequenzumrichtern und Motoren in vergleichbaren Betriebspunkten abzubilden.
 3) Die relativen Verluste beziehen sich auf die Bemessungsscheinleistung des Frequenzumrichters und sind maßgebend für die normative Klassifizierung nach EN 61800-9-2.
 4) Alle Verlustangaben sind lediglich derzeitige Prüfwerte, die der Veränderung unterliegen.
 5) Nach EN 61800-9-2 ist es zulässig, die Verluste in den Punkten mit 0 % relativer Motorstatorfrequenz bei einer absoluten Frequenz von 5 Hz zu messen.

KEB Automation KG Südstraße 38 32683 Bielefeld Tel. +495263 401-0 E-Mail: info@keb.de www.keb.de

Fig. 438: Energy Efficiency Tool Data Sheet 1




Fig. 439: Energy Efficiency Tool Data Sheet 2

26 Parameter cockpit

The Parameter Cockpit is a tool to display parameter values in separate window and bigger size.

Parameter Cockpit can be opened on a project or a device.

When the cockpit is opened on the project, parameters of several units can be inserted. If it is opened on a specific device, only from that device.

Open:

Open by menu bar icon "add object":




Fig. 440: Parameter cockpit

Or in the navigator with right mouse click:




Fig. 441: Add parameter cockpit object

Set a name:




Fig. 442: Assign parameter cockpit name




Fig. 443: Parameter Cockpit Display fields

The Parameter Cockpit includes 8 view boxes.

Parameters can be set by Drag&Drop from the device parameter editor or from a parameter list to one of the view boxes.




Fig. 444: Parameter Cockpit Drag and Drop

The Parameter Cockpit is placed at the bottom of the editor window. It can be placed also on other sides. (⇒ [Window layout \[▶ 146\]](#))




Fig. 445: Parameter Cockpit Testrun

The Parameter Cockpit can be opened several times.

Parameters from several units can be placed together in a Parameter Cockpit if it is attached to the project and not to a specific device.

27 Additional modules / plug-ins

Further additional modules for COMBIVIS 6 and/or COMBIVIS studio 6 may be published during the term of the version. These are integrated either via the update function or as a separate installation. The description for the additional modules is published separately in the KEB document database.

(⇒ ► [Document database \[► 283\]](#))

28 Help areas

28.1 Help for specific functions

By moving the mouse over the ⓘ sign, the corresponding help or explanation text is briefly displayed.




Fig. 446: Help area parameterisation

28.2 Help for program functions

Pressing the F1 key in a particular program function jumps to the corresponding place in the operating instructions.




Fig. 447: Help areas device editor




Fig. 448: Help areas display modes

- | | |
|-----------------------------|-------------------------------------|
| ① Opens the integrated help | ④ Open manual for COMBIVIS 6 as PDF |
| ② Keyword overview | ③ Search function in the help |

The help distinguishes between the function of COMBIVIS 6 and CODESYS programming system.




Fig. 449: Help areas online help programming system

28.3 Help for specific device functions (FAQ)

(Formerly "HowTo" documents)

Descriptions or examples are available for certain device functions and procedures. Help" menu bar → "Show FAQ documents".




Fig. 450: Help areas device editor

- ❶ View function descriptions and sample lists

The document database with file type FAQ is opened. Depending on the programme or device type, descriptions or sample parameter lists are displayed. Files can be opened directly with a double click. Parameter lists can be assigned to a device and opened by double-clicking.




Fig. 451: Help areas FAQ

28.4 Help for parameter functions

COMBIVIS 6 allows direct access to the device documentation. Requirement is that the documentation was imported from the KEB website into COMBIVIS 6. The feature is available only for registered COMBIVIS 6 or licensed COMBIVIS studio 6 versions. A PDF viewer is required. The KEB PDF viewer is integrated in COMBIVIS. However, others can also be used.

When the corresponding Programmer's Guide is installed, with the function context menu - "Find documentation ..." the declaration of the parameter will be shown.




Fig. 452: Help areas parameter function

- ① Right mouse button on the parameter. Displays an explanation of the parameter in KEB documents.

The programming manual of the device opens in the KEB PDF viewer.

Fig. 453: Help areas parameter function

In the right part of the window all digits are displayed where the selected parameter appears. The selection of a reference leads to a jump to the location in the PDF document.

The direct opening and import of the documentation is described in the following chapter (⇒ [Document database \[▶ 283\]](#)).

28.5 COMBIVIS error messages

COMBIVIS shows errors in message window or instead of the parameter value.

Value	Name	Source	Description
-200	Exception error	Driver (COMBIVIS internal)	Unexpected error in telegram processing

-110	Service parameter invalid	Driver (COMBIVIS internal)	Invalid coding of the request
-109	Channel not available	Driver (COMBIVIS internal)	Telegram could not be sent (e.g. interface not available)
-108	Channel occupied	Driver (COMBIVIS internal)	The channel is occupied by another component
-107	BCC error	Driver (COMBIVIS internal)	Transmission error (response from the device received incorrectly)
-106	Protocol error	Driver (COMBIVIS internal)	Invalid coding of the response telegram
-105	Service decoding unsupported	Driver (COMBIVIS internal)	Invalid coding of the request
-104	Service encoding unsupported	Driver (COMBIVIS internal)	Invalid coding of the request
-103	Node address invalid	Driver (COMBIVIS internal) / Gateway	Invalid node address
-102	Invoke ID invalid	Driver (COMBIVIS internal)	Invalid coding of the response telegram
-101	Invalid answer	Driver (COMBIVIS internal)	Invalid coding of the response telegram
-100	Channel closed	Driver (COMBIVIS internal)	The channel is closed / in parameter list:" wrong device reference
-10	No response	Driver (COMBIVIS internal)	No response received within the timeout period
0	OK	Target device	OK
1	Device not ready	Gateway	The target device is not accessible (error code is typically reported by a gateway component, e.g. USB converter, operator, port expander ...)
2	Address/password invalid	Target device / Gateway	Password level for access is not sufficient
3	Data invalid	Target device	Data is invalid (e.g. outside the range of values)
4	Parameter write-protected	Target device	Parameter can only be read
5	BCC error	Target device	Transmission error (request received incorrectly by the device)
6	Device busy	Target device	The device is accessible but busy (e.g. reset or similar) and will be available again soon
7	Service not available	Target device / Gateway	Service is not supported (can be reported by the device or a gateway component)
8	Password invalid	Target device / Gateway	Password level for access is not sufficient
9	Telegram error	Target device / Gateway	Invalid coding of the telegram
10	Transmission error	Target device / Gateway	Invalid coding of the telegram
11	Set/subindex invalid	Target device / Gateway	Set (for service 0) / subindex (for service 14) not available for this parameter
13	Address invalid	Target device	Invalid parameter address
14	Operation not possible	Target device / Gateway	Function (in the current state of the device) not possible. e.g.: Control release is set

28.5.1 Other error messages:

- a) At starting of COMBIVIS or COMBIVIS studio an error message pops up: The file C:\Programdata\COMBIVIS6\ COMBIVIS6ProjectDefaults.opt could not be loaded.




Fig. 454: Help areas error messages

The last time the project was saved, the "COMBIVIS6ProjectDefaults.opt" file was damaged or is now empty. These .opt files save personal settings for language, window sizes, etc. They have no influence on the content of the project. The files are created new each time the project is saved. Therefore, the damaged file (only this one!) can be deleted:

The path is displayed in the error message. "Program Data" is a so-called "hidden" folder. If it is not visible in Windows Explorer, you must make it visible in the folder options.

Windows 10:




Fig. 455: Help areas view hidden files

Then restart COMBIVIS 6.

Reinstalling COMBIVIS will not help, because this folder is not deleted when uninstalling.

28.6 TeamViewer

You can access the KEB website for technical support via the "Service and support" menu item. The "TeamViewer Quicksupport" software is available for download here. "Help" menu → "Service and support"




Fig. 456: Help - Call up the service and support page

TeamViewer is a programme with which a participant can access another PC via the Internet, see its screen and operate it.

The computer with COMBIVIS must have a sufficiently fast internet connection.

The owner of the "watched" PC must explicitly start the programme and agree to the access. Remote access is only possible with a licensed full version of the same or higher version.

COMBIVIS TeamViewer cannot be used to access another PC. Access is not restricted to COMBIVIS.

Start the program:

Agree to the disclaimer:




Fig. 457: Help areas Disclaimer

Give the ID and password to the user of the PC to be connected:

Info! A new password is assigned each time the system is called up.




Fig. 458: Help areas allow remote control

The connection status is displayed at the bottom. A recording of the session can be made:




Fig. 459: Help Areas Confirm Access

The control and properties window is displayed:




Fig. 460: Help areas TeamViewer
Click on the "X" to exit and close.

29 Frequently asked questions (FAQ) about COMBIVIS 6

29.1 FAQ COMBIVIS 6 parameterisation environment

29.1.1 Can COMBIVIS 5 and COMBIVIS 6 be used simultaneously?

Both programs can be installed and opened at the same time. But each COM- and USB-interface can be used only by one of them. (e.g., CV5 by COM1/serial and CV6 by USB-COM6 will work).

29.1.2 Is it possible to use COMBIVIS 6 twice at the same time?

CV6 can be open several times at the same time. But each COM- and USB-interface can be used only by one of them.

29.1.3 Is it possible to use parameter lists (.dw5), work lists (.wr5) and scope files (.sc5) of COMBIVIS 5 at COMBIVIS 6?

With COMBIVIS 6 .dw5- and .wr5-files can be opened and saved. Scoped files "sc5" do not.

29.1.4 Is it possible to parameterize older KEB drive controllers (e.g., F4) with CV6?

No, it is not intended.

29.1.5 After inserting a parameter list into the project, there is shown: "channel closed" in the online values.

The device reference in the parameter list is not the same as in the actual device.
→ Adjust the device reference in the list. Or: Device is not connected.

29.1.6 Is it possible to open several projects with CV6 at the same time?

CV6 can handle only one project at the same time. But CV6 can be opened several times with different projects (also in different languages).

29.1.7 Why will be found the same device several times by using the USB-Serial-Converter Part No. 0058060-0020 / -0040?

By using USB serial converter at a HSP5 interface of F5/B6, a device is found at each searched node address, since at HSP5 the node addresses are not specified (always only 1 node at HSP5). The USB serial converter converts the HSP5 protocol to DIN66019, and there the node addresses are queried. Solution: Search only at one node address. Or at manually searching, mark and open only one device.

29.1.8 By using USB serial converter at a HSP5 interface of F5/B6, the drive controller will be not or only by searching several times found.

In default of COMBIVIS 6 with connected USB serial converter the searching procedure starts with 9600 baud and counts upwardly afterwards. Since HSP5 always works with 38400 baud, the USB serial converter must first count up the baud rate. → Preset the baud rate at the corresponding interface to 38400 baud, by way the drive controller is then reliably found.

Note: When using the USB serial converter at a serial interface DIN66019, another baud rate may also be correct (default F5: 9600 baud).

29.1.9 When changing a parameter value, the property editor window is not shown. Or: Parameter values cannot be entered/changed.

Please try to open the property editor window in the toolbar menu "view". Afterwards search at the screen frame to see if the property editor window is not collapsed. If found, click into the property editor window, and open it.

Clicking on the pin symbol fixes the window size.

Also possible: "Menu" → "Window" → "Reset Window Layout".



Fig. 461: FAQ Property Editor

29.1.10 The copy function Fr01 at COMBIVERT F5/B6/G6 seems not to work.

With the parameter set copy function Fr01 at COMBIVERT F5/B6/G6 finished sets can be copied to other sets and then does not have to enter all the parameters again. The copy function runs in the drive controller and is triggered by COMBIVIS by entering the parameter Fr01 only.

Because of the parameter "copy function" is set programmable, the set addressing mode plays an essential role in the process.

When copying the "collapsed" parameter the direct addressed set is the target (usually are then target and source set equal to 0):




Fig. 462: FAQ Copy function

Solution: Please adjust in column "set" the number of the set which is the target of the copying and adjust in the column "Offline/Online value" the number of the set which is to copy.

29.1.11 When creating a new project, the location is displayed as C:\user\... However, there is no file with this name in the Windows 7 workstation.

With Windows 7, the file names given by the system are handled in English. In the "work-space", the original names ("user") are then overlaid with the translated text ("user"). However, COMBIVIS (and most other programmes) can only access the original name ("user"). This even goes so far that you can create the file name "user" again, since the other file is originally called "user". Solution: "User" = "user" or "programs" = "programs" etc.

29.1.12 In editor is shown "service not available" at every parameter value“.

When operating with bus systems in "synchronous operation" only indirect addressing may be used.

(⇒ [Set addressing \[▶ 112\]](#))

29.2 FAQ Scope

29.2.1 Is it possible to record more than 16 channels?

Each scope can handle max. 16 channels, but Scope can be opened several times in a project, each with 16 different channels. However, the fast scope mode only works on 4 channels per device.

29.2.2 Is it possible to save a COMBIVIS 6-scope recording in COMBIVIS 5 (sc5) format?

No, because of different and upgraded structures it is not possible.

29.2.3 Is it possible to merge channels from different scope recordings?

This is planned for a later COMBIVIS 6 version. Currently it is already possible, but only indirectly via export in an Excel-compatible format. Export the scope as a CSV file. In Excel it is possible to merge curves as tables based on time-axis and compare them directly via diagram function.

29.2.4 The externally stored Scope file ending sc6 cannot be opened.

With COMBIVIS 6 versions up to 6.2.2.0 only XML files can be imported!

The .sc6 data format continues to be an XML format. A file extension .sc6 can be renamed to XML and thus imported into earlier COMBIVIS 6 versions.

29.3 Known problems

29.3.1 Scope - horizontal cursors

The **horizontal cursors** in Scope locks only on the values of the first channel. The measured values of the other channels cannot be read.

Workaround:

By "Scope → Settings → Extended": disable the hook at "Cursors snap to values". Within the cursors can be placed freely by mouse.




Fig. 463: Scope Settings

29.3.2 Windows - Decimal point

At German Windows operating system and setting in English, the COMBIVERT G6/F6 ASCL/SCL wizard has problems if the comma is used to separate the decimal place.

Workaround:

If a value with decimal place is entered, **the usual dot in English must be used**. A comma will be ignored! In the display, however, "by default" can be a comma and then also applies. The parameter editor can use either a dot or a comma, both are valid.




Fig. 464: Motor identification

29.3.3 Error message on startup

At starting of COMBIVIS or COMBIVIS studio an error message pops up: The file **C:\Programdata\COMBIVIS6\ COMBIVIS6ProjectDefaults.opt** could not be loaded.

Workaround:

Delete the file in Windows Explorer. Restart the programme.




Fig. 465: Error message on startup

Glossary

CODESYS

CODESYS® is a manufacturer-independent automation software for project planning of control systems. CODESYS is a registered trademark of CODESYS Development GmbH.

COMBIVIS

KEB start-up and parameterizing software.

SCADA

SCADA stands for Supervisory Control and Data Acquisition and describes the basic functions of a SCADA system. Companies use SCADA to control their systems across sites and to collect and record data about their operation.

Index

C

COMBIVIS connect	24
COMBIVIS studio HMI	23

P

Parameterisation version	23
Programming version	23

R

Remote maintenance	24
--------------------	----

S

Safety instructions	21
SCADA	23

V

Visualisation platform	23
------------------------	----

W

Wizard	173
--------	-----



MORE KEB PARTNERS WORLDWIDE:
www.keb-automation.com/contact





Automation with Drive

www.keb-automation.com

KEB Automation KG • Suedstraße 38 • D-32683 Barntrup • Tel: +49 5263 401-0 • E-Mail: info@keb.de

