

1 Installation C6 X1-G1

1.1 Assembly table bracket




Fig. 1: Table assembly C6 X1-G1

① Insert connector from above

② Insert the bracket through the opening, place the washer and nut

③ Tighten the nut

④ Fully assembled table bracket

1.2 Monitor assembly




Fig. 2: Monitor assembly C6 X1-G1

- ① Connect RJ45 connector to the monitor
- ② Fasten the bracket with the screws
- ③ Ready assembled bracket

NOTICE



Maximum expected service life 50,000 bendings!

a) Load capacity no longer guaranteed!

1.3 Dimensions




Fig. 3: Dimensions C6 X1-G1

NOTICE

Hazards and risks through ignorance!

- Read the instructions for use.
- Observe the safety and warning instructions.
- Ask if something is unclear.

NOTICE

Ingress of solid objects!

- To ensure IP20 and TYPE 1 the assembly instructions must be followed scrupulously.

NOTICE

Unpredictable malfunctions

- Installation must be carried out by specialised personnel with the necessary skills.
- Only use this mounting system for its intended purpose as described in this manual.
- Only use original manufacturer parts.
- It is the customer's responsibility to ensure that all mounting systems are correctly assembled and installed using the appropriate instructions.

1.4 Disposal

Electronic devices of KEB Automation KG are intended for professional, commercial processing (so-called B2B devices).

Manufacturers of B2B devices are obliged to take back and recycle devices manufactured after 14.08.2018. In principle, these devices may not be left at public or communal recycling or collection points.



Unless otherwise agreed between the customer and KEB or unless there is a deviating mandatory legal regulation, KEB products labelled in this way can be returned. Company and keyword for the return point can be found in the list below.

Shipping costs are at the expense of the customer. The devices are then professionally recycled and disposed of.

The entry numbers are listed country-specifically in the following table. KEB addresses can be found on our website.

| Withdrawal by | WEEE registration no. | Keyword |
|-------------------------|-----------------------------|------------------------------------|
| Germany | | |
| KEB Automation KG | EAR: DE12653519 | Keyword: "Withdrawal WEEE" |
| France | | |
| RÉCYLUM – Recycle point | ADEME: FR021806 | Mots clés "KEB DEEE" |
| Italy | | |
| COBAT | AEE: (IT) 19030000011216 | Parola chiave "Ritiro RAEE" |
| Austria | | |
| KEB Automation GmbH | ERA: 51976 | Keyword: "Withdrawal WEEE" |
| Spain | | |
| KEB Automation KG | RII-AEE: 7427 | Palabra clave "Retirada RAEE" |
| Czech republic | | |
| KEB Automation KG | RETELA: 09281/20-ECZ | Klíčové slovo "Zpětný odběr OEEZ" |
| Slovakia | | |
| KEB Automation KG | ASEKOL: RV22EEZ0000421 | Kľúčové slovo: "Spätňý odber OEEZ" |

The packaging must be sent for paper and cardboard recycling.